Batmax J2011-01-US, J2011-03-US

Batmax Replacement Battery User Manual

For Jawbone Big Jambox Models J2011-01-US & J2011-03-US

Product Overview

This manual provides essential information for the installation, operation, and maintenance of your Batmax replacement battery, designed specifically for the Jawbone Big Jambox J2011-01-US and J2011-03-US portable speakers. This high-quality Li-ion battery ensures extended performance and reliability for your device.



Image: Batmax replacement battery for Jawbone Big Jambox, shown with the included screwdriver and pry tools for installation.

Key Features:

- **Compatibility:** Specifically designed for Jawbone Big Jambox J2011-01-US and J2011-03-US models.
- **Battery Type:** Rechargeable Li-ion Battery.
- **Capacity:** 3250mAh, providing extended usage time.
- **Voltage:** 11.1V.
- **Quality:** Premium Grade A cell for longer battery life with no memory effect.
- **Certifications:** CE certified, tested to match OEM product standards.
- **Included:** One (1) replacement battery and necessary installation tools.

Specifications

Specification	Detail
Battery Type	Li-ion
Capacity	3250mAh
Voltage	11.1V
Compatibility	Jawbone Big Jambox J2011-01-US, J2011-03-US
Package Dimensions	8.74 x 1.65 x 1.54 inches
Item Weight	7.4 ounces
Battery Cell Composition	Lithium Ion
Number of Batteries	1 (included)

Installation (Setup)

Replacing the battery in your Jawbone Big Jambox requires careful handling. It is recommended to consult a device-specific disassembly guide or a professional if you are unsure about the process. The included tools are designed to assist in opening the device and safely removing the old battery.

General Installation Steps:

1. **Power Off:** Ensure your Jawbone Big Jambox is completely powered off and disconnected from any power source.
2. **Disassembly:** Carefully open the speaker casing using the provided pry tools. Locate the existing battery.
3. **Disconnect Old Battery:** Gently disconnect the old battery's connector from the speaker's circuit board. Note the orientation of the connector.
4. **Remove Old Battery:** Carefully remove the old battery. It may be secured with adhesive; proceed with caution to avoid damaging other components.
5. **Install New Battery:** Place the Batmax replacement battery into the battery compartment. Ensure it fits securely.
6. **Connect New Battery:** Connect the new battery's connector to the circuit board, ensuring proper alignment and a secure connection.
7. **Reassembly:** Carefully reassemble the speaker casing, ensuring all clips and screws are properly secured.
8. **Initial Charge:** After installation, fully charge the new battery before its first use.



Image: The Batmax battery showing its electrical connector, which must be properly aligned and connected during installation.

Operation

Once installed, the Batmax battery operates seamlessly with your Jawbone Big Jambox. For optimal performance and longevity, follow these guidelines:

- **First Use:** Fully charge the battery before its initial use to calibrate the battery management system.
- **Charging:** Use the original Jawbone Big Jambox charger or a compatible charger. Avoid using unapproved chargers.
- **Discharging:** It is generally recommended to avoid completely draining the battery frequently. Partial discharges and charges are often better for Li-ion battery health.
- **Performance:** The 3250mAh capacity provides extended playback time, allowing for longer enjoyment of your speaker.



Image: The Batmax battery positioned next to a Jawbone Big Jambox speaker, illustrating its capability to provide extended operational hours.



Image: A graphic highlighting the Batmax battery's 3250mAh capacity, contributing to long battery life and fast charging.

Maintenance and Safety

Proper maintenance and adherence to safety guidelines are crucial for the longevity of your battery and the safety of your device.

Battery Care:

- **Temperature:** Avoid exposing the battery to extreme temperatures (hot or cold), as this can degrade performance and lifespan.
- **Storage:** If storing the device for an extended period, ensure the battery is charged to about 50-60% and store in a cool, dry place.
- **Cleaning:** Keep battery contacts clean and free from dust or debris.

Safety Precautions:

- **Do not connect improperly:** Ensure correct polarity when connecting the battery. Improper connection can damage the battery and device.
- **Do not dispose of battery in fire:**Batteries may explode if disposed of in fire.
- **Battery may explode if damaged:** Do not puncture, drop, or subject the battery to strong mechanical shocks.
- **Do not expose the battery to liquid:**Keep the battery dry and away from water or other liquids.
- **Recycle Properly:** Dispose of old batteries according to local regulations for lithium-ion batteries. Do not discard with household waste.

Troubleshooting

If you encounter issues with your Batmax replacement battery, consider the following common troubleshooting steps:

- **Battery Not Charging:**
  - Verify that the charger is functioning correctly and is properly connected to the speaker.
  - Ensure the battery connector inside the speaker is securely attached and not loose.
  - Check for any visible damage to the charging port or cable.
- **Short Battery Life:**
  - Ensure the battery was fully charged after installation.
  - Avoid extreme temperatures during use and charging.
  - Reduce speaker volume or disable unnecessary features to conserve power.
- **Speaker Not Powering On:**
  - Confirm the battery is fully charged.
  - Re-check all internal connections to ensure the battery is properly installed.
  - If possible, test the speaker with a known working power source (e.g., directly plugged in without battery) to rule out other device issues.

If these steps do not resolve the issue, please refer to the Support section for further assistance.

Warranty and Support

Batmax products are designed for reliability and performance. This battery is CE certified and tested by the manufacturer to match OEM product standards.

For any questions, concerns, or technical assistance regarding your Batmax replacement battery, please contact the seller directly. Your satisfaction is important to us.

You can visit the official Batmax store on Amazon for more information and contact options:Batmax Amazon Store.

© 2024 Batmax. All rights reserved.
This manual is for informational purposes only. Batmax is not responsible for any damage or injury caused by improper installation or misuse of the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question