

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR Professional Hair Clipper V-276 User Manual](#)

VGR V-276

VGR Professional Hair Clipper V-276 User Manual

Model: **V-276** | Brand: **VGR**

1. INTRODUCTION

Thank you for choosing the VGR Professional Hair Clipper V-276. This manual provides essential information for the safe and effective use, maintenance, and care of your new hair clipper. Please read it thoroughly before first use and keep it for future reference.

2. SAFETY INFORMATION

Important Safety Instructions:

- Use once a day.
- Keep the device away from water. Do not use near bathtubs, showers, basins, or other vessels containing water.
- Avoid contact with eyes and skin.
- Do not use on infants.
- Disconnect power when not in use or before cleaning.
- Always follow recommended cleaning and maintenance procedures.
- This appliance is intended for household use only.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- VGR Professional Hair Clipper V-276 Unit
- Charging Cable
- Cleaning Brush

- Lubricating Oil
- Multiple Guide Combs



Image: The VGR Professional Hair Clipper V-276 shown with its various guide combs, charging cable, and cleaning brush.

4. PRODUCT FEATURES

The VGR Professional Hair Clipper V-276 is designed for efficient and precise hair grooming. Key

features include:

- **Rechargeable and Cordless Operation:** Provides flexibility and ease of use without being tethered to an outlet.
- **Stainless Steel Blade:** Durable and sharp blade material for effective cutting.
- **Lithium Battery:** Offers reliable power and extended usage time.
- **Self-Grinding Technology:** The fine steel cutter head is designed to maintain sharpness over time.
- **Quick Start Side Push Button:** Conveniently located for easy power control.
- **Liquid Crystal Display (LCD):** Shows available battery power percentage and RPM for precise control.



Image: A close-up view of the VGR Professional Hair Clipper V-276, highlighting its metallic finish and ergonomic design.

5. SETUP

5.1 Initial Charging

1. Before first use, fully charge the clipper for approximately 3 hours.
2. Connect the charging cable to the clipper and plug it into a suitable power outlet.
3. The LCD will indicate the charging status and battery percentage.

5.2 Attaching Guide Combs

1. Ensure the clipper is turned off.
2. Select the desired guide comb for your preferred cutting length.
3. Align the comb with the clipper blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb away from the blade.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

1. To turn on the clipper, locate the side push button on the left side of the unit and slide it upwards.
2. To turn off, slide the button downwards.



Lithium battery



Plug and play

SELF-GRINDING TECHNOLOGY OF FINE STEEL CUTTER HEAD

Fine Steel

The whole piece of fine steel material forging, not easy to rust and Perm for professional hairdresser and design, grinding to the end more use more sharp



Image: A diagram illustrating the location and function of the side push button for quick starting the clipper.

6.2 Adjusting Cutting Length

The clipper features an adjustable taper lever and guide combs for varying cutting lengths.

1. Use the guide combs (see Section 5.2) for specific hair lengths.
2. The taper lever, located on the side, allows for fine adjustment of cutting length without changing combs. Move the lever up for a shorter cut and down for a longer cut.

QUICK START WITH SIDE PUSH BUTTON

Switch

Push Button switch on the left side of the machine body, it is convenient and quick to start the machine without delay



Image: The VGR Hair Clipper's liquid crystal display showing battery percentage and RPM, providing real-time operational information.

6.3 General Usage Guidelines

- Ensure hair is clean and dry before clipping.
- Always start with a longer guide comb if you are unsure of the desired length.
- Move the clipper against the direction of hair growth for an even cut.
- This product can be used once a day.

7. MAINTENANCE

7.1 Cleaning the Blades

1. After each use, turn off and unplug the clipper.
2. Use the provided cleaning brush to remove loose hairs from the blades.
3. For a more thorough cleaning, detach the blade unit (refer to specific instructions if provided in a separate diagram or manual for blade removal).

7.2 Lubricating the Blades

1. Regularly apply a few drops of the provided lubricating oil to the blades.
2. Turn on the clipper for a few seconds to allow the oil to distribute evenly.
3. Wipe off any excess oil. Lubrication helps maintain blade sharpness and smooth operation.



Image: A visual representation of the self-grinding technology integrated into the fine steel cutter head, designed for long-lasting sharpness.

7.3 Storage

Store the clipper in a dry place, away from direct sunlight and out of reach of children.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or not charged.	Charge the clipper fully.
Poor cutting performance.	Blades are dull, dirty, or not lubricated.	Clean and lubricate the blades. If dull, consider professional sharpening or replacement.
Clipper pulls hair.	Blades are dirty, dull, or not properly aligned.	Clean and lubricate blades. Ensure blades are correctly assembled.

9. SPECIFICATIONS

- **Model Name:** V-276
- **Brand:** VGR
- **Item Model Number:** V-276
- **Power Source:** Battery Powered (Rechargeable, Cordless)
- **Blade Material:** Stainless Steel
- **Special Features:** Rechargeable, Cordless
- **Target Audience:** Men
- **Material:** Metal
- **Color:** Black
- **Package Dimensions:** 23.9 x 13.9 x 7.4 cm
- **Item Weight:** 850 grams
- **Manufacturer:** VGR

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact the retailer or the VGR customer service department.

Keep your purchase receipt as proof of purchase for warranty purposes.