

[Manuals.plus](#) /

> [WSKEN](#) /

> WSKEN Front Screen Protector for Samsung Galaxy Z Fold 7 - Instruction Manual

WSKEN z fold 7

WSKEN Front Screen Protector for Samsung Galaxy Z Fold 7 - Instruction Manual

Model: z fold 7

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your WSKEN Front Screen Protector for the Samsung Galaxy Z Fold 7. Please read this guide carefully to ensure proper application and optimal performance of your screen protector.



Image: The WSKEN Front Screen Protector package, showing the tempered glass protector and the included installation tools.

WHAT'S INCLUDED

The package for your WSKEN Front Screen Protector includes the following components:

- 4x Screen Protectors
- 1x Install Box
- 4x Install Tool Kits (including wet/dry wipes, dust-absorber sticker)
- Fingerprint Unlocking Manual
- Installation Instructions
- After-Sales Guarantee Card

SETUP AND INSTALLATION

Follow these steps for a successful, bubble-free, and dust-free installation of your screen protector.




Image: Step-by-step visual guide for installing the screen protector using the provided installation box.

1. **Prepare Your Device:** Ensure your Samsung Galaxy Z Fold 7 is powered off and clean. Use the provided wet and dry wipes from the install tool kit to thoroughly clean the screen surface. Remove any remaining dust particles with the dust-absorber sticker.
2. **Position the Phone:** Place your phone into the mounting box in the correct orientation, ensuring it is securely seated.
3. **Install the Screen Protector:** Carefully place the screen protector into the mounting box, aligning it with the phone's screen. Ensure the holes and edges are correctly positioned.
4. **Dust Removal:** Pull the dust-elimination film to remove any fine particles from the screen surface. This innovative electrostatic dust removal device ensures a clean application.



Image: A visual representation of the innovative electrostatic dust removal device, demonstrating how it cleans the screen during installation.

5. **Bubble Removal:** Slowly pull the cover back and forth using the roller device to force out air bubbles. Be patient during this process to ensure all bubbles are removed for a zero-residue finish.



Image: This image shows the exclusive design of the roller device, used to push out air bubbles for a smooth, residue-free application.


6. **Final Step:** Gently tear away the outer protective layer from the screen protector.

Fingerprint Sensor Re-registration

After installing the screen protector, it is crucial to re-register your fingerprints to ensure optimal performance of the in-display fingerprint scanner. This enhances touch sensitivity and recognition accuracy.

Upgraded 24° Anti-Peep

Protect your privacy anytime, anywhere...



Experience Original Fingerprint Unlock

Enhanced "ultrasonic" technology ensures faster, more responsive unlocking every time!

Image: Guide for adjusting fingerprint settings and re-scanning fingerprints.

1. Open "**Settings**" on your device.
2. Navigate to "**Privacy**" or "**Biometrics and security**" (depending on your Android version).
3. Select "**Fingerprints**".
4. Delete any previously stored fingerprints.
5. Re-scan your fingerprint **TWICE** from different angles to ensure the scan area is as large and comprehensive as possible.

OPERATING INSTRUCTIONS

Your WSKEN screen protector is designed to maintain the original touch experience and visual clarity of your Samsung Galaxy Z Fold 7.

- **Touch Sensitivity:** The screen protector is engineered for high touch responsiveness. If you experience reduced sensitivity, ensure your fingerprints are re-registered as described in the Setup section.
- **Clarity:** Enjoy 8K HD clarity with high transparency, preserving the original display quality.
- **Anti-Fingerprint:** The nano-coating helps reduce fingerprints and smudges, keeping your screen clean.
- **Case Friendly:** The protector is precisely cut to ensure compatibility with most phone cases.



Image: This visual demonstrates the precise cut and slim profile of the screen protector, ensuring a perfect fit that is compatible with most phone cases.

- **Durability:** Built with triple-reinforced 9H+ tempered glass, it offers military-grade protection against drops

and scratches.



Image: This image illustrates the robust, multi-layered construction of the 9H+ tempered glass, designed for enhanced durability and impact resistance.

- **Smooth Glide:** The 4-layer electroplating and nano-coating provide a silky, responsive touch, ideal for typing, swiping, and gaming.

Image: This image highlights the silky smooth surface and anti-fingerprint coating of the screen protector, providing an enhanced user experience.

MAINTENANCE

To maintain the clarity and effectiveness of your screen protector, follow these simple maintenance tips:

- **Cleaning:** Use a soft, lint-free cloth, preferably microfiber, to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:** While the protector is highly durable, avoid contact with sharp objects to prevent scratches or damage.
- **Temperature Exposure:** Avoid exposing your device to extreme temperatures, as this can affect the adhesive and material integrity of the screen protector.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Issue	Solution
Fingerprint scanner not working or slow.	Re-register your fingerprints after installation. Go to Settings > Privacy/Biometrics and security > Fingerprints, delete old prints, and re-scan twice from different angles. Ensure "Touch sensitivity" is enabled in Display settings if available.

Issue	Solution
Bubbles under the screen protector.	During installation, use the roller device to push out air bubbles. For small remaining bubbles, they may disappear naturally within 24-48 hours. If large bubbles persist, carefully lift the nearest edge of the protector and re-apply, pushing out air as you go.
Dust particles trapped under the protector.	This usually occurs during installation. Ensure the screen is completely dust-free before application using the dust-absorber sticker. If dust is trapped, it may require removing and re-applying a new protector from the pack.
Reduced touch sensitivity.	Check your phone's display settings for a "Touch sensitivity" option and enable it. Re-registering fingerprints can also help.

SPECIFICATIONS

Feature	Detail
Brand	WSKEN
Compatible Devices	Samsung Galaxy Z Fold 7
Material	Tempered Glass
Item Hardness	Tougher than 9H
Product Dimensions	2"L x 1"W
Special Features	Easy Installation, Auto Dust Remove, Zero Bubble, Case Friendly, HD Clarity, Eye Care, Anti-Fingerprint
Finish Type	Glossy
Unit Count	1 Count (package contains multiple protectors)
Screen Size (for protector)	6.1 Inches (Note: This refers to the cover screen size of the Z Fold 7)
Clarity	99%
Model Number	z fold 7
Part Number	WSKENJTG003rrr

WARRANTY AND SUPPORT

WSKEN offers a comprehensive warranty and support for your screen protector.

- **Warranty:** A 180-day free replacement warranty is provided for your WSKEN Samsung Galaxy Z Fold 7 screen protector. This covers issues such as wrong size, damage, or installation problems.

- **Customer Support:** For any questions, concerns, or warranty claims, please contact WSKEN customer service. Refer to the "After-Sales Guarantee Card" included in your package for specific contact details.

© 2026 WSKEN. All rights reserved.