

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Disney](#) /
- › [Disney Pixar Cars 1:14 Lightning McQueen R/C Instruction Manual](#)

## Disney 31775

# Disney Pixar Cars 1:14 Lightning McQueen R/C Instruction Manual

Model: 31775 | Brand: Disney

## PRODUCT OVERVIEW

Ka-chow! Lightning McQueen makes his return to the track in radio control form in this 1:14 scale R/C inspired by Disney/Pixar Cars! This authentically licensed Lightning McQueen is a full function radio control with real working suspension, pistol-grip controller, lithium-ion USB rechargeable battery and 2.4 GHz. With this radio control in hand, you can go faster than fast, quicker than quick... you are Lightning! The kids will have hours of fun with Lightning McQueen and their friends. The vehicle is 7 x 14 x 8.25".

## Key Features:

- Inspired by Disney/Pixar Cars!
- Full function R/C with real working suspension.
- Pistol grip controller.
- USB Charging. Rechargeable battery.
- 2.4 GHz



## SETUP GUIDE

### 1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure all parts are present: Lightning McQueen R/C vehicle, pistol-grip controller, and USB charging cable.



Image: The Lightning McQueen R/C car and its remote control, ready for setup.

### 2. Controller Battery Installation

The pistol-grip controller requires 2x AA batteries (not included). Open the battery compartment on the underside of the controller and insert the required batteries, observing polarity.

### 3. Vehicle Charging

The Lightning McQueen R/C vehicle features a built-in lithium-ion USB rechargeable battery. Locate the USB charging port on the vehicle (usually on the underside or within a compartment). Connect the provided USB charging cable to the vehicle and to a compatible USB power source (e.g., computer, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.



Image: View of the vehicle's underside, highlighting the power switch and charging port.

## OPERATING INSTRUCTIONS

### 1. Power On/Off

Turn on the vehicle using the switch located on its underside. Turn on the controller using its power switch. The indicator lights on both the vehicle and controller should illuminate, indicating a successful connection.

### 2. Driving the Vehicle

Use the joystick on the pistol-grip controller to control the vehicle's movement. Push forward for forward motion, pull back for reverse. Use the steering wheel/buttons for left and right turns. The 2.4 GHz frequency ensures responsive control.

### 3. Suspension System

The vehicle is equipped with real working suspension, allowing it to navigate uneven surfaces and small obstacles effectively. This feature enhances playability on various terrains.



Image: Side profile of the R/C car, illustrating its robust suspension for off-road play.

## MAINTENANCE AND CARE

- **Cleaning:** Wipe the vehicle and controller with a soft, damp cloth. Do not immerse in water.
- **Storage:** Store the R/C car and controller in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Fully charge the vehicle's battery before extended storage. Remove batteries from the controller if not used for a long period.
- **Durability:** The vehicle's plastic body is designed to withstand typical play, but avoid excessive force or impacts to prevent damage.

## TROUBLESHOOTING

- **Vehicle Not Responding:** Ensure both the vehicle and controller are powered on. Check controller batteries and vehicle charge level.
- **Poor Range/Interference:** Ensure no other 2.4 GHz devices are operating nearby. Move to an open area away from large metal objects or other electronic interference.
- **Slow Movement:** Recharge the vehicle's battery.

## PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	31775
Scale	1:14
Dimensions	19.61 x 9.97 x 9.41 inches
Item Weight	2.99 pounds

Recommended Age	6 years and up
Battery Type	Lithium-ion (USB Rechargeable)
Frequency	2.4 GHz
Manufacturer	Disney
Release Date	August 1, 2021

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Manufacturer: [Disney](#)