

[Manuals.plus](#) /

> [Mattel](#) /

> [Mattel Jurassic World Dominion Minis Giganotosaurus Rampage Playset Instruction Manual](#)

Mattel HFF12

Mattel Jurassic World Dominion Minis Giganotosaurus Rampage Playset Instruction Manual

1. PRODUCT OVERVIEW

The Mattel Jurassic World Dominion Minis Giganotosaurus Rampage Playset brings the action of Jurassic World Dominion's Biosyn Valley to life. This playset includes interactive features such as a puck-style launcher, swinging gates, movable foliage, and a hilltop building that can break apart to reveal a hidden dinosaur. It comes with two mini dinosaur figures, including the Giganotosaurus, allowing for dynamic play scenarios.

2. WHAT'S IN THE BOX

The package contains the following components:

- 1 Jurassic World Giganotosaurus Rampage Playset
- 2 Mini Dinosaur Figures (including Giganotosaurus)



Image: All components included in the Giganotosaurus Rampage Playset.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Giganotosaurus Rampage Playset:

1. Remove all components of the Giganotosaurus Rampage Playset from its packaging.
2. Ensure all pieces are present as listed in the 'What's in the Box' section.
3. Place the playset base on a flat, stable surface.
4. Position the hilltop building and gates as shown in the product images.

4. OPERATING INSTRUCTIONS

Engage with the playset's interactive features:

- **Launch Mini Dinosaurs:** Use the puck-style launcher to propel mini dinosaurs into the playset. Place a mini dinosaur on the launcher and press down to send it into action.



Shoot the dino into action!

Image: Using the puck-style launcher to send a mini dinosaur into play.


- **Break Apart Building:** Target a mini dinosaur at the building located on top of the hill. Upon impact, the building will break open, revealing another mini dinosaur figure hidden inside.

Destroy the building!



Image: The building breaking apart to reveal a hidden dinosaur.

- **Interact with Gates and Foliage:** The playset features swinging gates and movable foliage. Utilize these elements to create dynamic obstacles and hiding spots for your mini dinosaurs during play.



Crash the gate!

Image: The playset's crashable gate feature.

- **Connect to Other Playsets:** The playset includes a connector piece that allows it to link with the Mosasaurus Mayhem Playset (sold separately), expanding play possibilities.

Product Demonstration Video: A Closer Look

Your browser does not support the video tag.

Video: A detailed demonstration of the Mattel Jurassic World Dominion Minis Giganotosaurus Rampage Playset features and functionality.

5. PRODUCT FEATURES

- Replicates the Biosyn Valley setting from the Jurassic World Dominion movie.
- Includes a puck-style launcher for mini dinosaur figures.
- Features swinging gates and movable foliage for interactive play.
- Hilltop building designed to break apart, revealing a hidden dinosaur.
- Comes with two mini dinosaur figures, including the Giganotosaurus.
- Connects to the Mosasaurus Mayhem Playset (sold separately) for expanded play.
- Compatible with Jurassic World Matchbox vehicles (sold separately).



Movie-inspired setting!

Image: The playset depicting a movie-inspired setting.

6. SPECIFICATIONS

Attribute	Detail
Brand	Mattel
Model Name	Jurassic World Minis Playset Giant Dino Rampage Playset
Model Number	HFF12
UPC	194735038596
Material Type	Plastic
Item Dimensions (L x W x H)	9.83 x 9.8 x 7.25 inches
Number of Pieces	4
Recommended Age	4 years and older
Assembly Required	No

Batteries Required	No
Operation Mode	Manual

7. MAINTENANCE

To ensure the longevity of your playset:

- Clean the playset and figures with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Store the playset in a dry, cool place away from direct sunlight to prevent material degradation.
- Regularly check for any loose or damaged parts. Discontinue use if any significant damage is found.

8. TROUBLESHOOTING

If you encounter any issues with your playset:

- **Launcher not working:** Ensure the mini dinosaur is correctly seated on the puck-style launcher before attempting to launch.
- **Building not breaking apart:** Verify that the mini dinosaur is aimed directly at the designated impact point on the hilltop building.
- **Playset components not connecting:** Check that the connector pieces are aligned properly and gently push them together until they click into place.
- For any other concerns, refer to the product packaging or contact customer support.

9. WARRANTY AND SUPPORT

This product is provided with no specific manufacturer warranty description. For product support or inquiries, please visit the official Mattel store or contact their customer service.

Mattel Store: <https://www.amazon.com/stores/Mattel/page/328E252D-880D-4924-97D2-E9A392151155>