Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit CT-95018

ZdalaMit Infrared Replacement Remote Control for Toshiba TVs (CT-95018)

Instruction Manual

1. Introduction

This manual provides instructions for the ZdalaMit CT-95018 Infrared Replacement Remote Control, designed for various Toshiba TV models. This remote offers a straightforward, pre-programmed solution for controlling your television without the need for complex setup or pairing.





Figure 1: Front view of the ZdalaMit CT-95018 Infrared Replacement Remote Control.

2. Important Notes

- **Infrared Remote:** This is an infrared (IR) remote control. It requires a direct line of sight to your TV's IR receiver to function correctly.
- **No Voice Control:** This remote control **does not** feature voice control functionality.
- **No Programming or Pairing Needed:** The remote is pre-programmed and ready to use with compatible Toshiba TVs. No manual programming or pairing steps are required for basic operation.
- **Fire TV Pairing Mode:** If your Toshiba Fire TV screen displays "Searching for your remote" or is stuck in pairing/initial setup mode, this infrared remote control will not work to bypass this step. A voice remote control is typically needed to proceed in such situations. This remote will function once the pairing step is skipped or completed using an appropriate voice remote.

3. Package Contents

- 1x ZdalaMit Infrared Replacement Remote Control (Model: CT-95018)

Note: 2x 1.5V AAA Alkaline Batteries are required and are not included in the package.

4. Setup & Battery Installation

1. **Locate Battery Compartment:** Turn the remote control over to its back. The battery compartment cover is located at the bottom.
2. **Open Compartment:** Gently slide the battery compartment cover downwards to open it.
3. **Insert Batteries:** Insert two (2) AAA 1.5V Alkaline batteries into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside.
4. **Close Compartment:** Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Battery installation in the remote control. Ensure correct polarity.

5. Operation

Once batteries are installed, the ZdalaMit CT-95018 remote control is ready for immediate use with your compatible Toshiba TV. Point the remote directly at your television's infrared receiver and press the desired buttons.

Compatible Toshiba TV Models:

- CT-95018
- 50LF711U20, 65LF711U20, 43LF711U20
- 32LF221U19, 43LF421U19, 43LF621U19, 50LF621U19, 55LF711U20
- TF-50A810U19, TF-32A710U21, TF-43A810U21, TF-50A810U21, TF-55A810U21
- 49LF421U19, 55LF621U19, 55LF621C21, 32LF221C21, 50LF621C21, 43LF621C21
- 43C350KC, 50C350KC, 55C350KC, 65C350KC, 75C350KC



Figure 3: Overview of remote control buttons.

6. Troubleshooting

- **Remote Not Responding:**
  - Ensure fresh AAA batteries are correctly installed with proper polarity.
  - Check for any obstructions between the remote and the TV's IR receiver.
  - Make sure you are within a reasonable range and pointing the remote directly at the TV.
- **TV Stuck in Pairing Mode:** As noted in Section 2, this infrared remote cannot bypass the "Searching for your remote" or initial pairing screen on Fire TVs. A voice-enabled remote is required for that specific step.
- **Specific Buttons Not Working:** If only certain buttons are unresponsive, ensure the remote is clean and free from debris that might be jamming the buttons. If the issue persists, the remote may be faulty.

7. Specifications

Brand	ZdalaMit
Model	CT-95018
Compatible Devices	Toshiba Televisions (various models listed in Section 5)
Special Features	Pre-programmed, Infrared (IR)
Power Supply	2x 1.5V AAA Alkaline Batteries (not included)
Color	Black
Dimensions	15.24 x 3.3 x 1.27 cm
Weight	40 g

8. Support

Should you encounter any issues or have questions regarding your ZdalaMit replacement remote control, please do not hesitate to contact us. We are here to assist you.

© 2026 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CGKS63Y

More documents and user manuals: **https://manuals.plus/**