Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Kamon /
- > Kamon 5 Pack Earbuds Headphones with Remote & Mic, Earphones Wired Stereo in-Ear Bass (K2) Instruction Manual

Kamon K2 (KE)

Kamon 5 Pack Earbuds Headphones with Remote & Mic

Model: K2 (KE) | Brand: Kamon

NTRODUCTION

This instruction manual provides essential information for the proper use, setup, and maintenance of your Kamon 5 Pack Earbuds Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Kamon K2 Earbuds are wired stereo in-ear headphones designed for a wide range of devices with a 3.5mm interface. They feature an in-line remote and microphone for convenient call and music control.



Figure 1: Kamon 5 Pack Earbuds in various colors.

Key Features

- **Built-in Microphone & Remote:** Multi-functional button for answering/ending calls, playing/pausing music, and track navigation.
- Ergonomic Comfort: In-ear design for a secure and comfortable fit, reducing external noise.
- **High Fidelity Sound:** Delivers clear audio with driving bass, tight mids, and precise treble response.
- Wide Compatibility: Compatible with iPhone, Android smartphones, iPod, iPad, MP3 players, and other 3.5mm audio jack devices.
- Tangle-Free Cable: Durable, resistant cable designed to prevent tangling.




Figure 2: Internal dynamic speaker system for high-fidelity sound.



Figure 3: Ergonomic design for comfortable wear.

PACKAGE CONTENTS

The Kamon 5 Pack Earbuds package includes the following items:

• 5 x Earphones (2 x Black, 1 x White, 1 x Pink, 1 x Green)

• Ear Cushions (pre-installed or included as spares)

SETUP

Connecting the Earbuds

- 1. Locate the 3.5mm audio jack on your device (smartphone, tablet, laptop, MP3 player, etc.).
- 2. Insert the 3.5mm plug of the Kamon earbuds firmly into the device's audio jack.
- 3. For optimal connection, you may gently rotate the earbud plug a few cycles when connecting to your phone.



Figure 4: Wide compatibility with 3.5mm universal interface.

OPERATING INSTRUCTIONS

In-line Remote and Microphone Functions

The multi-functional button on the in-line remote allows for easy control of calls and music playback:

- **Answering/Ending Calls:** Press the button once to answer an incoming call. Press it once again to end an active call.
- Refusing Calls: Press the button two times to refuse an incoming call.
- Play/Pause Music: Press the button once to play or pause the current music track.
- Next Track: Press the button two times to skip to the next music track.
- Previous Track: Press the button three times to go back to the previous music track.



Figure 5: In-line remote control functions.

MAINTENANCE

Care and Handling

- Avoid Pulling the Cord: Do not pull the earbud cord directly when disconnecting. Always hold the earphone plug part and the earbud part when removing from devices or ears.
- **Storage:** Store the earbuds in a clean, dry place when not in use. The tangle-free cable helps prevent knots.
- **Cleaning:** Gently wipe the earbuds with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Temperature:** Do not expose the earbuds to extreme temperatures or direct sunlight for prolonged periods.

TROUBLESHOOTING

Common Issues and Solutions

Problem Possible Cause

Problem	Possible Cause	Solution
No sound or sound from only one earbud	Loose connection, incorrect plug insertion, device audio settings.	Ensure the 3.5mm plug is fully inserted. Gently rotate the plug in the jack. Check device's volume and audio output settings. Test with another device.
Microphone not working	Loose connection, device microphone settings, incompatible device.	Ensure the plug is fully inserted. Check your device's privacy settings for microphone access. Test with another device.
Remote control not responding	Loose connection, incompatible device, software glitch.	Ensure the plug is fully inserted. Some older devices or specific apps may not fully support all remote functions. Restart your device.
Sound distortion or buzzing	Poor connection, damaged cable, audio source issue.	Re-insert the plug. Test with another audio source or device. Inspect the cable for visible damage.

SPECIFICATIONS

Feature	Detail	
Model Name	kE (K2)	
Connectivity Technology	Wired (3.5mm Jack)	
Impedance	32ohm±15% at 1KHz	
Frequency Response	20~20,000Hz	
Power Rating	3mW	
Maximum Input Power	5mW	
Distortion	3% Maximum (1KHz/1mW)	
Cord Length	120cm	
Weight	11g	
Control Type	Remote (in-line)	
Cable Feature	Tangle Free Cord	
Material	Polycarbonate (PC), Rubber, Silicone, Thermoplastic Elastomer (TPE)	
UPC	743534707136	


WARRANTY AND SUPPORT

Kamon products are designed for reliability and performance. For specific warranty information, please refer to the product packaging or contact Kamon customer support directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance or technical support, please visit the official Kamon website or contact their customer service department.

© 2025 Kamon. All rights reserved.

Related Documents - K2 (KE)



LOSØI

LOSEI TWS-K2 Wireless Headset: FAQ and User Guide

Comprehensive FAQ and user guide for the LOSEI TWS-K2 Wireless Headset, covering pairing, charging, troubleshooting, and features. Learn how to connect, use, and maintain your wireless earbuds.