

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 2-Prong 9V AC/DC Adapter for Homitt HM115 Series Electric Spin Scrubber

UPBRIGHT 2-Prong 9V AC/DC Adapter

UpBright 2-Prong 9V AC/DC Adapter Instruction Manual

Compatible with Homitt HM115 Series Electric Spin Scrubbers

1. PRODUCT OVERVIEW

This UpBright 2-Prong 9V AC/DC Adapter is designed to provide reliable power and charging for specific Homitt Electric Spin Scrubber models. It converts standard AC wall power to the required 9V DC output for your device.



Image 1.1: The UpBright 2-Prong 9V AC/DC Adapter. This image displays the compact black adapter with its attached power cord, featuring a 2-prong connector at the end.

2. SAFETY INFORMATION

For safe operation and to prevent damage to the adapter or your device, please observe the following safety guidelines:

- **Input Voltage:** Ensure the adapter is connected to a power outlet within the specified input voltage range of 100-240VAC, 50/60Hz.
- **Protection Features:** This adapter includes built-in safety features:
 - **OVP (Over Voltage Output Protection):** Protects against excessive output voltage.
 - **OCP (Over Current Output Protection):** Guards against excessive output current.
 - **SCP (Short Circuit Output Protection):** Prevents damage from short circuits.
- **Environment:** Use the adapter in a dry environment. Avoid exposure to water, moisture, or high humidity.

- **Ventilation:** Do not cover the adapter during use to ensure proper ventilation and prevent overheating.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter.



Image 2.1: UpBright adapter highlighting internal components and protection icons. This image illustrates the adapter's internal circuitry and symbols representing Short-Circuit Protection, Over-Temp Protection, Over-Voltage Protection, and Overcurrent Protection.

3. COMPATIBILITY

This adapter is specifically designed for use with the following Homitt Electric Spin Scrubber models that utilize **2-prong charging port**:

- Homitt HM115C
- Homitt HM115D
- Homitt HM115CW
- Homitt HM115CD

- Homitt HM115CG
- Homitt HM115E
- Compatible with Homitt FD Model: DK10-090-0650

Important Compatibility Notes:

- **NOT compatible with 3.65V versions.**
- **NOT compatible with 5.5V versions.**
- **NOT compatible with Homitt models that use a round charging port.** This adapter features a 2-prong connector.



Image 3.1: This image demonstrates the compatibility of the 2-prong connector with newer Homitt scrubber models, clearly showing the correct 2-prong charging port and indicating incompatibility with older round charging ports.

4. SETUP AND OPERATION

4.1 Initial Setup

1. **Unpack:** Carefully remove the AC/DC adapter from its packaging.
2. **Inspect:** Check the adapter and its cable for any visible damage. Do not use if damaged.

4.2 Charging Your Device

1. **Connect to Scrubber:** Insert the 2-prong connector of the UpBright adapter firmly into the charging port of your compatible Homitt Electric Spin Scrubber. Ensure the connection is secure.
2. **Connect to Power Outlet:** Plug the 2-prong end of the adapter into a standard 100-240VAC wall outlet.
3. **Charging Indicator:** Refer to your Homitt Electric Spin Scrubber's user manual for information on its charging indicator light (e.g., color changes for charging, fully charged, or in use). Charging typically takes 3-4 hours for over 90 minutes of runtime.

4. **Disconnect:** Once your device is fully charged, unplug the adapter from the wall outlet first, then disconnect it from the scrubber.



Image 4.1: This image shows the UpBright 2-prong adapter correctly connected to a Homitt Electric Spin Scrubber, illustrating the 'Perfect Matching' of the connector type and the scrubber in various cleaning scenarios.

5. MAINTENANCE

Proper care and maintenance will extend the life of your UpBright AC/DC adapter:

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Cable Care:** Do not pull on the cable to disconnect the adapter. Always grasp the plug itself. Avoid placing heavy objects on the cable or bending it sharply.

6. TROUBLESHOOTING

If you encounter issues with your adapter, please refer to the following common solutions:

- **Device Not Charging:**
 - Ensure the adapter is firmly plugged into both the wall outlet and the scrubber.
 - Verify that the wall outlet is functional by testing it with another device.
 - Confirm that your Homitt scrubber model is listed as compatible (see Section 3).
 - Check the adapter cable and connector for any visible damage.
- **Adapter Overheating:**

- Unplug the adapter immediately.
- Ensure the adapter is not covered and has adequate ventilation.
- If overheating persists, discontinue use and contact support.

- **Loose Connection:**

- Ensure the 2-prong connector is fully inserted into the scrubber's charging port.
- Avoid putting strain on the cable while charging.

If these steps do not resolve the issue, please refer to the Support section.

7. SPECIFICATIONS

Feature	Detail
Brand	UPBRIGHT
Connector Type	2-Prong Connector
Input Voltage	100-240VAC (World Wide Input Voltage)
Input Frequency	50/60Hz
Output Voltage	9 Volts (DC)
Output Current	0.65 Amps (650 Milliamps)
Wattage	10 Watts
Special Features	OVP, OCP, SCP Protection (Over Voltage, Over Current, Short Circuit Protection)
Color	Black
Material	Plastic
Power Source	Corded Electric
Power Plug Type	Type A - 2 pin (North American)
Included Components	1 x AC Adapter
Specification Met	CE

8. WARRANTY INFORMATION

This UpBright AC/DC Adapter comes with the following warranty:

- **Refund Policy:** 30 Days Refund
- **Exchange Policy:** 24 Months Exchange

Please retain your proof of purchase for warranty claims.

9. SUPPORT

For further assistance, technical support, or warranty inquiries, please contact UpBright customer service through the retailer where the product was purchased or visit the official UpBright store page.

When contacting support, please have your product model (UpBright 2-Prong 9V AC/DC Adapter) and purchase details readily available.

Online Resources:

- UpBright Store on Amazon: [Visit Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question