

[manuals.plus](#) /› [BAOBER](#) /› [BAOBER H1 Bluetooth Wireless Over-Ear Headphone Instruction Manual](#)**BAOBER BAOBER H1**

# BAOBER H1 Bluetooth Wireless Over-Ear Headphone Instruction Manual

Model: BAOBER H1

## 1. INTRODUCTION

Thank you for choosing the BAOBER H1 Bluetooth Wireless Over-Ear Headphones. This manual provides detailed instructions for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual carefully before use.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- BAOBER H1 Wireless Over-Ear Headphones
- USB Transmitter
- 3.5mm Audio Cable
- USB Charging Cable
- User Manual

## 3. PRODUCT OVERVIEW AND CONTROLS

Familiarize yourself with the headphone's components and controls.



**Image 3.1: Headphone Controls and Ports**

This diagram illustrates the various features and controls on the BAOBER H1 headphones, including the adjustable headband, rotatable earcups, charging socket, 3.5mm audio input for wired mode, buttons for next/previous song, microphone, volume up/down controls, indicator light, and the ON/OFF button.

- **Adjustable Headband:** For comfortable fit.
- **Rotatable Earcups:** For storage and comfort.
- **Charging Socket:** USB port for charging the headphones.
- **3.5mm Audio-in:** For wired connection (Wired Headphone mode).
- **NEXT/PREV Song Buttons:** Control track selection.
- **Microphone:** Built-in for calls in Bluetooth mode.
- **Volume +/-:** Adjust audio volume.
- **Indicator:** LED light for status (power, pairing, charging).
- **ON/OFF Button:** Power the headphones on or off.

## 4. SETUP AND CONNECTION

---

### 4.1. Charging the Headphones

Before first use, fully charge the headphones. Connect the USB charging cable to the headphone's charging socket and to a 5V USB power source. The indicator light will show charging status and turn off or change color when fully charged (approximately 2 hours).

### 4.2. Using the Headphone Without Transmitter (Bluetooth Mode)

Connect the headphones to your mobile phone or other Bluetooth audio device via Bluetooth 5.0.

1. Ensure the headphones are charged and powered on.
2. Activate Bluetooth on your mobile device.
3. Search for "BAOBER H1" in the list of available Bluetooth devices and select it to pair.
4. Once paired, the indicator light will confirm connection.

In Bluetooth mode, the built-in microphone allows for phone calls, and all button functions (volume, track control) are available.



**Image 4.2: Bluetooth and Wired Connection Examples**

This image demonstrates two connection methods: the headphones wirelessly connected to a cellphone via Bluetooth, enabling button functions and calls; and the headphones connected via a 3.5mm audio cable to a cellphone or computer, where buttons are inactive and no power is required.

### 4.3. Using the USB Transmitter for PC

The USB transmitter allows for wireless audio transmission from your computer to the headphones.

1. Plug the USB transmitter directly into an available USB port on your computer.
2. Power on the BAOBER H1 headphones.
3. The headset and transmitter will automatically pair. Your computer will automatically install the necessary driver.
4. Once paired, the computer's audio will be transmitted to the headphones.

**Note:**

- In this mode, you can only adjust the volume directly through the headphone controls. The computer's volume control will not affect the headphone volume.
- When connected to the transmitter, only volume buttons can be used.

### 4.4. Using the USB Transmitter for TV or 3.5mm Audio Devices

This method enables wireless audio from devices with a 3.5mm audio output, such as TVs or MP3 players.

1. Connect the USB transmitter to your source device (TV, MP3 player) using the 3.5mm audio cable.
2. Plug the USB end of the transmitter into a 5V power supply (e.g., a USB wall adapter, not included).
3. Power on the BAOBER H1 headphones.
4. The headset and transmitter will automatically pair.
5. The audio from your source device will now be transmitted wirelessly to the headphones.

**Note:**

- The audio transmitted in this connection mode is not in stereo.
- When connected to the transmitter, only volume buttons can be used.



**Image 4.4: USB Transmitter Connection Examples**

This image illustrates how to use the USB transmitter: wirelessly connecting the headphones to a computer via the USB transmitter, and connecting the headphones to a TV (with RCA audio-out) or MP3 player using the 3.5mm audio cable and a 5V powered USB transmitter.

Note that only volume controls are active when using the transmitter.

## 4.5. Wired Headphone Mode

You can use the BAOBER H1 as a wired headphone even if the battery is depleted.

1. Connect one end of the 3.5mm audio cable to the headphone's 3.5mm audio-in port.
2. Connect the other end of the 3.5mm audio cable to your audio device's 3.5mm audio output jack.

**Note:**

- In wired mode, all headphone buttons (volume, track control, power) are inactive. Audio control must be done via the connected device.
- The headphones do not require power in wired mode.

## 5. OPERATING INSTRUCTIONS

### 5.1. Power On/Off

- **Power On:** Press and hold the ON/OFF button until the indicator light illuminates.
- **Power Off:** Press and hold the ON/OFF button until the indicator light turns off.

### 5.2. Volume Control

- Press the Volume + button to increase volume.
- Press the Volume - button to decrease volume.

**Note:**

- Volume controls are active in Bluetooth mode and when using the USB transmitter.
- Volume controls are inactive in wired (3.5mm audio cable) mode.

### 5.3. Music Playback Control (Bluetooth Mode Only)

- **Play/Pause:** Press the ON/OFF button once.
- **Next Track:** Press the NEXT button once.
- **Previous Track:** Press the PREV button once.

## 5.4. Call Management (Bluetooth Mode Only)

- **Answer/End Call:** Press the ON/OFF button once.
- **Reject Call:** Press and hold the ON/OFF button for 2 seconds.

## 6. TROUBLESHOOTING (Q&A)



Image 6.1: Common Questions and Answers

This image provides a quick reference for frequently asked questions regarding the BAOBER H1 headphones and their connectivity.

### 1. What equipment can be used?

The headphones can be used without the transmitter with a cellphone or any Bluetooth device. With the transmitter, they can be used with 3.5mm / RCA / USB audio-out devices.

### 2. How to reduce latency when using the transmitter?

Reduce blocking between the transmitter and the headset. If latency persists, try to reconnect the transmitter and headset.

### 3. Why didn't the headset connect with the transmitter?

Reboot the headset and reinsert the transmitter into its power source/device. Ensure no other paired Bluetooth devices are nearby that might interfere.

### 4. Does the transmitter transmit stereo sound?

USB audio-out mode provides stereo sound. However, when connected via 3.5mm audio-in mode (e.g., to TV/MP3 player), the sound transmitted is not in stereo.

### 5. How long does it take to pair the headphone to the transmitter?

Pairing typically takes 3-10 seconds, depending on the number of 2.4G devices in the vicinity. To ensure proper pairing, turn off other paired Bluetooth devices as the transmitter may connect to another device.

## 7. SPECIFICATIONS

Model Name	BAOBER H1
Connectivity Technology	Wireless (Bluetooth 5.0), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth
Headphones Jack	3.5 mm Jack

<b>Ear Placement</b>	Over Ear
<b>Form Factor</b>	Over Ear
<b>Noise Control</b>	None
<b>Frequency Response</b>	20 Hz (Lower limit provided, typical range is 20Hz-20kHz)
<b>Impedance</b>	32 Ohms
<b>Battery Life</b>	10 Hours
<b>Charging Time</b>	2 Hours
<b>Item Weight</b>	136 Grams (4.8 ounces)
<b>Product Dimensions</b>	2.3 x 7.8 x 8.7 inches
<b>Material</b>	Plastic
<b>Special Features</b>	Microphone Included, USB connectivity, Volume Control, Wireless
<b>Compatible Devices</b>	iPhone, Android Phone, 3.5mm Audio-out Device, PC

## 8. CARE AND MAINTENANCE

- Keep the headphones dry. Do not expose them to rain or moisture.
- Clean the earcups and headband with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the headphones in a cool, dry place when not in use.
- Avoid extreme temperatures.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Charge the headphones regularly, even if not used frequently, to maintain battery health.

## 9. WARRANTY AND SUPPORT

BAOBER products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or contact BAOBER customer service through the retailer where you purchased the product.

Please retain your proof of purchase for warranty claims.