

wavytalk QL-5917BDC

Wavytalk Ionic Hair Dryer

USER MANUAL

Model: QL-5917BDC

1. Product Overview

The Wavytalk Ionic Hair Dryer is designed for efficient and gentle hair drying, featuring advanced ionic and ceramic technology to reduce frizz and enhance shine. Its powerful 1875W motor ensures fast drying times, while multiple attachments provide versatility for various hair types and styling needs.



Image: The Wavytalk Ionic Hair Dryer in Cyber Rose Pink, shown with its concentrator, diffuser, and comb

Key Features:

- **2x Faster Drying:** Equipped with a 1875W motor for high-speed airflow, reducing drying time and minimizing heat exposure.
- **Ionic Frizz Reduction:** Releases negative ions to neutralize static, tame frizz, and boost hair shine.
- **3 Versatile Attachments:** Includes a concentrator nozzle for precision, a diffuser for curls and waves, and a comb attachment for smoothing.
- **Customizable Settings:** Offers three temperature settings and two airflow speeds, plus a cool shot option.
- **Safety & Low Radiation:** Features automatic overheating shutdown and reduced electromagnetic radiation for safer use.

2. Safety Information

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Do not place or store the hair dryer where it can fall or be pulled into a tub or sink.
- Keep the appliance away from water. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not use the hair dryer with a damaged cord or plug. If the appliance is not working properly, has been dropped or damaged, return it to a service center for examination and repair.
- Keep the air intake and outlet clear of lint, hair, and other debris to prevent overheating.
- This appliance is for household use only. Do not use it outdoors or for commercial purposes.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Ensure your hands are dry when plugging in or unplugging the appliance.

3. Product Components and Setup

Your Wavytalk Ionic Hair Dryer comes with the main unit and three interchangeable attachments:

- **Main Hair Dryer Unit:** Features power switch, temperature and speed controls, and cool shot button.
- **Concentrator Nozzle:** For precise, targeted airflow, ideal for straightening and smooth styles.
- **Diffuser:** Designed to evenly distribute airflow, enhancing natural curls and waves while reducing frizz.
- **Comb Attachment:** Helps to smooth and straighten thick or unruly hair.



Comb Nozzle

Straightens smoothly while drying



Concentrator

Dries hair with precision



Diffuser

Defines natural curls and waves

Image: Close-up of the three attachments: comb nozzle, concentrator, and diffuser, with examples of their use.

Setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check the hair dryer and attachments for any signs of damage. Do not use if damaged.
3. **Attach Nozzle:** Select the desired attachment (concentrator, diffuser, or comb) and firmly attach it to the front of the hair dryer until it clicks into place. Ensure it is securely fastened before use.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

4. Operating Instructions

Using your Wavytalk Ionic Hair Dryer is straightforward. Follow these steps for optimal results:

1. **Power On:** Plug in the hair dryer. Use the power switch to turn the appliance on.
2. **Select Temperature:** Choose your desired heat setting using the temperature control switch. Options typically include Low, Medium, and High.
3. **Adjust Airflow Speed:** Select the airflow speed (Soft or Fast) using the speed control switch.
4. **Drying Hair:** Direct the airflow towards your hair, moving the dryer continuously to ensure even drying and prevent heat concentration on one area.

5. Using Attachments:

- *Concentrator Nozzle*: Ideal for precise styling and smoothing sections of hair.
 - *Diffuser*: Best for curly or wavy hair. Place sections of hair into the diffuser bowl and lift towards the scalp to enhance natural texture and volume.
 - *Comb Attachment*: Use to detangle and straighten hair while drying, especially effective for thick hair.
6. **Cool Shot Function**: Press and hold the cool shot button to deliver a burst of cool air. This helps to set your hairstyle and add shine.
7. **Power Off**: After use, switch the power off and unplug the hair dryer from the outlet. Allow it to cool down before storing.

5. Maintenance and Care

Regular maintenance ensures the longevity and optimal performance of your hair dryer.

- **Cleaning the Air Filter:**
The rear air filter should be cleaned regularly to prevent lint and dust buildup, which can affect performance and lead to overheating. Gently twist or pull off the filter cover (refer to your specific model's design), remove any accumulated debris with a soft brush or cloth, and then reattach the cover securely.
- **Cleaning the Exterior:**
Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the appliance is unplugged and completely dry before storage or next use.
- **Storage:**
Store the hair dryer in a cool, dry place, away from direct sunlight and moisture. Do not wrap the power cord tightly around the appliance, as this can damage the cord. Avoid hanging the dryer by its cord.

6. Troubleshooting

If you encounter any issues with your Wavytalk Ionic Hair Dryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in correctly; power outlet issue; internal fault.	Ensure the plug is fully inserted. Test the outlet with another appliance. If still not working, contact customer support.
Low airflow or weak drying.	Blocked air intake filter; motor issue.	Clean the air intake filter at the back of the dryer. Ensure nothing is obstructing the air outlet.
Hair dryer overheats and shuts off.	Blocked air filter; prolonged use; safety feature activated.	Unplug the dryer and allow it to cool down for at least 10-15 minutes. Clean the air filter. Avoid prolonged use without breaks.

Problem	Possible Cause	Solution
Attachments do not stay on.	Not properly aligned; worn attachment mechanism.	Ensure the attachment is aligned correctly and pushed firmly until it clicks. If the issue persists, the attachment or dryer may be worn.

If the problem persists after trying these solutions, please contact Wavytalk customer support.

7. Specifications

Feature	Detail
Brand	Wavytalk
Model Number	QL-5917BDC
Power	1875 Watts
Product Dimensions	10.3 x 7.8 x 3.3 inches
Weight	1.6 Pounds
Material	Metal
Color	Cyber Rose Pink
Power Source	Corded Electric

8. Warranty and Support

Wavytalk products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Wavytalk website.

For technical support, troubleshooting assistance, or any other inquiries, please contact Wavytalk Customer Service:

- **Website:** [Visit the Wavytalk Store on Amazon](#) (for general product information)
- **Email:** support@wavytalk.com (example, actual email not provided)
- **Phone:** 1-800-XXX-XXXX (example, actual phone not provided)

Please have your model number (QL-5917BDC) and purchase date ready when contacting support.