

ElectriBrite MS-672

ElectriBrite MS-672 5-in-1 Head Shaver

USER MANUAL

1. Introduction

Thank you for choosing the ElectriBrite MS-672 5-in-1 Head Shaver. This versatile grooming kit is designed to provide a comfortable and efficient shaving experience for your head and face. Featuring a 5D rotary shaver, hair clipper, nose/ear hair trimmer, facial cleansing brush, and face massage head, this device offers comprehensive personal care. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

2. Important Safety Information

Please observe the following safety precautions to prevent injury or damage to the device:

- This product is intended for external use only.
- Always ensure the device is unplugged when not in use or during cleaning.
- Before first use, fully charge the electric shaver.
- When shaving, use gentle circular motions.
- After shaving, clean the shaving head under running water.
- Dry the shaver thoroughly before storing.
- This product is waterproof (IPX7) but not submersible. Do not use in a bath or jacuzzi.
- Do not use damaged cables or chargers.
- Keep out of reach of children.

3. Package Contents

Carefully unpack the box and verify that all the following items are included:

- 1x Bald Head Shaver (main unit)

- 1x Hair Clipper attachment
- 1x Nose/Ear Hair Trimmer attachment
- 1x Facial Cleansing Brush attachment
- 1x Face Massage attachment
- 3x Hair Trimmer Guide Combs (3mm, 5mm, 7mm)
- 1x Type-C USB Charging Cable
- 1x Cleaning Brush
- 1x Protection Head Cover



Image: All components included in the ElectriBrite 5-in-1 Head Shaver package, laid out clearly.

4. Product Overview

The ElectriBrite MS-672 is a compact, ergonomic grooming device. The main unit features a powerful motor and an intelligent LED display for battery level and cleaning reminders. The primary rotary shaver head is designed with 6 flexible blades for a close and comfortable shave. Various interchangeable attachments allow for diverse grooming needs.



Image: The ElectriBrite head shaver main unit with its 6-blade rotary head, alongside a separate trimmer attachment, showcasing the sleek design and LED display.

The rotary shaver features a dual-ring, self-sharpening blade design for efficient and precise cutting, minimizing irritation.

Double Ring & Self-Sharpening Blade

Smooth, quick and precise cutting



Image: An exploded view illustrating the double ring and self-sharpening blade mechanism of the ElectricBrite shaver, highlighting its internal components for smooth cutting.

5. Initial Setup

5.1 Charging the Device

1. Before first use, ensure the shaver is fully charged.
2. Connect the Type-C USB charging cable to the charging port on the shaver.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., PC, power bank, car charger, or wall adapter).
4. The LED display will show the battery level percentage during charging. A full charge typically takes approximately 1.5 hours and provides up to 90 minutes of cordless running time.
5. Unplug the shaver once fully charged to prevent overcharging.

Type-C Rechargeable

Convenient for home and travel use



USB Charger



PC



Power Bank



Car Charger

1.5 Hours
of Running Time

90 Mins
of Charging Time



Image: The ElectriBrite shaver connected via a Type-C USB cable to a laptop for charging, demonstrating its convenient and versatile charging options.

5.2 Attaching and Detaching Heads

To change attachments, gently twist the current head counter-clockwise to unlock and remove it. Align the desired attachment with the main unit and twist clockwise until it clicks securely into place.

6. Operating Instructions

6.1 Using the Rotary Shaver (Head & Face)

The rotary shaver is suitable for both wet and dry shaving.

- **Dry Shaving:** Ensure your skin is clean and dry. Press the power button to turn on the shaver. Move the shaver in gentle circular motions over the desired area.
- **Wet Shaving:** Apply shaving foam or gel to your skin. Press the power button and move the shaver in gentle circular motions. The IPX7 waterproof design allows for use in the shower.

The 5D floating heads are designed to contour to the curves of your head and face for a close and smooth shave.



Image: A diagram illustrating how the ElectriBrite shaver's flexible heads conform to the contours of a head and face, ensuring a close and smooth shave.

Perfect for Shaving

Relish a comfortable shaving
and get a refreshing look



Image: A man comfortably shaving his head with the ElectriBrite shaver while showering, demonstrating its wet-use capability and ergonomic design.

6.2 Using the Hair Clipper

1. Attach the hair clipper head to the main unit.
2. Select and attach one of the guide combs (3mm, 5mm, or 7mm) if you desire a specific hair length.
3. Turn on the clipper and move it against the direction of hair growth for an even trim.

6.3 Using the Nose/Ear Hair Trimmer

1. Attach the nose/ear hair trimmer head.
2. Gently insert the trimmer tip into your nostril or ear canal.
3. Move the trimmer slowly to remove unwanted hair. Do not insert too deeply.

6.4 Using the Facial Cleansing Brush

1. Attach the facial cleansing brush head.
2. Dampen your face and apply your preferred facial cleanser to the brush head or your skin.
3. Turn on the device and gently move the brush in circular motions across your face for a deep cleanse.

6.5 Using the Face Massage Head

1. Attach the face massage head.
2. Turn on the device and gently glide the massage head over your face and neck to stimulate circulation and relax facial muscles.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your shaver. The IPX7 waterproof rating allows for easy cleaning under running water.

7.1 Daily Cleaning (Rotary Shaver Head)

1. After each use, turn off the shaver.
2. Remove the rotary shaver head by twisting it counter-clockwise.
3. Rinse the shaver head thoroughly under running tap water to remove hair clippings and debris.
4. For a more thorough clean, gently open each individual blade cover and rinse the inside.
5. Shake off excess water and allow the head to air dry completely before reattaching or storing.



Image: The ElectricBrite shaver being rinsed under running water, demonstrating its IPX7 waterproof feature for easy and thorough cleaning.

7.2 Cleaning Other Attachments

Rinse the hair clipper, nose/ear trimmer, facial cleansing brush, and face massage heads under running water after each use. Use the provided cleaning brush to remove any stubborn hair or residue. Ensure all attachments are completely dry before storage.

7.3 Storage

Store the shaver and its attachments in a cool, dry place. Use the protective head cover for the rotary shaver head when not in use to prevent damage to the blades.

8. Troubleshooting

If you encounter any issues with your ElectriBrite MS-672 shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the device is fully charged. Check if the travel lock is activated (indicated by a lock icon on the LED display); press and hold the power button for 3 seconds to deactivate it.
- **Poor shaving performance:** Clean the shaver head thoroughly. Ensure the blades are free of hair and debris. If performance does not improve, the blades may need replacement (replacement parts sold separately).
- **Charging issues:** Verify that the Type-C USB cable is securely connected to both the shaver and the power source. Try a different USB port or power adapter.
- **Excessive pulling or irritation:** Ensure the shaver head is clean. For wet shaving, use sufficient shaving foam or gel. Shave against the direction of hair growth with gentle pressure.

If the problem persists, please contact customer support.

9. Technical Specifications

Model Number	MS-672
Brand	ElectriBrite
Power Source	Cordless and Rechargeable
Battery Type	Lithium Ion (included)
Charging Time	Approx. 1.5 hours
Battery Life	Approx. 90 minutes
Waterproof Rating	IPX7
Blade Material	Carbon Steel
Item Weight	400 Grams
Package Dimensions	16.4 x 13.8 x 7.9 cm

10. Warranty and Support

ElectriBrite products are manufactured to high-quality standards. For warranty information, technical

support, or to inquire about replacement parts, please refer to the contact information provided with your purchase or visit the official ElectriBrite website. Please retain your proof of purchase for warranty claims.