

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Faroro](#) /
- › [Faroro 7L Automatic Pet Feeder Instruction Manual](#)

Faroro PF31

Faroro 7L Automatic Pet Feeder

Model: PF31

INTRODUCTION

The Faroro 7L Automatic Pet Feeder is designed to provide convenient and consistent feeding for your small to medium-sized pets, including cats and dogs. With its large capacity, programmable timer, and voice recording function, it ensures your pet receives meals on schedule, even when you are away. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new pet feeder.



Image: The Faroro 7L Automatic Pet Feeder, a white cylindrical unit with a black food chute, dispensing kibble into a black feeding bowl. This image shows the overall design and function of the feeder.

SAFETY INFORMATION

- Read all instructions carefully before using the feeder.

- Keep the feeder away from children and pets when not in use or during assembly.
- Use only dry pet food with a kibble size between 2-18 mm. Do not use wet food, canned food, or treats.
- Do not immerse the main base unit in water or any other liquid. Only the hopper and feeding bowl are washable.
- Ensure the power adapter cable is not chewed by pets. Use the battery backup feature for added safety during power outages.
- Place the feeder on a flat, stable surface to prevent tipping.
- Unplug the feeder from the power outlet before cleaning or when not in use for extended periods.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present and in good condition:

- Faroro 7L Automatic Pet Feeder Main Unit
- Food Hopper (7L capacity)
- Feeding Bowl
- Power Adapter
- USB Cable
- User Manual (this document)
- S-size propeller (5g per portion) and L-size propeller (10g per portion) - one pre-installed.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Faroro Automatic Pet Feeder.

4 Key Features



Programmable
Timer



7Lbs Large
Hopper



Dual Power
Supply



Voice
Recording



Image: An illustration highlighting the four key features of the Faroro Pet Feeder: Programmable Timer, 7L Large Hopper, Dual Power Supply, and Voice Recording. A small dog is visible in the background.

- **Food Hopper:** Transparent container for storing dry pet food.
- **Top Lid:** Secure, sealed lid to keep food fresh and prevent access by pets. Features a locking mechanism.
- **Control Panel:** Located under the top lid, with an intuitive button interface for programming.
- **Food Outlet:** Where kibble is dispensed from the hopper into the bowl.

- **Feeding Bowl:** Detachable bowl for your pet to eat from.
- **Base Unit:** Contains the motor, electronics, and battery compartment.
- **Infrared Sensor:** Prevents food from spilling or getting stuck.

TOP-LID

Keep food fresh and secure



Image: A close-up view of the top lid of the Faroro Pet Feeder, showing a hand pressing the release button to open the lid. This illustrates the secure top-lid design.

INFRARED DETECTION

Prevent food from spilling and being stuck in the hole



Image: A cat eating from the Faroro Pet Feeder, with a visual overlay indicating "Infrared Detection" to prevent food from spilling or getting stuck. This image demonstrates the feeder's intelligent dispensing system.

SETUP

1. Unpacking and Assembly

1. Carefully remove all components from the packaging.
2. Attach the feeding bowl to the main unit by sliding it into place until it clicks securely.
3. Ensure the food hopper is properly seated on the base unit.

2. Power Supply

The Faroro Pet Feeder supports dual power supply for reliable operation.

- **AC Power:** Connect the provided power adapter to the feeder's power port and plug it into a standard wall outlet. This is the primary power source.
- **Battery Backup:** For uninterrupted feeding during power outages, install three (3) D-size batteries (not included) into the battery compartment located at the bottom of the feeder. Ensure correct polarity.



Image: A transparent view of the Faroro Pet Feeder's base, illustrating the internal battery compartment and the connection point for the USB power cable. This highlights the dual power supply feature for continuous operation.

OPERATING INSTRUCTIONS

1. Filling the Food Hopper

1. Press the release button on the top lid and open it.
2. Pour dry pet food into the hopper. The 7L capacity can hold approximately 15 lbs of food, sufficient for 15-21 days for small to medium pets.
3. Close the top lid securely until you hear a click.



Grande Capacité

Sans souci pendant un demi-mois

Assez pour manger pendant 15 à 21 jours pour répondre à différents besoins

Image: The Faroro Pet Feeder with its top lid open, showing a large quantity of kibble inside the hopper. The number "7L" is prominently displayed, emphasizing the large capacity.

2. Setting Up the Feeding Schedule

The feeder allows for flexible meal planning with up to 5 meals per day and up to 39 portions per meal.

FEEDING SCHEDULE



1-5 meals
per day



Up to 39
portions



1/8 cup 1
portion (L)



Image: The Faroro Pet Feeder in a living room setting, with text overlays detailing its feeding schedule capabilities: "1-5 meals per day", "Up to 39 portions", and "1/8 cup 1 portion (L)".

1. **Access Control Panel:** Open the top lid to reveal the control panel.
2. **Set Current Time:** Use the "Time" button to set the current hour and minute.
3. **Program Meals:**

- Press the "Meal" button to select the meal number (1-5).
- Use the "Hour" and "Minute" buttons to set the desired feeding time for that meal.
- Use the "Portion Size" button to adjust the number of portions (1-39) for that meal. The feeder comes with S (5g) and L (10g) size propellers for different portion sizes.
- Repeat for all desired meals.

4. **Save Settings:** The settings are usually saved automatically after a few seconds of inactivity on the control panel.



Image: A close-up view of the Faroro Pet Feeder's control panel, showing the digital display and various buttons for setting time, meal size, and other functions. A hand is shown interacting with the buttons, illustrating ease of use.

3. Voice Recording Function

You can record a 10-second voice message to call your pet at meal times.

1. Press and hold the "MIC" button until you hear a "beep".
2. Record your message (up to 10 seconds).
3. Release the "MIC" button to save the recording.
4. You can choose to play the recording at each scheduled meal.

4. Manual Feeding

To dispense food manually, press the "Manual Feed" button on the control panel. Each press will dispense one portion.

AUTOMATIC FEEDING

Feed your pet anywhere at any time automatically



Image: The Faroro Pet Feeder in action, with a cat eating from it. Three small inset images show people sleeping, working on a laptop, and socializing, illustrating the convenience of automatic feeding when owners are occupied.

MAINTENANCE

1. Cleaning

- **Hopper and Bowl:** The food hopper and feeding bowl are detachable and can be washed with water and mild detergent.

Rinse thoroughly and dry completely before reassembling.

- **Base Unit:** The main base unit, which contains electronic components, should only be wiped clean with a dry cloth. Do not immerse it in water.
- Regularly clean the food outlet to prevent blockages.

2. Food Freshness

The sealed top lid helps keep food fresh. For optimal freshness, store the feeder in a cool, dry place and avoid direct sunlight.



Image: The Faroro Pet Feeder positioned next to a dog, with illustrations of various dry food types (dry food, puffed food, freeze-dried food, air-dried food, snacks) that are compatible with the feeder. This highlights its moisture-resistant design and versatility for different kibble types.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food.	<ul style="list-style-type: none">◦ Food hopper empty.◦ Food outlet blocked.◦ Incorrect programming.◦ Power issue.	<ul style="list-style-type: none">◦ Refill food hopper.◦ Clear any blockages in the food outlet.◦ Verify meal times and portion settings on the control panel.◦ Check power adapter connection; ensure batteries are installed and charged if using backup.
Food spilling or overflowing.	<ul style="list-style-type: none">◦ Too many portions set.◦ Kibble size too large for portion setting.	<ul style="list-style-type: none">◦ Reduce the number of portions per meal.◦ Ensure kibble size is within the recommended 2-18 mm range.

Problem	Possible Cause	Solution
Voice recording not playing.	<ul style="list-style-type: none"> Recording not saved correctly. Voice playback feature disabled. 	<ul style="list-style-type: none"> Re-record the message, ensuring you hold the MIC button until the beep and release it to save. Check the control panel settings to ensure voice playback is enabled for scheduled meals.
Feeder not turning on.	<ul style="list-style-type: none"> No power. Batteries drained or incorrectly installed. 	<ul style="list-style-type: none"> Ensure the power adapter is securely plugged into both the feeder and a working outlet. Replace D-size batteries or check their polarity.

SPECIFICATIONS

Brand	Faroro
Model Number	PF31
Capacity	7 Liters (approx. 15 lbs dry food)
Dimensions (L x W x H)	24.5 x 21 x 38.4 cm
Weight	2.03 Kilograms
Material	Polyethylene Terephthalate (PET)
Recommended Kibble Size	2-18 mm
Meals per Day	1-5 meals
Portions per Meal	Up to 39 portions (5g or 10g per portion, depending on propeller)
Power Supply	AC Adapter (included), 3 x D-size batteries (not included) for backup
Special Features	Timer, Voice Recording, Portion Control, Infrared Detection
Care Instructions	Hopper and bowl washable; base unit wipe clean only.

WARRANTY AND SUPPORT

Faroro products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or the official Faroro website. Please retain your proof of purchase for warranty claims.