Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vicloon V5-QXDZHSB-FBA

Vicloon V5 Silicone Digital Nurse Fob Watch User Manual

Model: V5-QXDZHSB-FBA

Introduction

Thank you for choosing the Vicloon V5 Silicone Digital Nurse Fob Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Designed for medical professionals, this clip-on digital watch offers convenience and functionality in various professional settings.
The watch features a large digital display for easy time reading, a stopwatch, alarm, 12/24 hour format, and an EL backlight. Its durable silicone casing and detachable alloy dial are designed for hygiene and ease of use.

Package Contents

- Digital Nurse Watch (1x)
- User Manual (1x)

Setup and Initial Configuration

Before first use, please familiarize yourself with the watch buttons and display features.



Image: Overview of the watch display and button functions (Light, Mode, Start, Reset).

Setting the Time and Date:

1. Press the **MODE** button repeatedly until the time display starts flashing.
2. Use the **START** button to adjust the flashing digit (hours, minutes, etc.).
3. Press the **RESET** button to move to the next digit or setting.
4. Once all settings are correct, press the **MODE** button again to exit the setting mode.
5. **Quick Tip for Time Setting:** Some users have found success by pressing the top right button (likely **START**) once, then pressing the bottom right button (likely **RESET**) four times consecutively to enter time setting mode.

Attaching the Watch:

The watch features a safety pin and fixed clip design for secure attachment.



Image: Detailed view of the watch's pin and clip mechanism for attachment.

- Use the safety pin to securely fasten the watch to uniforms, nurse jackets, or medical gowns.
- Ensure the watch is firmly attached to prevent accidental detachment during work.

Operating Instructions

Basic Time Display:

The watch displays time in a clear digital format. It supports both 12-hour and 24-hour formats, which can be selected during the time setting process.

Using the Backlight:

To illuminate the display in low-light conditions:

- Press the **LIGHT** button (top left).

- The backlight will activate for approximately 3 seconds to conserve battery life.




Image: Demonstrates the watch display with and without the backlight activated.

Stopwatch Function:

The watch includes a stopwatch for timing tasks.

1. Press the **MODE** button until the stopwatch display appears (usually indicated by 00:00:00).
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause the stopwatch.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press the **MODE** button to return to the time display.

Alarm Function:

Set an alarm to remind you of important events.

1. Press the **MODE** button until the alarm setting display appears.
2. Use the **START** and **RESET** buttons to set the desired alarm time.

3. Press the **MODE** button to confirm and activate the alarm.
4. To turn the alarm on/off, typically press the **START** button while in alarm display mode.

Date and Week Display:

The watch automatically displays the current date and day of the week.

Care and Maintenance

- **Cleaning:** The silicone casing and alloy dial can be separated for easy sterilization. Wipe with a damp cloth and mild disinfectant.
- **Water Resistance:** This watch is **NOT waterproof**. Do not immerse the watch in water or expose it to heavy splashing. Remove the watch before washing hands thoroughly or showering.
- **Battery Replacement:** When the display dims or functions become erratic, the battery may need replacement. This typically requires a small screwdriver and a new watch battery (type not specified, usually a common button cell). It is recommended to have this done by a professional if you are unsure.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Watch display is blank or dim.	Low battery.	Replace the battery.
Cannot set the time/date.	Incorrect button sequence or mode.	Refer to the "Setting the Time and Date" section under Setup. Ensure you are in the correct setting mode. Try the quick tip: press START once, then RESET four times consecutively.
Alarm sounds unexpectedly or cannot be turned off.	Alarm is set incorrectly or accidentally activated.	Navigate to the alarm setting mode and ensure the alarm is deactivated or set to the desired time. Consult the "Alarm Function" section.
Watch detaches from clothing.	Improper attachment or worn clip/pin.	Ensure the safety pin and clip are securely fastened to a sturdy part of your uniform. Inspect the clip and pin for damage.

Product Specifications

Brand	Vicloon
Model Number	V5-QXDZHSB-FBA
Display Type	Digital
Movement Type	Quartz
Material	Silicone (casing), Alloy (dial), Acrylic (dial window)
Product Dimensions (L x W x H)	Overall: 11 x 5 x 2 cm; Watch Case: 9 x 4.3 x 1.2 cm; Clip: 3.2 cm; Pin: 3.2 cm

Case Diameter	32 Millimeters
Case Thickness	12 Millimeters
Water Resistance Level	Not waterproof
Special Features	Chronograph, Alarm, EL Backlight, 12/24 Hour Format, Date, Week Display
Power Source	Battery Powered
Country of Origin	China




Image: Dimensional drawing of the Vicloon Nurse Fob Watch, indicating length, width, and thickness.

Warranty Information

Specific warranty details for the Vicloon V5 Silicone Digital Nurse Fob Watch are not provided in this manual. Please refer to the product packaging or the retailer's website for information regarding warranty coverage and terms. Keep your proof of purchase for any warranty claims.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Vicloon customer support or the retailer from whom you purchased the product. Contact information can typically be found on the product packaging or the official Vicloon website.
For online resources, you may visit the product page on Amazon for additional details or frequently asked questions.

© 2023 Vicloon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CQ9FFQD

More documents and user manuals: **https://manuals.plus/**