

[Manuals.plus](#) /

› [CubiCubi](#) /

› CubiCubi Simple Gaming Desk Z Shaped 40 inch Gamer Workstation Instruction Manual

CubiCubi GDSZ-40B

CubiCubi Simple Gaming Desk Z Shaped 40 inch Gamer Workstation Instruction Manual

Model: GDSZ-40B

1. INTRODUCTION

Thank you for choosing the CubiCubi Simple Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new gaming desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The CubiCubi Simple Gaming Desk, featuring a carbon fiber surface and Z-shaped legs, designed for gaming setups.

2. SAFETY INFORMATION

Always assemble the desk according to the provided instructions. Do not exceed the maximum weight recommendation of 90 kilograms (200 pounds) to ensure stability and safety. Keep small parts away from children during assembly. Ensure all screws and fasteners are securely tightened before use.

3. PACKAGE CONTENTS

Before assembly, please verify that all the following components are present and undamaged:

- Desktop Panel (Carbon Fiber Surface)
- Z-Shaped Leg Frames (Left and Right)
- Crossbar Support
- Headphone Hook
- Adjustable Foot Pads
- Assembly Hardware (Screws, Allen Wrench)
- Instruction Manual

If any parts are missing or damaged, please contact CubiCubi customer support for assistance.

4. ASSEMBLY INSTRUCTIONS

Assembly of the CubiCubi Simple Gaming Desk is designed to be straightforward. It is recommended that one person performs the assembly. Please follow the steps below carefully.

4.1. Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Leg Frames:** Attach the crossbar support between the two Z-shaped leg frames using the provided screws. Ensure all connections are snug but do not overtighten initially.
3. **Attach Foot Pads:** Screw the adjustable foot pads into the bottom of each leg frame. These can be adjusted later to level the desk.
4. **Secure Desktop:** Carefully place the desktop panel onto the assembled leg frame. Align the pre-drilled holes on the desktop with the holes on the leg frame. Secure the desktop using the remaining screws.
5. **Install Headphone Hook:** Attach the headphone hook to the designated location on the side of the desk using the provided screw.
6. **Final Tightening:** Once all components are in place, systematically tighten all screws to ensure the desk is stable. Do not overtighten to avoid damaging the material.
7. **Level the Desk:** Adjust the foot pads as needed to ensure the desk is stable and level on your floor.



Image 4.1: The Z-shaped leg design provides enhanced stability for the desk.



Image 4.2: Adjustable foot pads for leveling and a convenient headphone hook are included.

4.2. Assembly Video Guide

For visual assistance with the assembly process, please refer to the official installation video below:

Your browser does not support the video tag.

Video 4.3: Official CubiCubi Simple Gaming Desk installation video. This video demonstrates the step-by-step assembly process.

5. OPERATING INSTRUCTIONS

The CubiCubi Simple Gaming Desk is designed for optimal gaming and workstation use. Its ergonomic wraparound shape provides a comfortable experience.

- **Placement:** Position the desk on a flat, stable surface to ensure maximum stability.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 90 kg (200 lbs) to prevent damage or instability.
- **Headphone Hook:** Utilize the integrated headphone hook to keep your headphones or other accessories organized and within reach.
- **Cable Management:** The desk design assists in managing cables, helping to maintain a tidy workspace.




Image 5.1: The ergonomic wraparound shape of the desktop is designed for user comfort.




Image 5.2: The desk's design facilitates better cable organization compared to standard setups.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your CubiCubi gaming desk.

- **Cleaning:** Wipe the carbon fiber surface and metal frame with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.

- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability.
- **Avoid Excessive Moisture:** Do not expose the desk to excessive moisture or direct sunlight for prolonged periods.

7. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common solutions:

- **Desk is Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the foot pads on the bottom of the legs to level the desk on uneven floors.
- **Missing or Damaged Parts:**
 - Refer to the "Package Contents" section to confirm all parts were received.
 - Contact CubiCubi customer support for replacement parts.

8. SPECIFICATIONS

Feature	Specification
Brand	CubiCubi
Model Number	GDSZ-40B
Product Dimensions (D x W x H)	23.6"D x 40"W x 28.1"H (60cm D x 100cm W x 75cm H)
Item Weight	21.6 Pounds (9.8 kg)
Maximum Weight Recommendation	90 Kilograms (200 Pounds)
Top Material Type	Engineered Wood (Carbon Fiber Surface)
Base Material	Alloy Steel
Color	Black
Special Feature	Ergonomic, Headphone Hook
Assembly Required	Yes



Image 8.1: Key dimensions of the CubiCubi Simple Gaming Desk.

9. WARRANTY AND SUPPORT

CubiCubi is committed to providing quality products and services. If you receive any parts that are damaged or defective, please contact our customer service team immediately. We are happy to send replacement parts to you.

For further assistance or inquiries, please visit the official CubiCubi store or contact our support team through the retailer where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09CV3X5MB>

More documents and user manuals: <https://manuals.plus/>