

E T EASYTAO B09CYLQF94

E T EASYTAO Wireless Keyboard User Manual

Model: B09CYLQF94

Brand: E T EASYTAO

1. INTRODUCTION

This manual provides detailed instructions for the E T EASYTAO Wireless Keyboard. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan. This keyboard is designed for multi-device connectivity, offering a compact, ergonomic, and silent typing experience.

2. KEY FEATURES

- **Ergonomic Design and Exquisite Appearance:** Constructed from high-quality plastic with feet for optimal typing angle, preventing wrist strain during extended use. Features a modern black color scheme and frosted, splash-proof keys for durability and a clean feel.
- **Multi-Device Connection:** Connects to up to 3 devices seamlessly via built-in Bluetooth technology. Automatically recognizes device systems and reconnects to previously paired devices. Compatible with iPad, iPhone, Mac, laptops, PCs, smartphones, Windows, and iOS.
- **Rechargeable Battery:** Equipped with a long-lasting rechargeable battery, providing 3 to 6 months of standby time on a single charge. Features environmental protection and energy-saving functions, including an automatic sleep mode after 5 minutes of inactivity.
- **Responsive and Spanish Layout Keys:** Features a sleek design for fast and efficient input, ensuring no missed keystrokes. Includes a Spanish keyboard layout for user convenience.
- **Practical and Ultra-Thin Design:** Designed for comfortable typing. Includes industry-standard function buttons such as mute, play/pause, rewind, fast forward, volume up/down to enhance work efficiency. Its slim profile allows for easy portability in a backpack or laptop bag.

3. PRODUCT OVERVIEW



Figure 1: E T EASYTAO Wireless Keyboard (Black)

DISEÑO ULTRA SLIM



Figure 2: Ultra-slim design of the keyboard, showing dimensions of 28.5 cm length, 11.9 cm width, and thickness ranging from 0.7 cm to 1.3 cm.



Estructura de Pies de Tijera

Gracias a su diseño de interruptor de tijera y perfil bajo, estas teclas garantizan una escritura silenciosa y cómoda



Interruptor de tijera

Figure 3: Close-up of the keyboard showcasing the scissor-foot key structure, which ensures silent and comfortable typing.

Experiencia de Entrada Silenciosa

Diseño de botón de reducción de ruido íntimo, no afecta al resto de compañeros de habitación y familiares



El botón está en silencio



Figure 4: The keyboard's silent operation, featuring noise-reduction button design for a quiet typing experience that does not disturb others.

4. SPECIFICATIONS

| Feature | Detail |
|--------------------|---|
| Brand | E T EASYTAO |
| Model Series | E T EASYTAO Teclado Inalambrico Español |
| Color | Black |
| Product Dimensions | 28.5 x 11.9 x 1.3 cm |
| Weight | 410 g |
| Power Source | Battery |
| Compatible Devices | Personal Computer, Laptop, Tablet |

| Feature | Detail |
|-------------------------|--|
| Connectivity Technology | Bluetooth |
| Keyboard Description | Mechanical (refers to key mechanism, not full mechanical keyboard) |
| Special Feature | Bluetooth, Wireless |
| Number of Keys | 78 |
| Style | Contemporary |
| Recommended Uses | Office work, writing, home use, studies, mobile device browsing, presentations |

5. SETUP INSTRUCTIONS

5.1 Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the provided charging cable to the keyboard's charging port and to a USB power source. The battery indicator light will show charging status.

Ahorro de Energía y Ambientalmente Amigable

Carga rápida, batería de larga duración

Tiempo de carga: <3 horas
Tiempo en espera: 4 meses
Tiempo de vida: 30 días

- Indicador de mayúsculas
- Indicador de trabajo
- Indicador de batería

Figure 5: Keyboard charging port and indicator lights for Caps Lock, Work, and Battery status. A full charge takes less than 3 hours, providing up to 4 months of standby time or 30 days of active use.

- **Charging Time:** Less than 3 hours.
- **Standby Time:** 3 to 6 months.
- **Working Time:** Approximately 30 days.

5.2 Connecting to Devices (Bluetooth)

The keyboard supports connection to up to three devices via Bluetooth. Follow these steps to pair your keyboard:

1. Turn on the keyboard using the power switch.
2. Press and hold the **Fn** key and one of the channel keys (**1**, **2**, or **3**) for 3-5 seconds until the corresponding channel indicator light flashes, indicating pairing mode.
3. On your device (e.g., smartphone, tablet, computer), go to Bluetooth settings and search for available devices.
4. Select "EASYTAO Keyboard" or a similar name from the list of found devices.
5. If prompted, enter the pairing code displayed on your screen using the keyboard and press **Enter**.
6. Once connected, the indicator light will stop flashing and remain solid for a few seconds before turning off.

MULTI DISPOSITIVO TECLADO BLUETOOTH

Fácil de configurar y cambiar entre 3 dispositivos a la vez




Figure 6: Diagram illustrating multi-device Bluetooth connectivity, showing the keyboard connected to a smartphone (Channel 1), a tablet (Channel 2), and a laptop (Channel 3).

5.3 Connecting to Devices (2.4GHz Wireless)

For devices without Bluetooth, or for a dedicated 2.4GHz connection, use the included USB receiver.

1. Locate the USB receiver, typically stored in a compartment on the back of the keyboard.
2. Plug the USB receiver into an available USB port on your computer or device.
3. The keyboard should automatically connect to the receiver. No additional pairing is usually required.



Figure 7: The compact USB receiver for 2.4GHz wireless connectivity, often stored discreetly within the keyboard itself.

6. OPERATING INSTRUCTIONS

6.1 Switching Between Devices

To switch between paired Bluetooth devices, simply press the **Fn** key along with the corresponding channel key (**1**, **2**, or **3**) that your device is paired to. The keyboard will automatically switch its connection.

6.2 Function Keys

The keyboard features a row of function keys (F1-F12) that perform various multimedia and system functions when pressed in combination with the **Fn** key. Some common functions include:

- **Fn + F1:** Media Player
- **Fn + F2:** Volume Down
- **Fn + F3:** Volume Up
- **Fn + F4:** Mute
- **Fn + F5:** Previous Track
- **Fn + F6:** Next Track
- **Fn + F7:** Play/Pause
- **Fn + F8:** Stop
- **Fn + F9:** Home
- **Fn + F10:** Mail
- **Fn + F11:** My Computer
- **Fn + F12:** Search



Figure 8: Overview of the keyboard's function keys (F1-F12) and their associated multimedia and system controls, accessible via the Fn key.

6.3 Operating System Compatibility

The keyboard automatically recognizes the operating system of the connected device (iOS, Android, Windows) and adjusts its layout and functions accordingly. Specific keys like "Mayús" (Shift), "control", "alt", "command", and "option" are labeled to reflect their functions across different operating systems.



Figure 9: The E T EASYTAO keyboard in a typical office setup, demonstrating its compatibility and use with a desktop computer, laptop, and tablet.

7. MAINTENANCE

7.1 Cleaning

- To clean the keyboard, power it off first.
- Use a soft, dry, lint-free cloth to wipe the surface.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- Do not use abrasive cleaners, alcohol, or solvents, as these may damage the keyboard's finish or keys.

7.2 Battery Care

- Recharge the keyboard when the battery indicator light shows low power.
- Avoid completely draining the battery frequently, as this can reduce its lifespan.
- If storing the keyboard for an extended period, charge it to about 50% before storage and recharge every few months to prevent deep discharge.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|---|--|
| Keyboard not connecting via Bluetooth. | Keyboard is off, battery is low, not in pairing mode, or device's Bluetooth is off. | Ensure keyboard is on and charged. Put keyboard in pairing mode (Fn + Channel key). Turn on Bluetooth on your device. Forget previous pairings on your device and try again. |
| Keys are unresponsive or delayed. | Low battery, too far from device, interference, or keyboard in sleep mode. | Charge the keyboard. Move closer to the device. Reduce interference from other wireless devices. Press any key to wake the keyboard from sleep mode. |
| Cannot switch between devices. | Devices not properly paired to respective channels. | Ensure each device is paired to a unique channel (1, 2, or 3). Press Fn + corresponding channel key to switch. |
| Keyboard types incorrect characters. | Incorrect operating system detected or language settings. | Check your device's language and keyboard layout settings. The keyboard automatically adapts, but manual adjustment on the device might be needed. |

9. WARRANTY AND SUPPORT

E T EASYTAO products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official E T EASYTAO website. If you encounter any issues not covered in this manual, or require further assistance, please contact E T EASYTAO customer support through their official channels.

Please retain your proof of purchase for warranty claims.