Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-MX-CT03-RBN-BC06

VECELO Coffee Table with 2-Tier Storage Shelf X-Frame

Model: KHD-MX-CT03-RBN-BC06

Instruction Manual

Introduction

Thank you for choosing the VECELO Coffee Table. This manual provides detailed instructions for the safe and correct assembly, operation, and maintenance of your new coffee table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information:

- Ensure all parts are present and undamaged before assembly.
- Follow assembly steps precisely to ensure structural integrity.
- Do not exceed the maximum weight recommendation of 200 lbs (90.7 kg) on the tabletop or lower shelf.
- Keep small parts away from children during assembly.

Included Components

Please verify that all the following components are included in your package:

1. 1 x Tabletop (Part 1)
2. 2 x Wooden Support Bars (Part 2)
3. 2 x X-Frame Side Panels (Part 3)
4. 1 x Mesh Storage Shelf (Part 4)
5. 4 x Cam Lock Screws (Part A)
6. 8 x Wood Screws (Part B)
7. 4 x Flat Head Screws (Part C)
8. 4 x Adjustable Feet (Part D)
9. 1 x Allen Wrench (Part E)

Refer to the provided accessory bag and instruction sheet for visual identification of each part.

Setup Instructions

Follow these steps for proper assembly of your VECELO Coffee Table:

Step 1: Prepare the Tabletop and Wooden Support Bars

Place the tabletop (Part 1) upside down on a soft, clean surface to prevent scratches. Insert the four cam lock screws (Part A) into the pre-drilled holes on the underside of the tabletop. Then, align the two wooden support bars (Part 2) with the cam lock screws, ensuring the holes on the bars face inwards. Secure the wooden support bars by turning the cam locks with a screwdriver until they are tight.



Image: The tabletop with its overall dimensions, illustrating the size of the coffee table.

Step 2: Attach X-Frame Side Panels

Position the two X-frame side panels (Part 3) to the ends of the tabletop assembly. Align the holes on the side panels with the pre-drilled holes on the wooden support bars and the tabletop. Use the eight wood screws (Part B) to attach the side panels. Use the provided Allen wrench (Part E) to tighten these screws securely.



Image: A fully assembled VECELO coffee table, showcasing its design and two-tier structure.

Step 3: Install the Mesh Storage Shelf

Carefully place the mesh storage shelf (Part 4) between the X-frame side panels, aligning the holes on the shelf with the corresponding holes on the lower section of the side panels. Secure the mesh shelf using the four flat head screws (Part C). Use the Allen wrench (Part E) to tighten these screws.

Step 4: Attach Adjustable Feet

Screw the four adjustable feet (Part D) into the bottom of each leg of the X-frame side panels. These feet help to level the table on uneven surfaces and protect your floor.



Image: Detail of the adjustable table leg, designed for stability and floor protection.

Assembly Video Guide

For a visual guide on the assembly process, please watch the official VECELO assembly video:

Your browser does not support the video tag.

Video: Official VECELO assembly guide for the coffee table, demonstrating each step.

Operating Instructions

Your VECELO Coffee Table is designed for versatile use in your living space:

- **Tabletop Use:** The spacious tabletop provides ample surface area for drinks, remote controls, laptops, or decorative items.
- **Storage Shelf:** The open lower mesh shelf is ideal for organizing books, magazines, small baskets, or other daily necessities, keeping your living area tidy.
- **Weight Capacity:** Ensure that the total weight placed on the table, including the tabletop and the lower shelf, does not exceed 200 lbs (90.7 kg). Distribute weight evenly to maintain stability.



Image: The coffee table in a living room, demonstrating its use for holding various items on both tiers.

Your browser does not support the video tag.

Video: A brief overview of the VECELO Coffee Table's features and functionality in a home environment.

Maintenance

To ensure the longevity and appearance of your coffee table, follow these maintenance guidelines:

- **Cleaning:** Wipe the tabletop and metal frame with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** The tabletop is designed to be waterproof. Promptly wipe up any spills to prevent potential damage or staining.
- **Screw Tightness:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Adjustable Feet:** Ensure the adjustable feet are properly set to keep the table level and prevent wobbling.




Image: The tabletop surface, emphasizing its resistance to water and ease of cleaning.

Troubleshooting

If you encounter any issues with your VECELO Coffee Table, please refer to the following common solutions:

- **Table is Wobbly:** Check that all assembly screws are securely tightened. Adjust the leveling feet (Part D) on the bottom of each leg to stabilize the table on uneven floors.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact VECELO customer

service for assistance. Do not attempt to assemble with incomplete or damaged components.

Specifications

Brand	VECELO
Model Name	VECELO Coffee Table with 2-Tier Storage Shelf X-Frame
Model Number	KHD-MX-CT03-RBN-BC06
Product Dimensions (L x W x H)	39.4" x 19.7" x 17.7" (100 cm x 50 cm x 45 cm)
Item Weight	24.6 Pounds (11.16 kg)
Maximum Weight Recommendation	200 Pounds (90.7 kg)
Material	Engineered Wood (tabletop), Metal (frame)
Color	Brown (tabletop), Black (frame)
Style	Industrial, Farmhouse
Features	2-Tier Storage, X-Frame Design, Adjustable Feet, Waterproof & Scratch-Resistant Tabletop

Warranty and Support

VECELO is committed to providing quality products and customer satisfaction. For any questions, concerns, or assistance with your coffee table, please contact VECELO customer service. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the VECELO website for warranty information.
For support, please visit the official VECELO store: VECELO Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CYMY5SR

More documents and user manuals: **https://manuals.plus/**