

[Manuals.plus](#) /

› [AMZCHEF](#) /

› AMZCHEF 3300W Dual Zone Induction Cooktop User Manual

AMZCHEF CE-FS-IRC119B33-GA

AMZCHEF 3300W Dual Zone Induction Cooktop User Manual

Model: CE-FS-IRC119B33-GA

1. INTRODUCTION

Thank you for choosing the AMZCHEF 3300W Dual Zone Induction Cooktop. This manual provides important information for the safe and efficient use of your appliance. Please read it thoroughly before installation and operation, and keep it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, injury to persons, or damage when using the appliance, follow basic safety precautions.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is equipped with a safety lock function to prevent accidental operation, especially by children.
- The cooktop features overheat protection and automatic shut-off if temperatures become too high.

Multiplies protections de sécurité



Figure 2.1: Overview of the cooktop's multiple safety features, including a child lock, 99-minute timer, and overheat protection system.

3. PRODUCT OVERVIEW

The AMZCHEF Dual Zone Induction Cooktop offers versatile cooking options with its flexible zones and precise temperature control.

3.1 Key Features

- **2-in-1 Multifunction:** Features a Flexzone that combines two separate cooking areas into one larger rectangular zone (40 x 20 cm) with a total power of 3300 watts. It also includes a BBQ mode for maintaining pan surface temperature.
- **Precise Temperature Control:** Equipped with IGBT electronic temperature regulation software for stable temperature curves and minimal temperature difference. Both zones have 10 refined power levels, with the highest 'B' gear for continuous high-power heating.
- **Premium Material:** Made from high-quality polished ceramic glass, offering a flat, translucent surface that is heat-resistant, wear-resistant, and easy to clean.
- **Safety Functions:** Includes a 1-99 minute timer, safety lock, overheat protection, automatic shut-off, dry-burn protection, and overflow protection.

3.2 Compatible Cookware

This induction cooktop is only suitable for cookware with a magnetic bottom. To check compatibility, place a magnet on the bottom of your pot or pan. If the magnet sticks, the cookware is compatible.

- **Compatible:** Iron pots, cast iron pans, enameled iron, stainless steel with magnetic base.
- **Incompatible:** Heat-resistant glass, copper, aluminum, ceramic pots.

Compatible avec les ustensiles de cuisine magnétiques



Figure 3.1: Guide to compatible magnetic cookware (enameled iron, cast iron, iron, stainless steel) and incompatible materials (glass, copper, aluminum, ceramic).

4. SETUP AND INSTALLATION


The AMZCHEF Induction Cooktop offers two installation options: built-in or countertop use.

4.1 Installation Options

- **Built-in:** For a seamless and space-saving aesthetic, the cooktop can be recessed into a countertop. Refer to the dimensions in the specifications section for cutout requirements.
- **Countertop:** The cooktop can also be used as a portable unit, placed directly on a stable, flat surface.

2 types d'installation

Il peut être utilisé directement sur le comptoir ou encastré



● Encastré

Esthétique et gain de place



● Comptoir

Mobile et facile à utiliser

Figure 4.1: Illustration of the two installation methods: built-in for a sleek look and countertop for flexible placement.

4.2 Electrical Connection

Ensure the cooktop is connected to a 220-240V ~ 50/60Hz power supply. The appliance comes with a VDE plug. Always ensure the electrical outlet is properly grounded and capable of handling the 3300W power requirement.

IMPORTANT: Professional installation is recommended for built-in applications to ensure proper ventilation and electrical safety.

5. OPERATING INSTRUCTIONS

This section details how to use your AMZCHEF Induction Cooktop effectively.

5.1 Powering On/Off

- To turn on, press the Power button. The display will light up.

- To turn off, press the Power button again.

5.2 Selecting Cooking Zones and Power Levels

- Place compatible cookware on the desired cooking zone.
- Select the zone using the corresponding touch control.
- Adjust the power level from P1 to P9, or 'B' (Boost) using the '+' and '-' buttons. The cooktop offers 10 power levels for precise control.

10 niveaux de puissance




Figure 5.1: The 10 power levels and their recommended uses, from P1 (melting) to B (boiling water).

5.3 Precise Temperature Control and BBQ Mode

The cooktop utilizes IGBT electronic temperature regulation for stable and precise heating. The BBQ mode, available in the Flexzone, helps maintain a consistent surface temperature for grilling.

Contrôle précis de la température

Le chauffage continu avec un profil de température plus stable rend les aliments plus savoureux



Pour augmenter la sécurité de la cuisson, le réglage de la puissance passe automatiquement à P9 après 10 minutes en mode zone B ou zone flexible.

Figure 5.2: Illustration of precise temperature control and the cooktop's BBQ mode for grilling.

5.4 Flexzone Function

The Flexzone feature allows you to combine two cooking zones into one large area, ideal for larger pots, griddle pans, or BBQ mode.

- To activate Flexzone, press the dedicated Flexzone button (often indicated by an arrow icon).
- In Flexzone mode, you can place a large pan across both zones.
- The BBQ mode can be activated within the Flexzone to maintain a consistent surface temperature for grilling.

Flex-Zone et 2 Zones Séparées



Figure 5.3: Illustration of the Flex-Zone function, combining two zones for a larger cooking surface (3300W), versus using two separate zones (1800W and 1500W).

5.5 Timer Function

The integrated timer allows you to set a cooking duration from 1 to 99 minutes.

- Press the Timer button.
- Use the '+' and '-' buttons to adjust the desired cooking time.
- The cooktop will automatically turn off once the timer expires.

5.6 Safety Lock

Activate the safety lock to prevent accidental changes to settings or unintended operation, especially useful with children around.

- To activate, press and hold the Lock button for a few seconds. An indicator light will appear.
- To deactivate, press and hold the Lock button again until the indicator light turns off.

6. MAINTENANCE AND CLEANING

Proper care ensures the longevity and optimal performance of your induction cooktop.

6.1 Cleaning the Cooktop Surface

- Always ensure the cooktop is turned off and completely cool before cleaning.
- Use a soft cloth or sponge with a mild detergent and warm water.
- For stubborn stains, use a ceramic hob scraper or a specialized induction cooktop cleaner.
- Wipe dry with a clean cloth to prevent water spots.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals that can damage the ceramic glass surface.

Panneau en cristal noir de première qualité

Les panneaux en matériau microcristallin de haute qualité facilitent l'élimination des taches



Figure 6.1: Cleaning the cooktop surface, emphasizing its easy maintenance, high temperature resistance, and scratch-resistant properties.

6.2 General Care

- Do not drop heavy objects on the cooktop surface.
- Avoid dragging cookware across the surface to prevent scratches.
- Ensure proper ventilation around the cooktop, especially for built-in installations.

7. TROUBLESHOOTING

If you encounter any issues with your AMZCHEF Induction Cooktop, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power button not pressed; Safety lock activated.	Check power connection; Press Power button firmly; Deactivate safety lock.
Cookware not heating.	Incompatible cookware; Cookware not centered; Small cookware.	Use magnetic cookware; Center cookware on zone; Ensure cookware base covers minimum zone area.
Display shows an error code (e.g., "E0", "E1").	Overheat; Internal fault; Voltage issue.	Turn off and let cool; Consult the full manual or contact customer support.
Unusual noise during operation.	Normal fan operation; Cookware vibration.	A slight fan noise is normal. Ensure cookware is flat and stable.
Controls are unresponsive.	Safety lock activated; Wet or greasy fingers; Control panel dirty.	Deactivate safety lock; Ensure fingers are dry and clean; Clean control panel.

If the problem persists after attempting these solutions, please contact AMZCHEF customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	CE-FS-IRC119B33-GA
Brand	AMZCHEF
Color	Grey
Material	Ceramic Glass
Heating Elements	2 Induction Zones
Power (Watts)	3300 Watts
Voltage	220-240V (AC)

Feature	Detail
Frequency	50/60 Hz
Product Dimensions (D x W x H)	30 cm x 52 cm x 6.2 cm (11.8 in x 20.5 in x 2.4 in)
Cutout Dimensions (W x D)	(26.8-27) cm x (48.8-49) cm (10.5-10.6 in x 19.2-19.3 in)
Control Type	Touch Sensitive
Special Features	Timer, Flexible Zones, Safety Lock, Overheat Protection, Automatic Shut-off
Included Components	1 x AMZCHEF Dual Zone Induction Cooktop

Dimension du produit



Figure 8.1: Detailed product dimensions and recommended cutout dimensions for built-in installation.

9. WARRANTY AND SUPPORT

AMZCHEF products come with a standard manufacturer's warranty. For specific warranty details, registration, or to contact customer support, please visit the official AMZCHEF website or refer to the warranty card included with your product.

For technical assistance, troubleshooting beyond this manual, or spare parts, please contact AMZCHEF customer service:

- **Website:** www.amzchef.com
- **Email:** support@amzchef.com

Please have your model number (CE-FS-IRC119B33-GA) and purchase date ready when contacting support.

© 2023 AMZCHEF. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09CYNZC1K>

More documents and user manuals: <https://manuals.plus/>