

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [APM](#) /

> [APM 571075 Full HD 1080P Webcam User Manual](#)

## APM 571075

# APM 571075 Full HD 1080P Webcam User Manual

Model: 571075

## 1. PRODUCT OVERVIEW

---

The APM 571075 is a Full HD 1080P wired USB webcam designed for clear and fluid video communication. It features an integrated microphone and a privacy cover, making it suitable for virtual meetings, online calls, and streaming.



Image: APM 571075 Full HD 1080P Webcam, front view.

### Key Features:

- Full HD 1080P resolution (1920x1080 px) for clear video.
- Integrated microphone for audio capture.
- Smooth image transmission at 30 frames per second.
- Integrated privacy cover for enhanced security.
- Automatic adjustments for saturation, contrast, sharpness, white balance, and exposure.
- Wide-angle lens.
- Wired USB connection for reliable performance.

## 2. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x APM 571075 Full HD 1080P Webcam
- 1 x User Manual (Multilingual)



Image: APM 571075 Webcam in its retail packaging.

### 3. SETUP

---

#### System Requirements:

The APM 571075 webcam is compatible with:

- Personal Computers (PCs)
- Laptops
- Tablets (with USB host support)

#### Connecting the Webcam:

1. Unpack the webcam and uncoil the USB cable.
2. Plug the USB connector into an available USB port on your computer or compatible device.



Image: A hand plugging the USB cable of the webcam into a laptop's USB port.

### **Driver Installation:**

The APM 571075 webcam is a plug-and-play device. It does not require manual driver installation on most modern operating systems (e.g., Windows 10/11, macOS). Your system should automatically detect and install the necessary drivers upon connection.

## **4. OPERATING**

---

### **Using the Privacy Cover:**

The webcam features an integrated sliding privacy cover. To use it:

- **To cover the lens:** Gently slide the cover over the webcam lens when not in use to ensure privacy.
- **To uncover the lens:** Slide the cover away from the lens when you need to use the webcam.



Image: Close-up of the webcam lens with the integrated privacy cover.

### Video Conferencing and Streaming:

Once connected and recognized by your system, the webcam can be used with various video conferencing and streaming applications. Select the APM 571075 as your preferred camera and microphone input within the application settings.



Image: A screen displaying multiple participants in a video conference call, demonstrating the webcam's use.

### Automatic Adjustments:

The webcam automatically adjusts various image parameters, including saturation, contrast, sharpness, white balance, and exposure, to optimize video quality in different lighting conditions.

## 5. MAINTENANCE

---

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optics to gently wipe the webcam lens. Avoid abrasive materials or harsh chemicals.
- **Cleaning the Body:** Wipe the webcam's body with a soft, dry cloth.
- **Storage:** When not in use, store the webcam in a clean, dry place, preferably with the privacy cover engaged to protect the lens from dust and scratches.
- **Avoid Moisture:** This device is not waterproof. Keep it away from liquids and high humidity.

## 6. TROUBLESHOOTING

---

Problem	Possible Solution
Webcam not detected by computer.	<ul style="list-style-type: none"><li>• Ensure the USB cable is securely plugged into a working USB port.</li><li>• Try a different USB port on your computer.</li><li>• Restart your computer.</li><li>• Check your operating system's device manager to see if the webcam is listed.</li></ul>
Video image is frozen or choppy.	<ul style="list-style-type: none"><li>• Ensure you have a stable internet connection if using for online calls.</li><li>• Close other applications that might be using significant system resources.</li><li>• Try unplugging and replugging the webcam.</li><li>• Update your computer's USB drivers.</li></ul>
No audio from the integrated microphone.	<ul style="list-style-type: none"><li>• Check the audio settings in your operating system and the application you are using to ensure the APM 571075 microphone is selected and not muted.</li><li>• Ensure the privacy cover is not obstructing the microphone hole (if applicable).</li></ul>
Image quality is poor or colors are off.	<ul style="list-style-type: none"><li>• Ensure the lens is clean and free of smudges.</li><li>• Check lighting conditions; sufficient and even lighting improves image quality.</li><li>• Verify that the privacy cover is fully open.</li></ul>

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	APM
Model	571075
Color	Black

Feature	Detail
Product Type	Compact Webcam
Special Features	Integrated privacy cover
Focal Length	1 millimeter
Connectivity Technology	USB
Video Resolution	1080p (1920x1080 px)
Compatible Devices	Personal Computer, Laptop, Tablet
Package Dimensions (L x W x H)	14.8 x 7.7 x 6.2 centimeters
Image Stabilization	No
Included Components	1 webcam
Water Resistance Level	Not waterproof
Focus Type	Automatic focus
Effective Still Resolution	2.07 Megapixels
Video Capture Format	MP4
Supported Audio Format	PCM

## 8. WARRANTY INFORMATION

---

The APM 571075 Webcam comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets quality standards. Please retain your proof of purchase for warranty claims.

## 9. CUSTOMER SUPPORT

---

If you encounter any issues or have questions not covered in this manual, please contact APM customer support. Refer to the contact information provided with your product packaging or visit the official APM website for assistance.