Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- OnePlus /
- > OnePlus Nord N100 LTE Smartphone User Manual (Model BE2012)

OnePlus BE2012

OnePlus Nord N100 LTE Smartphone User Manual

Model: BE2012

1. Introduction

This manual provides essential information for the safe and efficient use of your OnePlus Nord N100 LTE smartphone. Please read this guide thoroughly before operating your device to ensure optimal performance and longevity. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The OnePlus Nord N100 LTE (Model BE2012) is a feature-rich smartphone designed for daily communication and entertainment. Key features include a 13MP Triple Camera System, an 8MP Front Camera, a large 90Hz display for immersive viewing, 4GB RAM, and 64GB of internal storage. It operates on Android 10 and is factory unlocked for major GSM carriers like T-Mobile, Sprint, and AT&T.



Image 2.1: Front and Rear View of the OnePlus Nord N100 LTE Smartphone. The device features a punch-hole display on the front and a triple camera setup with a fingerprint sensor on the back.

Amazon Renewed conditions All Amazon Renewed products are fully functional, and come with generic or original accessories and packaging. Example body scratches and dents – not actual products Excellent Good Acceptable Body: No cosmetic damage visible from Body: Light scratches, barely visible from Body: Light scratches, clearly visible from Screen: No scratches Screen: No scratches Screen: May have scratches, invisible when turned on Battery life: Greater than 80% Battery life: Greater than 80% Battery life: Greater than 80%

Image 2.2: Diagram highlighting key features of the OnePlus Nord N100, including the 6.52" HD+ LCD Display, Triple Camera System, 64 GB built-in storage, 18W Fast Charging, and Large 5000mAh battery.

3. SETUP

3.1 Inserting SIM and SD Card

- 1. Locate the SIM tray on the side of your device.
- 2. Use the SIM ejector tool (not included in renewed package) to open the tray.
- 3. Place your Nano-SIM card(s) and/or microSD card into the tray, ensuring correct orientation.
- 4. Gently push the tray back into the device until it clicks into place.

3.2 Initial Power On

- 1. Press and hold the Power button (located on the side) until the OnePlus logo appears.
- 2. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

4. OPERATING YOUR DEVICE

4.1 Basic Navigation

- Touchscreen: Tap to select, swipe to scroll, pinch to zoom.
- Power Button: Press to lock/unlock the screen. Press and hold for power options.
- Volume Buttons: Adjust media volume, ringtone volume, and alarm volume.
- Fingerprint Sensor: Located on the rear of the device for secure unlocking.

4.2 Display Features

The OnePlus Nord N100 features a 6.52-inch HD+ LCD display with a 90Hz refresh rate, providing a smooth visual experience for scrolling and gaming. The display resolution is 1920 x 1080 pixels.

5. CAMERA FEATURES

Capture your moments with the versatile camera system.

5.1 Rear Camera System

- Main Camera: 13MP sensor for clear and detailed photos.
- Macro Lens: 2MP dedicated lens for close-up shots.
- Depth Sensor: 2MP sensor for enhanced portrait mode with background blur.

5.2 Front Camera



Image 5.1: Diagram illustrating the triple camera system of the OnePlus Nord N100, detailing the 13MP Main Camera, Macro Lens, and Specialized Camera (Depth Sensor).

6. BATTERY MANAGEMENT

The device is equipped with a 5000 Milliamp Hours (mAh) Lithium Polymer battery, providing long-lasting power for extended use. Charging is facilitated via the USB-C port.

6.1 Charging

- Connect the provided USB Cable and Adapter to your device and a power outlet.
- Ensure you use the original or certified compatible charging accessories for optimal performance and safety.

7. CONNECTIVITY

- Wireless Carrier: Unlocked for all major GSM carriers (T-Mobile, Sprint, AT&T). Not compatible with Cricket, Xfinity, Visible, or other CDMA networks. Verify carrier frequency compatibility.
- Connectivity Technologies: USB (Type-C).
- Wireless Communication Technologies: Cellular, Wi-Fi, Bluetooth.
- GPS: Integrated GPS functionality for location services.
- Audio Jack: No traditional headphone jack. Audio output is via USB-C or Bluetooth.

8. Specifications

Feature	Detail
Model Name	BE2012
Brand	OnePlus
Operating System	Android 10.0
RAM	4 GB
Memory Storage Capacity	64 GB
Screen Size	6.52 Inches
Resolution	1920 x 1080
Refresh Rate	90 hertz
CPU Model	Snapdragon
Battery Capacity	5000 Milliamp Hours
Item Weight	11.3 ounces
Color	Midnight Frost

9. MAINTENANCE

9.1 Software Updates

Your device runs on Android 10.0. Periodically check for software updates in the device settings to ensure optimal performance, security, and access to new features. Available storage may be less due to device software updates and appusage.

9.2 Cleaning and Care

- Use a soft, lint-free cloth to clean the screen and body of the device.
- Avoid using harsh chemicals or abrasive materials that could damage the finish.
- Protect your device from extreme temperatures and direct sunlight.



Image 9.1: Guidelines for Amazon Renewed product conditions, detailing criteria for 'Excellent', 'Good', and 'Acceptable' states regarding cosmetic damage, screen condition, and battery life.

10. TROUBLESHOOTING

10.1 Common Issues

- Device not responding: Press and hold the Power button for 10-15 seconds to force restart.
- Network connectivity issues: Check SIM card insertion, toggle Airplane Mode, or restart the device.
- Battery draining quickly: Close unused apps, reduce screen brightness, or check for rogue apps in battery settings.

10.2 Factory Reset

If you experience persistent issues, a factory reset may resolve them. **Warning:** This will erase all data on your device. Back up important information before proceeding.

- 1. Go to Settings > System > Reset options.
- 2. Select 'Erase all data (factory reset)'.
- 3. Confirm your choice and follow the on-screen prompts.

11. WARRANTY AND SUPPORT

This Amazon Renewed device comes with a 90-day store limited warranty. For support or warranty claims, please contact the seller directly.

11.1 What's in the Box

- OnePlus Nord N100 LTE Smartphone (Renewed)
- · Premium aftermarket charger
- USB Cable

Please note that renewed products may have minor scuffs or scratches and ship in non-retail packaging.

Related Documents - BE2012



OnePlus Nord User Manual: Comprehensive Guide to Your Smartphone

Explore the OnePlus Nord User Manual for detailed instructions on setup, features, settings, app usage, safety precautions, and regulatory compliance for your OnePlus Nord smartphone.

OnePlus Nord N100 Quick Start Guide

Learn how to set up and use your OnePlus Nord N100 smartphone with this comprehensive quick start guide, covering device layout, SIM installation, charging, basic functions, settings, and safety information.

Nivod na použžie OnePlus Nord N100	Návod na použitie OnePlus Nord N100 Komplexný návod na použitie pre smartfón OnePlus Nord N100. Obsahuje pokyny k nastaveniu, funkciám, aplikáciám, tipom, bezpečnostným informáciám a regulačnému súladu.
OnePlan Nord CE 5G Nisved an possibile	OnePlus Nord CE 5G: Návod na použitie a informácie o produkte Komplexný návod na použitie pre smartfón OnePlus Nord CE 5G. Získajte podrobné informácie o nastavení, funkciách, bezpečnosti, tipoch a podpore pre vaše zariadenie.
OnePlus Nord N10 SG Användarmanual	OnePlus Nord N10 5G Användarmanual Denna användarmanual för OnePlus Nord N10 5G ger detaljerade instruktioner för att komma igång, konfigurera inställningar, använda appar, samt viktig säkerhetsinformation och tekniska specifikationer. Lär dig allt du behöver veta för att maximera din enhets potential.