EUHOMY IM-03S

EUHOMY Nugget Ice Maker User Manual

Model: IM-03S

Product Overview

The EUHOMY Nugget Ice Maker is designed to provide soft, chewable nugget ice quickly and efficiently. This countertop unit features a self-cleaning function and offers flexible water refilling options, making it suitable for various home and office environments.



Figure 1: Front view of the EUHOMY Nugget Ice Maker, showcasing its sleek silver design and transparent lid.

Key Features:

- **Nugget Ice Type:** Produces soft, chewable nugget ice that absorbs drink flavors and cools beverages rapidly.
- **High Ice Production:** Capable of producing up to 34 lbs of ice per day, with the first batch ready in 15-18 minutes.
- **Dual Water Refill Options:** Supports both automatic water line connection and manual refilling via a 3-quart reservoir.
- **Automatic Self-Cleaning:** Integrated self-cleaning function helps prevent limescale buildup and odors.
- **Intelligent Operation:** Features "Ice-full Reminder" and "Water Shortage Alert" indicators for convenient use.



Figure 2: Visual representation of the ice maker's key features, including daily production capacity, ice readiness time, ice basket size, and water reservoir capacity.

Setup

Unpacking and Placement:

- Carefully remove the ice maker from its packaging.
- Place the unit on a flat, stable, and level surface away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.
- Allow the ice maker to stand upright for at least 4 hours before initial use to allow refrigerants to settle.

Initial Cleaning:

Before first use, it is recommended to perform a self-cleaning cycle to ensure optimal hygiene and ice quality.

1. Ensure the ice maker is empty of any ice and water.
2. Fill the water reservoir with clean, potable water up to the "MAX" fill line.
3. Press and hold the "Clean" button for more than 3 seconds to initiate the self-cleaning program.
4. The cleaning cycle will run for approximately 5 minutes. Once complete, drain the water from the unit.



Figure 3: Illustration of the automatic self-cleaning process, activated by holding the "Clean" button.

Operating Instructions

Water Refill Options:

The EUHOMY Nugget Ice Maker offers two convenient methods for water refilling:

1. **Manual Water Refill:** Open the top lid and pour potable water directly into the 3-quart reservoir up to the "MAX" fill line.
2. **Automatic Water Refill:** For continuous ice production, connect the ice maker to your home water system using the provided water pipe. Refer to the detailed diagram for connection points.



Figure 4: Depiction of both manual and automatic water refilling methods for the ice maker.

Making Ice:

1. Ensure the water reservoir is filled.
2. Press the "ON/OFF" button on the control panel to start ice production. The "Power" indicator light will illuminate.
3. The ice maker will begin producing nugget ice. The first batch typically takes 15-18 minutes.
4. The "Ice Full" indicator will light up when the ice basket is full, and the machine will automatically pause production.

5. The "Add Water" indicator will light up when the water reservoir is low, prompting you to refill.



Figure 5: Step-by-step guide for operating the ice maker, from adding water to enjoying nugget ice.

Control Panel:

The intuitive control panel provides clear indicators for the ice maker's status:

- **ICE FULL:** Illuminates when the ice storage basket is full.
- **ON/OFF:** Press to start or stop ice production.
- **CLEAN:** Press and hold for 3 seconds to activate the self-cleaning cycle.
- **ADD WATER:** Illuminates when the water reservoir needs refilling.



Figure 6: Close-up of the control panel showing the "Ice-full Reminder" and "Water Shortage Alert" indicators.

Maintenance

Regular Cleaning:

Regular cleaning is crucial for maintaining the performance and longevity of your ice maker. It is recommended to clean the unit at least once a month, or more frequently depending on usage and water hardness.

1. **Drain Water:** Before cleaning, ensure the unit is unplugged and all water is drained from the reservoir.
2. **Self-Cleaning Cycle:** Utilize the automatic self-cleaning function as described in the Setup section. This helps to remove mineral buildup and odors from internal components.
3. **Manual Cleaning:** For thorough cleaning, remove the ice basket and wipe down the interior surfaces with a soft

cloth and a mild detergent solution. Rinse thoroughly with clean water.

4. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
5. **Air Filter:** Periodically check and clean the air filter located on the side or back of the unit to ensure proper ventilation.

Troubleshooting

If you encounter issues with your EUHOMY Nugget Ice Maker, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; unit unplugged; ambient temperature too high.	Fill water reservoir; ensure unit is plugged in; operate in a cooler environment.
"Add Water" indicator is on.	Water level is low.	Refill the water reservoir to the "MAX" line.
"Ice Full" indicator is on.	Ice basket is full.	Remove ice from the basket.
Unusual noise during operation.	Normal operation sounds (compressor, water pump); unit not level.	Ensure unit is on a level surface. If noise persists or is excessive, contact support.
Ice is melting quickly.	Poor insulation; high ambient temperature.	Ensure lid is closed properly; operate in a cooler environment. The unit is not a freezer and ice will melt over time.

If the problem persists after attempting these solutions, please contact EUHOMY customer support for further assistance.

Specifications

- **Brand:** EUHOMY
- **Model Number:** IM-03S
- **Product Dimensions:** 17.64"D x 9.69"W x 17"H
- **Capacity:** Max 34 lbs/day ice production, 3 Qt water reservoir
- **Wattage:** 170 watts
- **Item Weight:** Approximately 37.75 Pounds



Figure 7: Visual guide to the ice maker's dimensions and included accessories like the ice scoop and water pipe.

Warranty and Support

EUHOMY offers a **12-month after-sales service** for this ice maker. For any questions, concerns, or support needs, please contact EUHOMY customer service. Please have your model number (IM-03S) and purchase details ready when contacting support.

For additional resources, you may refer to the officialUser Manual (PDF).

© 2024 EUHOMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question