

[Manuals.plus](#) /

> [Samsung](#) /

> SAMSUNG Galaxy Watch 4 Bluetooth & GPS Smartwatch, 40mm - Black User Manual

Samsung SM-R860NZKALTA

SAMSUNG Galaxy Watch 4 User Manual

Model: SM-R860NZKALTA

PRODUCT OVERVIEW

The Samsung Galaxy Watch 4 is a Bluetooth and GPS-enabled smartwatch designed to help users track fitness, manage notifications, and stay connected. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.





Image: The retail packaging for the Samsung Galaxy Watch 4. The white box features the 'Galaxy Watch4' logo at the top and a depiction of the black smartwatch with a green watch face in the center. The Samsung logo is visible at the bottom of the box.

SETUP

1. What's in the Box

- Samsung Galaxy Watch 4 (SM-R860NZKALTA)
- 1 Lithium Ion battery (pre-installed or included)
- Charging cable/dock
- Quick Start Guide

2. Initial Charging

Before first use, fully charge your Galaxy Watch 4. Connect the charging cable to a power source and place the watch on the charging dock. The watch display will indicate charging status.

3. Pairing with Your Smartphone

1. Ensure your smartphone is running a compatible operating system (Android or iOS).
2. Download and install the **Samsung Wearable** app from your device's app store.
3. Open the Samsung Wearable app and follow the on-screen instructions to pair your Galaxy Watch 4 via Bluetooth.
4. Confirm the pairing code on both your watch and smartphone.

OPERATING YOUR GALAXY WATCH 4

Basic Navigation

- **Touchscreen:** Swipe, tap, and pinch to navigate menus and interact with apps.
- **Buttons:** Use the physical buttons on the side for power, back, and home functions.

Key Features

- **Time Display:** Customize watch faces to show time and other information.
- **Text Messaging:** Send and receive text messages directly from your wrist.
- **GPS:** Utilize built-in GPS for accurate location tracking during outdoor activities.
- **Health Tracking:** Monitor heart rate, track workouts, and analyze sleep patterns to achieve health goals.

Connectivity

The Galaxy Watch 4 supports both Bluetooth and Wi-Fi connectivity for seamless integration with your smartphone and access to online services.

MAINTENANCE

Cleaning Your Watch

Regularly clean your watch and strap with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

Battery Care

To maximize battery life, avoid extreme temperatures and fully discharging the battery frequently. Charging nightly is recommended for consistent use. The watch uses a 361 Milliamp Hour Lithium Ion battery.

Software Updates

Keep your watch's software updated through the Samsung Wearable app to ensure optimal performance, new features, and security enhancements.

TROUBLESHOOTING

Common Issues and Solutions

Issue	Possible Cause	Solution
Watch not pairing	Bluetooth off, app issue, watch not in pairing mode	Ensure Bluetooth is on, restart watch and phone, try resetting the watch.
Rapid battery drain	High usage, background apps, outdated software	Reduce screen brightness, close unused apps, update software, disable unnecessary features.

Issue	Possible Cause	Solution
Watch overheating	Intensive use, charging, software issue	Stop using the watch, remove it from your wrist, allow it to cool down. If persistent, contact support.
NFC not working	Compatibility issues, software settings	Check NFC settings on both watch and phone. Ensure phone compatibility (e.g., Xiaomi phones mentioned in reviews).

Resetting the Watch

If issues persist, you may need to perform a factory reset. This will erase all data on the watch. Consult the Samsung Wearable app or Samsung's official support website for detailed instructions on how to perform a factory reset.

SPECIFICATIONS

Samsung Galaxy Watch 4 (SM-R860NZKALTA)

Feature	Detail
Model Number	SM-R860NZKALTA
Product Dimensions	1.59 x 1.55 x 0.39 inches
Item Weight	0.882 ounces (25 Grams)
Screen Display Size	1.35 Inches
Shape	Round
Memory Storage Capacity	16000 MB
RAM Memory Installed Size	1.5 GB
Operating System	Android, iOS compatible
Special Features	Time Display, Text Messaging, GPS
Battery Capacity	361 Milliamp Hours
Battery Type	Lithium Ion
Connectivity Technology	Wi-Fi, Bluetooth
GPS	True (Built-in)
Manufacturer	SAMSUNG
First Available Date	August 19, 2021

WARRANTY AND SUPPORT

Your Samsung Galaxy Watch 4 comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Samsung support website for detailed warranty terms and conditions.

For technical assistance, troubleshooting, or to inquire about repairs, please contact Samsung Customer Service or visit their online support portal. You may also consider purchasing extended protection plans for additional coverage.

