

Finnhomy Nightstand

Finnhomy Nightstands Set of 2 with Rattan Drawers - Assembly and Care Manual

Brand: Finnhomy | Model: Nightstand

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Always assemble the product according to the instructions provided.
- Do not exceed the maximum weight limit of **45 pounds** on the tabletop.
- Be cautious when using the drawers to prevent pinching.
- It is recommended to anchor the product to the wall to prevent tipping, especially in households with children or pets.
- Keep small parts away from children during assembly.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 2 x Finnhomy Nightstands (unassembled)
- Assembly Hardware Kit (screws, dowels, drawer slides, handles)
- Instruction Manual

3. SETUP AND ASSEMBLY

Assembly is required for these nightstands. It is recommended to have a screwdriver for the assembly process. Follow the step-by-step instructions provided in the included manual for optimal results. Assembly

typically takes approximately 1.5 hours per nightstand for one person.

3.1 Component Overview

Familiarize yourself with the main components of the nightstand before starting assembly.



This image illustrates key components such as the solid wood handles, handmade rattan drawer fronts, smooth drawer sliders, and solid wood construction elements.

3.2 Dimensions

Ensure the dimensions meet your space requirements before assembly.



The diagram shows the nightstand's dimensions: 15.75" W x 15.55" D x 21.65" H, with a drawer height of 6.37".

3.3 Assembly Steps

1. Unpack all components and verify against the parts list.
2. Attach the solid wood legs to the base of the nightstand using the provided hardware.
3. Assemble the main frame of the nightstand according to the diagrams.
4. Install the drawer slides onto the nightstand frame.
5. Assemble the drawers, ensuring the rattan panels are correctly inserted.
6. Attach the solid wood handles to the drawer fronts.
7. Insert the assembled drawers into the nightstand frame, ensuring smooth operation.
8. Place the nightstand in its desired location and, if possible, anchor it to the wall for stability.

4. OPERATING INSTRUCTIONS

The Finnhome Nightstands are designed for convenient storage and display in your bedroom or living area.

4.1 Drawer Usage

- To open a drawer, gently pull the handle.
- To close a drawer, push it firmly until it is flush with the nightstand frame.

- Avoid overloading drawers to ensure smooth operation and prevent damage to the slides.

4.2 Top Surface Use

- The top surface can be used to place lamps, alarm clocks, books, or decorative items.
- Do not place items heavier than 45 pounds on the tabletop.
- Use coasters under drinks to protect the lacquered surface from moisture rings.



This image shows two nightstands in a natural finish, demonstrating typical usage with a lamp, alarm clock, and decorative items on their surfaces.

5. MAINTENANCE

Proper care will extend the life and appearance of your Finnhome Nightstands.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the lacquered finish.
- **Rattan Care:** The natural rattan can be gently dusted with a soft brush or vacuum cleaner with a brush attachment. Avoid excessive moisture.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Spills:** Clean spills immediately to prevent staining, especially on the natural wood and rattan components.

6. TROUBLESHOOTING

If you encounter any issues with your nightstands, refer to the following common problems and solutions.

- **Drawers do not slide smoothly:**
 - a. Ensure the drawer slides are installed correctly and are aligned. Refer to the assembly instructions.
 - b. Check for any obstructions within the drawer tracks.
 - c. Verify that all screws securing the slides are tightened.
- **Nightstand feels wobbly:**
 - a. Check that all assembly screws are fully tightened.
 - b. Ensure the nightstand is placed on a level surface.
 - c. Consider anchoring the nightstand to the wall for added stability.
- **Missing or damaged parts:**
 - a. Review the package contents list carefully. If parts are genuinely missing or damaged upon arrival, contact Finnhome customer service for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Finnhome
Model Name	Nightstand
Product Dimensions (D x W x H)	15.55" x 15.75" x 21.65"
Maximum Weight Recommendation	45 Pounds
Color	Natural
Material Type	Engineered Wood, Rattan
Finish Type	Lacquered
Number of Drawers	2
Item Weight	48 Pounds (for the set)
Tools Recommended For Assembly	Screw Driver

8. WARRANTY AND SUPPORT

Finnhome is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, Finnhome offers customer support for any questions or issues you may encounter.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Finnhome customer service. We aim to resolve your problems within 24 hours.

For support, please refer to the contact information provided on the product packaging or the official Finnhome website.

