

[manuals.plus](#) /› [Packard Bell](#) /› [Packard Bell airFrame 27" FHD Monitor User Manual \(Model M27200\)](#)

Packard Bell M27200

Packard Bell airFrame 27" FHD Monitor User Manual

Model: M27200

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Packard Bell airFrame 27" FHD Monitor. Please read this manual thoroughly before using the monitor and retain it for future reference.

Safety Information

- Ensure the monitor is placed on a stable, level surface to prevent accidental falls.
- Do not expose the monitor to rain or moisture to avoid electric shock or fire.
- Keep ventilation openings clear to prevent overheating.
- Use only the power adapter supplied with the monitor.
- Disconnect the power cable from the outlet before cleaning the monitor.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Packard Bell airFrame 27" FHD Monitor
- Monitor Stand (Base and Neck)
- Power Adapter
- HDMI Cable
- User Manual (this document)

3. SETUP

3.1 Assembling the Stand

1. Carefully remove the monitor from its packaging, placing it face down on a soft, clean surface to prevent scratches.
2. Attach the stand neck to the monitor's rear panel. Secure with screws if provided.
3. Attach the stand base to the stand neck. Secure with the thumb screw or screws provided.
4. Carefully lift the assembled monitor and place it on a stable desk or table.

3.2 Connecting Cables

Connect the necessary cables to the monitor and your computer or device.

- **Power Cable:** Connect the power adapter to the monitor's power input, then plug the adapter into a power outlet.
- **HDMI Cable:** Connect one end of the HDMI cable to the HDMI port on your monitor and the other end to the HDMI port on your computer or device.
- **VGA Cable:** Alternatively, connect one end of the VGA cable to the VGA port on your monitor and the other end to the VGA port on your computer or device.



Image: Front view of the Packard Bell airFrame 27" monitor, illustrating its main features and connectivity options.

3.3 VESA Mounting

The monitor is VESA mount compatible, allowing it to be mounted on a wall or a monitor arm (mounting hardware sold separately).

- Remove the stand from the monitor.
- Attach the VESA-compatible mounting bracket (100x100mm) to the rear of the monitor using appropriate screws.

- Follow the instructions provided with your VESA mounting hardware for secure installation.



VESA MOUNT COMPATIBLE

Compatible with VESA for wall or desk mounting.

Image: Illustration of the VESA mount compatibility on the rear of the monitor, showing a mounting plate being secured.


4. OPERATING THE MONITOR

4.1 Powering On/Off

Press the power button, usually located on the bottom right or rear of the monitor, to turn the monitor on or off. The power indicator light will illuminate when the monitor is on.

4.2 Adjusting the Viewing Angle

The monitor supports tilt adjustment for optimal viewing comfort. You can tilt the screen from -5 degrees forward to +15 degrees backward.



ERGONOMIC TILT

Find the perfect angle for viewing and productivity with a -5° to +15° tilt range.

Image: Diagram illustrating the ergonomic tilt range of the monitor, from -5° to +15°.


4.3 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various display settings. The control buttons are typically located on the bottom or rear of the monitor.

- Press a menu button to activate the OSD.
- Use the navigation buttons (up/down/left/right) to browse through menu options.
- Press an 'OK' or 'Enter' button to select an option or confirm a setting.
- Press an 'Exit' or 'Menu' button again to close the OSD.

Common OSD Settings:

- **Brightness/Contrast:** Adjust the overall luminance and difference between light and dark areas.
- **Color Settings:** Modify color temperature, hue, and saturation.
- **Input Select:** Manually switch between HDMI and VGA inputs.
- **Aspect Ratio:** Adjust the display aspect ratio (e.g., 16:9, 4:3).
- **Picture Mode:** Select predefined display modes (e.g., Standard, Game, Movie).



FULL HIGH DEFINITION RESOLUTION

Visually striking HD 1920x1080 resolution designed for multimedia apps, entertainment, and gaming.

Image: The monitor displaying a vibrant image, highlighting its Full HD 1920x1080 resolution.



Image: A diagram illustrating the monitor's 178-degree wide viewing angle, ensuring consistent image quality from various positions.

5. MAINTENANCE

5.1 Cleaning the Monitor

- Always unplug the monitor from the power outlet before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, solvents, or abrasive materials.

5.2 General Care

- Avoid placing heavy objects on the monitor or its cables.
- Do not block the ventilation slots.
- Store the monitor in a cool, dry place if not in use for an extended period.

6. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image on screen	Monitor not powered on; Incorrect input selected; Video cable loose or disconnected.	Ensure power cable is connected and monitor is on. Select correct input source (HDMI/VGA). Check video cable connections.
Image is blurry or distorted	Incorrect resolution; Dirty screen.	Set display resolution to 1920x1080. Clean the screen as per maintenance instructions.
No sound (if applicable)	Volume too low; Audio cable disconnected (if external speakers).	Adjust monitor volume. Check computer audio settings. Ensure external speakers are connected and powered.
Monitor flickers	Refresh rate mismatch; Interference.	Set display refresh rate to 75Hz. Ensure no strong electromagnetic devices are nearby.

7. SPECIFICATIONS

Feature	Specification
Model Number	M27200
Screen Size	27 Inches
Resolution	1920 x 1080 (FHD 1080p)
Aspect Ratio	16:9
Refresh Rate	75Hz
Response Time	5ms
Viewing Angle	178 Degrees
Tilt Adjustment	-5° to +15°
VESA Compatibility	Yes (100x100mm)
Inputs	HDMI, VGA
Product Dimensions (without stand)	14.2 x 24.2 x 1.77 inches
Item Weight	5 pounds
Manufacturer	Southern Telecom

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Packard Bell airFrame monitor is covered by a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.


8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Packard Bell customer support. Contact information can typically be found on the manufacturer's official website or on the warranty card.

You may also visit the [Packard Bell Store on Amazon](#) for additional product information and resources.

© 2025 Packard Bell. All rights reserved.

Related Documents - M27200

	<p>Packard Bell WS21500BK AirFrame Dual Monitor Workstation Quick Start Guide</p> <p>A quick start guide for the Packard Bell WS21500BK AirFrame Dual Monitor Workstation, covering unboxing, assembly, connections, and setup for Windows and Mac operating systems.</p>
	<p>Packard Bell N11250 CloudBook Quick Start Guide</p> <p>A quick start guide for the Packard Bell N11250 CloudBook, covering buttons, ports, touchpad usage, Windows 10 S Mode, storage expansion with SATA M.2 SSD, and warranty information.</p>
	<p>Packard Bell EasyNote TS User Guide</p> <p>Comprehensive user guide for the Packard Bell EasyNote TS laptop, covering setup, software, internet usage, safety, maintenance, and recovery.</p>
	<p>Packard Bell EasyNote LJ65 Service Guide: Disassembly, Repair, and Troubleshooting</p> <p>This comprehensive service guide provides detailed technical information for the Packard Bell EasyNote LJ65 laptop, including disassembly procedures, component replacement instructions, troubleshooting steps, and system specifications.</p>
	<p>Packard Bell EasyNote TR82 Quick Start & Troubleshooting Guide</p> <p>This comprehensive guide provides essential information for setting up, using, and troubleshooting your Packard Bell EasyNote TR82 computer. Learn about basic operations, safety precautions, software, internet connectivity, and common issues.</p>

Non-Contact Infrared Thermometer



PBT200 User Guide



[Packard Bell PBT200 Non-Contact Infrared Thermometer User Guide](#)

User guide for the Packard Bell PBT200 non-contact infrared thermometer. Learn how to use its features, including body/surface modes, fever alert system, and temperature history, along with safety and maintenance instructions.