

[manuals.plus](#) /

› [Barbie](#) /

› [Barbie House Modern User Manual](#)

Barbie HCD47

Barbie House Modern Instruction Manual

Model: HCD47

1. INTRODUCTION

Welcome to the world of Barbie! This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Barbie House Modern (Model HCD47). Designed for imaginative play, this fully furnished dollhouse offers multiple play areas and folds for convenient storage.



Figure 1.1: The Barbie House Modern, showing both its packaging and assembled form. This image illustrates the product as it appears out of the box and ready for play.

2. SETUP

Your Barbie House Modern is designed for easy setup and portability. It comes in a folded configuration for compact storage and transport.

- 1. Unboxing:** Carefully remove all components from the packaging. Ensure all accessories listed in the product description are present.
- 2. Unfolding the House:** The house is designed to unfold from its compact state. Gently extend the sections until they lock into place, forming the full two-story structure. Refer to the visual guides for proper alignment.
- 3. Accessory Placement:** Place the included furniture and accessories within the designated play areas as desired.



Fold & store!

Figure 2.1: The Barbie House Modern in its folded state, ready for storage or transport. This compact design allows for easy setup and put-away.



Figure 2.2: An exterior view of the Barbie House Modern, showcasing its modern design and front entrance. This view highlights the aesthetic details of the dollhouse.

3. OPERATING INSTRUCTIONS (PLAY FEATURES)

The Barbie House Modern offers a dynamic 360-degree play experience across two stories and four distinct play areas. Dolls are sold separately.

- **Front Door & Welcome Area:** Use the front door to welcome Barbie dolls and their friends into the house.
- **Kitchen:** The fully equipped kitchen area includes a sink, stove, and oven, inspiring culinary adventures.



Kitchen with sink, stove & oven!

Figure 3.1: A Barbie doll interacting with the kitchen area, featuring a sink, stove, and oven. This image demonstrates the functional aspects of the kitchen play space.

- **Dining Area:** The dining table with seating for two allows for shared meals and social play.

Dining area with furniture!



DOLLS SOLD SEPARATELY. SUBJECT TO AVAILABILITY

Figure 3.2: Barbie dolls seated at the dining table, illustrating the dining area's setup with furniture. This image shows how the dining space can be utilized for storytelling.

- **Loft Bed:** After a day of play, Barbie dolls can be tucked into the cozy loft bed for rest.
- **Accessories:** Utilize the various storytelling pieces, including a pet puppy and other small items, to enhance imaginative play.



Pet puppy & accessories!

Figure 3.3: A collection of accessories included with the Barbie House Modern, featuring a pet puppy, dishes, and other small items. These accessories add detail and expand play possibilities.



DOLLS SOLD SEPARATELY, SUBJECT TO AVAILABILITY.

Figure 3.4: A child engaging in play with the Barbie House Modern and several Barbie dolls. This image demonstrates the interactive nature of the dollhouse and its appeal to children.

4. MAINTENANCE

- **Cleaning:** To clean the Barbie House Modern, wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Storage:** When playtime is over, the entire set folds for easy clean-up and compact storage. Ensure all accessories are stored safely within the folded unit or a separate container to prevent loss.

5. TROUBLESHOOTING

Most issues with the Barbie House Modern can be resolved with simple checks.

- **House Not Standing Firmly:** Ensure all folding sections are fully extended and locked into place. Check for any obstructions preventing proper assembly.
- **Missing Pieces:** Refer to the product packaging or description to confirm all included accessories. If a piece is genuinely missing upon unboxing, contact customer support.
- **Difficulty Folding/Unfolding:** Apply gentle, even pressure. Do not force parts. Ensure no accessories are caught in the folding mechanism.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	12.13 x 27.8 x 20.24 inches
Item Weight	3.09 pounds
Item Model Number	HCD47
Manufacturer Recommended Age	0 months and up
Release Date	November 1, 2021
Manufacturer	Mattel

7. WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain support for your Barbie House Modern, please contact Mattel customer service directly. Keep your purchase receipt as proof of purchase.



You can also visit the official Barbie store for more products and information [Barbie Official Store](#)

For more Barbie Dreamhouse fun, visit: [Barbie Dreamhouse](#)

© 2025 Mattel. All rights reserved. Barbie and associated trademarks are owned by Mattel.

Related Documents - HCD47

	<p>Barbie Queen of the Prom Board Game Rules and Instructions</p> <p>Official rules and instructions for the Barbie Queen of the Prom board game by Mattel. Learn how to play, game components, and winning conditions.</p>
	<p>HMD Barbie Phone Reviewer's Guide: Classic Flip Phone Experience</p> <p>Explore the HMD Barbie Phone, a stylish flip phone designed for a classic, social-media-free experience. Learn about unboxing, setup, features like the Malibu Snake game, and its availability.</p>

	<p>Barbie Gotta Groove 73020UK Instruction Manual - How to Play & Setup</p> <p>Official instruction manual for the Barbie Gotta Groove electronic toy (Model 73020UK). Learn how to set up, play, install batteries, and troubleshoot this fun dancing game from Radica.</p>
	<p>Barbie Kayak and Tent Playset Assembly Instructions (Model HRG77)</p> <p>Detailed, step-by-step assembly guide for the Barbie Kayak and Tent playset. Includes a list of contents, assembly steps, and important safety warnings. Model HRG77.</p>
	<p>Guide d'utilisation du cadre photo numérique Barbie BAR598</p> <p>Manuel d'utilisation complet pour le cadre photo numérique Barbie BAR598, incluant les instructions de sécurité, de configuration, de fonctionnement, de dépannage et de garantie par Emerson Radio Corp.</p>
	<p>Barbie Gotta Groove Instruction Manual - Model 73020</p> <p>Official instruction manual for the Barbie Gotta Groove electronic dance game (Model 73020). Learn how to play, set skill levels, perform moves, install batteries, and troubleshoot issues. Includes warranty and FCC compliance information.</p>