

[Manuals.plus](#) /

› [CLP](#) /

› CLP Los Angeles Bar Stool Instruction Manual

CLP Los Angeles Bar Stool

CLP Los Angeles Bar Stool Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your CLP Los Angeles Bar Stool. Please read these instructions carefully before assembly and operation, and retain them for future reference.





Front-side view of the assembled CLP Los Angeles Bar Stool in black, featuring a padded seat, backrest, armrests, and an adjustable height mechanism with a footrest on a round black base.

2. SAFETY INFORMATION

Important Safety Precautions:

- Do not exceed the maximum load capacity of **150 kg**. Overloading can cause damage to the stool and potential injury.
- Ensure the bar stool is placed on a stable and level surface to prevent tipping.
- Keep hands and fingers clear of moving parts during height adjustment.
- Regularly check all screws and connections to ensure they are tight. Retighten if necessary.
- Do not stand on the stool.



An icon illustrating the maximum weight capacity of the bar stool, which is 150 kilograms.

3. PRODUCT FEATURES

The CLP Los Angeles Bar Stool is designed for comfort and versatility, featuring:

- **Adjustable Height:** The seat height can be easily adjusted to suit various counter or bar heights.
- **360° Swivel Function:** The seat rotates fully, providing flexibility and ease of movement.
- **Padded Seat, Backrest, and Armrests:** Offers enhanced seating comfort.
- **Sturdy Metal Base:** Provides stability and durability.
- **Integrated Footrest:** For additional comfort and support.



An icon demonstrating the bar stool's adjustable height feature and its ability to swivel 360 degrees.

4. SETUP AND ASSEMBLY

Assembly is required. Please follow these steps carefully. It is recommended to assemble the stool on a soft, clean surface to prevent scratches.



An illustrative diagram depicting the main components of the bar stool: the base, the gas lift column, and the seat assembly, indicating how they fit together.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (if provided with your product).
2. **Attach Gas Lift to Base:** Insert the wider end of the gas lift cylinder into the center hole of the metal base. Ensure it is seated firmly.
3. **Attach Footrest:** Slide the footrest onto the gas lift cylinder, if it is a separate component. Ensure it is at the correct height and secured.
4. **Prepare Seat Assembly:** Attach the mounting plate (if separate) to the underside of the seat using the provided screws. Ensure all screws are tightened securely.
5. **Connect Seat to Gas Lift:** Place the assembled seat onto the narrower end of the gas lift cylinder. The seat should fit securely onto the cylinder.
6. **Test Stability:** Gently sit on the stool to ensure all components are properly engaged and stable.

5. OPERATING INSTRUCTIONS

Height Adjustment:

- To raise the seat, lift the adjustment lever while standing up, allowing the gas lift to extend. Release the lever at the desired height.
- To lower the seat, lift the adjustment lever while seated, applying your weight to the seat. Release the lever at the desired height.

Swivel Function:

- The seat can rotate 360 degrees freely. Simply turn the seat in the desired direction.

6. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your bar stool.

- **Cleaning Fabric:** For general cleaning, use a soft brush or vacuum cleaner to remove dust and loose particles. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner according to its instructions, testing on an inconspicuous area first.
- **Cleaning Metal Parts:** Wipe metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically inspect all screws and connections for tightness. Retighten as needed to maintain stability.
- **Floor Protection:** The base includes floor protection to prevent scratches. Ensure these remain intact and replace if worn.



An icon indicating the presence of floor protection features on the bar stool's base to prevent scratches.

7. TROUBLESHOOTING

If you encounter issues with your bar stool, refer to the following common solutions:

- **Stool feels wobbly:** Check all assembly screws and connections. Ensure they are fully tightened. Verify the stool is on a flat, even surface.
- **Height adjustment not working:** Ensure the lever is fully engaged. If the gas lift is not responding, it may be faulty and require replacement.
- **Squeaking noises:** Apply a small amount of silicone-based lubricant to moving parts, such as the swivel mechanism or gas lift connections.

8. SPECIFICATIONS

Brand	CLP
Model	Los Angeles Bar Stool
Total Height	113 cm
Total Width	60 cm
Total Depth	56 cm
Seat Height	64 - 84 cm (adjustable)
Seat Width	49 cm
Seat Depth	44 cm
Backrest Height	30 cm
Upholstery Thickness	7 cm
Base Diameter	Ø 45 cm
Maximum Load Capacity	150 kg

Product Weight	13 kg
Frame Material	Metal
Seat Material Type	Polyester Fabric



93cm

56cm

60cm

Diagram showing the overall dimensions of the bar stool: total height 93cm, total width 60cm, total depth 56cm.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact CLP customer service directly. Keep your proof of purchase for any warranty claims.

© 2023 CLP. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question