

iMoshion Universal Bike Mount

iMoshion Universal Bike Mount Instruction Manual

Model: Universal Bike Mount

1. PRODUCT OVERVIEW

The iMoshion Universal Bike Mount is designed to securely hold your smartphone on your bicycle handlebars, allowing for convenient access to navigation, fitness apps, or music while cycling. Made from soft, shock-resistant silicone, it ensures your device is held firmly without causing damage.

- Made from soft, shock-resistant silicone.
- Easy to attach to any bicycle handlebar.
- Simple and secure device placement.
- Ideal for smartphone navigation.



Image 1.1: The iMoshion Universal Bike Mount securely holding a smartphone on a bicycle handlebar, ready for use.

2. SETUP AND INSTALLATION

Follow these steps to properly install your iMoshion Universal Bike Mount:

- 1. Attach to Handlebar:** Locate a suitable position on your bicycle handlebar. Wrap the main silicone strap of the mount around the handlebar and secure it. Ensure it is tight and stable.

Einfache Montage

Die Halterung kann **einfach** am Lenker befestigt werden



Image 2.1: Attaching the mount to the bicycle handlebar.

2. **Insert Smartphone:** Gently stretch the four silicone corners of the mount over your smartphone. Start with two opposite corners, then stretch the remaining two over the other corners of your device. Ensure all four corners of your phone are securely held by the silicone straps.



Image 2.2: Placing the smartphone into the flexible silicone straps.

3. **Adjust Position:** The mount is designed to be rotatable. Adjust the angle of your smartphone for optimal viewing while riding.

3. OPERATING INSTRUCTIONS

Once installed, using your iMoshion Universal Bike Mount is straightforward:

- **Secure Fit:** The flexible silicone material provides a snug and secure fit for various smartphone sizes, up to a maximum size of 16.5 cm.



Für Smartphones mit einer
maximalen Größe von **16,5 cm**



Image 3.1: The mount accommodates various smartphone sizes.

- **Navigation Use:** Position your phone to easily view navigation directions without obstructing your view of the road.

Sicher unterwegs



Image 3.2: Using the mount for smartphone navigation.

- **Access Ports:** The design allows access to most charging ports and headphone jacks, depending on your phone model and port location.
- **Removal:** To remove your smartphone, gently peel back the silicone corners one by one. To remove the mount from the handlebar, unwrap the main strap.

4. MAINTENANCE

To ensure the longevity and optimal performance of your iMoshion Universal Bike Mount, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the silicone mount with a damp cloth to remove dust and dirt. For stubborn grime, a mild soap solution can be used, followed by rinsing with clean water and air drying.
- **Storage:** When not in use, store the mount in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically inspect the silicone for any signs of wear, tears, or damage. If significant damage is observed, replace the mount to ensure secure phone retention.

5. TROUBLESHOOTING

If you encounter any issues with your iMoshion Universal Bike Mount, consider the following:

- **Phone feels loose:** Ensure all four silicone corners are properly stretched over your phone's corners. The mount is designed for phones up to 16.5 cm; larger phones may not fit securely.
- **Mount slips on handlebar:** Verify that the main strap is wrapped tightly around the handlebar. The silicone material provides grip, but excessive force or an unusually smooth handlebar surface might cause minor movement. Re-adjust and tighten if necessary.
- **Difficulty inserting/removing phone:** The silicone is designed to be snug. Ensure you stretch the corners sufficiently when inserting or removing the phone. Avoid forcing the phone, as this could damage the mount or your device.

6. SPECIFICATIONS

Brand	iMoshion
Model Name	Universal Bike Mount
Manufacturer Reference	FIETSHOUDER44942601
Material	Silicone and TPU (soft)
Mounting Type	Handlebar
Compatible Devices	Smartphones (up to 16.5 cm max size)
Special Features	Rotatable
Color	Black

7. WARRANTY AND SUPPORT

The iMoshion Universal Bike Mount comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, warranty claims, or any other inquiries, please contact your retailer or the iMoshion customer service department through their official website or contact channels.