

BLACK+DECKER 90609979

OEM 90609979 Replacement for Black & Decker Squeegee User Manual

Brand: BLACK+DECKER | Model: 90609979

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the OEM 90609979 Replacement Squeegee for Black & Decker products. This genuine replacement part is designed to ensure optimal performance and compatibility with your existing Black & Decker equipment. Please read this manual thoroughly before attempting any installation or use.

PRODUCT OVERVIEW

The 90609979 replacement squeegee is a genuine OEM part manufactured for Black & Decker. It is designed to replace worn or damaged squeegees on compatible Black & Decker cleaning tools.

- **Genuine, OEM Replacement Part:** Ensures perfect fit and function as per original manufacturer specifications.
- **Part Number 90609979:** Specifically designed for models requiring this part number.
- **Dimensions:** Measures approximately 5.05 inches in height, 2.50 inches in width, and 1.45 inches in depth.



Image 1: The OEM 90609979 Replacement Squeegee. This image shows the blue, textured squeegee replacement part, highlighting its material and shape.

SETUP AND INSTALLATION

Before beginning installation, ensure the Black & Decker tool is powered off and disconnected from any power source. Refer to your specific Black & Decker tool's user manual for detailed instructions on how to access and replace the squeegee component.

1. **Identify the Squeegee Location:** Locate the existing squeegee on your Black & Decker cleaning device.
2. **Remove the Old Squeegee:** Carefully detach the old squeegee. This may involve unscrewing fasteners or releasing clips. Note the orientation of the old squeegee for correct installation of the new one.
3. **Install the New Squeegee:** Align the new OEM 90609979 squeegee with the mounting points. Secure it in place using the original fasteners or by re-engaging the clips. Ensure it is firmly seated and properly aligned.
4. **Test Functionality:** After installation, perform a brief test to ensure the squeegee is correctly attached and functions as expected.

Caution: Always wear appropriate safety gear, such as gloves, during installation to prevent injury.

OPERATING INSTRUCTIONS

The OEM 90609979 squeegee is a component of a larger Black & Decker cleaning tool. Its operation is integrated with the functionality of that tool. Once installed, the squeegee will perform its intended function (e.g., wiping, drying, or collecting liquids) as part of the tool's normal operation.

- Ensure the squeegee is clean and free of debris before each use to maintain optimal performance.
- Operate your Black & Decker tool according to its specific user manual.
- Avoid applying excessive force that could damage the squeegee or the tool.

MAINTENANCE

Regular maintenance of your squeegee will extend its lifespan and ensure effective cleaning.

- **Cleaning:** After each use, rinse the squeegee with clean water to remove any residue or dirt. For stubborn grime, a mild soap solution can be used. Ensure it is thoroughly rinsed to prevent soap buildup.
- **Drying:** Allow the squeegee to air dry completely before storing to prevent mildew or odor.
- **Inspection:** Periodically inspect the squeegee for signs of wear, tears, or damage. A worn squeegee may leave streaks or reduce cleaning efficiency.
- **Storage:** Store the squeegee in a clean, dry place, away from direct sunlight or extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your squeegee, consider the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--|---|--|
| Squeegee leaves streaks | Dirty squeegee blade, worn blade, improper angle of use. | Clean the blade thoroughly. If worn, replace the squeegee. Adjust the angle of the cleaning tool during operation. |
| Squeegee not collecting liquid effectively | Improper installation, damaged blade, incorrect pressure. | Ensure the squeegee is securely installed. Inspect for damage and replace if necessary. Apply appropriate pressure as per your tool's instructions. |
| Squeegee detaches during use | Loose installation, incompatible tool. | Re-install the squeegee, ensuring all fasteners or clips are secure. Verify that this squeegee part number is compatible with your specific Black & Decker tool model. |

SPECIFICATIONS

| Attribute | Detail |
|-----------|--------------|
| Brand | BLACK+DECKER |

| Attribute | Detail |
|----------------------|--|
| Model Number | 90609979 |
| Color | Multicolor |
| Product Dimensions | 2.5"W x 5.05"H (approximately 5.05" x 2.50" x 1.45") |
| Item Weight | 0.03 Kilograms (1.06 ounces) |
| Blade Material | Stainless Steel |
| Handle Material | Plastic |
| ASIN | B09D8QJ1GS |
| Date First Available | May 14, 2018 |

WARRANTY AND SUPPORT

This OEM replacement part is typically covered by the original manufacturer's warranty for replacement parts. For specific warranty terms and conditions, please refer to the documentation provided with your original Black & Decker tool or contact BLACK+DECKER customer support directly.

For further assistance or to inquire about other replacement parts, you may visit the official BLACK+DECKER store on Amazon: [BLACK+DECKER Store](#).