Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YunLone SKE-JBP-J01

YunLone Galaxy Projector SKE-JBP-J01 User Manual

Your guide to setting up and operating your YunLone Galaxy Projector.

1. Introduction

The YunLone Galaxy Projector SKE-JBP-J01 is a versatile device designed to create a captivating aurora and star projection experience. It integrates a Bluetooth 5.0 speaker, a white noise machine, and offers multiple control options including a smart app, infrared remote, voice control, and onboard buttons. This manual provides detailed instructions for safe and effective use of your projector.



Image 1.1: YunLone Galaxy Projector with app and remote control.

2. Safety Information

- This product is designed for **indoor use only**. Do not use outdoors or in wet environments.
- The device is **not water resistant**. Avoid contact with water or other liquids.
- Keep the projector away from heat sources, direct sunlight, and flammable materials.
- Do not stare directly into the projection light source to avoid eye strain.
- Ensure the power adapter is compatible with your local voltage and current specifications.
- Keep out of reach of small children to prevent accidental damage or injury.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

3. Package Contents

Please check the package for the following items:

- YunLone Galaxy Projector (SKE-JBP-J01)
- Infrared Remote Control
- USB Power Cable (Power adapter not always included, use a standard 5V/2A USB adapter)
- User Manual

4. Product Overview

Familiarize yourself with the main components of your YunLone Galaxy Projector and its remote control.



Image 4.1: Projector components and remote control layout.

4.1 Projector Components

- **ON/OFF / WiFi / Volume / Charging Port:**Multi-function button/port for power, WiFi pairing, volume adjustment,

and power input.

- **LED Light:** The light source for aurora projection.
- **Speaker:** Integrated Bluetooth speaker for audio playback.
- **Anti-slip Rubber Pad:** Provides stability on surfaces.
- **Projector ON/OFF Button:** Controls the main projection.
- **Stars ON/OFF Button:** Controls the star projection.

4.2 Remote Control Functions

The remote control requires 1 Lithium Ion battery (not included). Insert the battery according to the polarity markings.

- **Power Button:** Turns the projector on/off.
- **8 Sound Track Button:** Cycles through white noises and lullabies.
- **Red/Green/Blue/White Light Buttons:** Directly select aurora colors.
- **Volume Up/Down:** Adjusts speaker volume.
- **Previous/Next Song:** Skips tracks during Bluetooth playback.
- **Play/Pause:** Controls media playback.
- **Aurora LED Light ON/OFF:** Toggles the aurora projection.
- **Voice Control Switch:** Activates voice control mode.
- **Flow Speed Up/Down:** Adjusts the movement speed of the aurora.
- **Brightness Adjustment:** Changes the overall projection brightness.
- **Stars ON/OFF:** Toggles the star projection.
- **Fade Mode 1/2:** Selects different fade effects for colors.
- **Bluetooth / White Noise Switch:** Toggles between Bluetooth audio and white noise modes.
- **Timer Settings (1H, 2H, 4H, Timer Off):** Sets auto-off duration.

5. Setup

5.1 Placement

Place the projector on a stable, flat surface. For optimal projection, position it in the center of the room or facing a wall/ceiling where you desire the display.

5.2 Power Connection

1. Connect the USB power cable to the charging port on the projector.
2. Plug the other end of the USB cable into a 5V/2A USB power adapter (not included) and then into a wall outlet.
3. The projector will power on automatically or can be turned on using the power button.

5.3 Remote Control Battery Installation

Open the battery compartment on the back of the remote control. Insert 1 Lithium Ion battery (not included), ensuring correct polarity. Close the compartment securely.

6. Operating Instructions

The YunLone Galaxy Projector offers four primary control methods:



Image 6.1: Four control methods for the projector.

6.1 Host Button Control

The buttons on the projector itself allow for basic control:

- Press the **ON/OFF** button to power the device on or off.
- Short press the **Volume/Pause/Bluetooth** button to cycle through functions or pause/play music.
- Long press the **Volume/Pause/Bluetooth** button to enter Bluetooth pairing mode.

6.2 IR Remote Control

Refer to Section 4.2 for a detailed overview of the remote control buttons. Point the remote directly at the projector for

effective operation.

6.3 Smart APP Control

The projector can be controlled via a dedicated smartphone application, offering advanced customization.

1. **Download the App:** Search for the 'Smart Life' or 'Tuya Smart' app in your smartphone's app store (iOS/Android).
2. **Register/Log In:** Create an account or log in to the app.
3. **Add Device:** Ensure your projector is powered on and in pairing mode (often indicated by a blinking light). In the app, tap '+' to add a device, then select 'Lighting' or 'Galaxy Projector'. Follow the on-screen instructions to connect the projector to your home Wi-Fi network (2.4GHz only).
4. **Control Functions:** Once connected, you can control lighting effects, colors, brightness, speed, music playback, white noise, and timer settings directly from the app.



Image 6.2: Smart APP control interface.

6.4 Voice Control (Alexa Compatible)

The projector is compatible with Amazon Alexa for voice commands.

1. **Enable Skill:** In the Alexa app, enable the 'Smart Life' or 'Tuya Smart' skill and link your account.
2. **Discover Devices:** Ask Alexa to discover new devices.
3. **Voice Commands:** Use commands such as:
    - "Alexa, turn on [Projector Name]."
    - "Alexa, change [Projector Name] to blue."
    - "Alexa, set [Projector Name] brightness to 50%."

6.5 Lighting Effects

The projector offers 18 lighting effects, 6 brightness levels, and 4 light moving speeds, providing over 300 patterns.

- **Color Selection:** Use the remote or app to select individual colors (Red, Green, Blue, White) or combinations.
- **Brightness Adjustment:** Adjust the overall projection brightness (10%, 40%, 70%, 100%) and star brightness (0%-100%) via remote or app.
- **Motion Speed:** Control the aurora's movement speed (fast, middle, slow, still) using the remote or app.



Image 6.3: Examples of various lighting effects.

6.6 Bluetooth Speaker

Connect your smartphone or other Bluetooth-enabled device to play music through the projector's speaker.

1. Ensure the projector is powered on.
2. Long press the **Volume/Pause/Bluetooth** button on the projector or press the Bluetooth button on the remote to enter pairing mode.

3. On your device, search for Bluetooth devices and select 'SKE-JBP-J01' (or similar name).
4. Once paired, you can play audio from your device. Use the remote or app to control volume and track selection.



Image 6.4: Projector used with Bluetooth speaker function.

6.7 White Noise Machine

The projector includes 8 soothing white noise sounds, including 3 baby lullabies.

- Press the **8 Sound Track Button** on the remote to cycle through the available sounds.
- Adjust the volume using the remote or app.



Image 6.5: Projector with white noise feature for relaxation.

6.8 Timer Function

Set an automatic shut-off timer for 1, 2, or 4 hours using the remote control or the app.

- Press the **1H, 2H, or 4H** buttons on the remote to set the desired timer.
- To cancel the timer, press the **Timer Off** button on the remote or disable it via the app.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the projector. Do not use abrasive cleaners or solvents.
- **Lens Care:** Gently clean the projection lens with a microfiber cloth to avoid scratches and maintain clear projection.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
Projector does not turn on.	No power, faulty adapter/cable.	Check power connection. Ensure adapter is 5V/2A. Try a different USB cable or adapter.
Remote control not working.	Dead battery, obstruction, out of range.	Replace remote battery. Ensure no obstructions between remote and projector. Point remote directly at the projector.
Bluetooth connection fails.	Projector not in pairing mode, device too far, interference.	Ensure projector is in Bluetooth pairing mode. Keep devices within 10 meters. Disconnect from other Bluetooth devices.
App cannot connect to projector.	Incorrect Wi-Fi band, incorrect pairing steps, network issues.	Ensure your Wi-Fi is 2.4GHz. Follow app pairing instructions carefully. Restart projector and router.
Projection is dim or unclear.	Brightness setting too low, dirty lens, ambient light.	Increase brightness via remote or app. Clean the projection lens. Reduce ambient light in the room.

9. Specifications

Feature	Detail
Brand	YunLone
Model Number	SKE-JBP-J01
Product Dimensions	4.13"D x 4.13"W x 5.59"H (10.5 cm x 10.5 cm x 14.2 cm)
Item Weight	1.1 pounds (500 Grams)
Power Source	Mains-powered (5V)
Wattage	5 watts
Light Source Type	LED
Control Methods	App, Voice (Alexa compatible), IR Remote, Host Button
Bluetooth Version	5.0
White Noise Sounds	8 (including 3 lullabies)
Timer Settings	1H, 2H, 4H
Brightness Levels	4 (10%-40%-70%-100%) for aurora, 0%-100% for stars
Motion Speeds	4 (fast-middle-slow-still)
Material	Stainless Steel (Base/Shade)

Feature	Detail
Indoor/Outdoor Usage	Indoor use only
Water Resistance Level	Not Water Resistant

10. Warranty and Support

YunLone products are manufactured with quality and care. This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. Please refer to the product packaging or contact your retailer for specific warranty terms and duration.
For technical support, troubleshooting assistance, or warranty claims, please contact YunLone customer service through the retailer's platform or visit the official YunLone website for contact information.
Customer Support: [Insert Customer Support Contact Information Here, e.g., email, website link]

© 2023 YunLone. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09D91RJG7

More documents and user manuals: **https://manuals.plus/**