

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Noma](#) /

› **NOMA St Moritz Artificial Christmas Tree 2.3m Instruction Manual Model 7217010**

Noma 7217010

NOMA St Moritz Artificial Christmas Tree 2.3m Instruction Manual

Model: 7217010 | Brand: NOMA

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- This artificial Christmas tree is designed for **indoor use only**. Do not use outdoors.
- Keep the tree away from direct heat sources, open flames, and heating appliances to prevent fire hazards.
- Ensure the tree is placed on a stable, level surface to prevent tipping.
- This product is not a toy. Keep children and pets away from the tree during assembly and ensure decorations are securely attached.
- Do not overload the tree with excessive or heavy decorations, as this may compromise its stability.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Artificial Christmas Tree Sections (typically 2-3 sections depending on height)
- Metal Swivel Stand
- Stand Screws (if applicable)

3. SETUP INSTRUCTIONS

Follow these steps to assemble your NOMA St Moritz Artificial Christmas Tree:

1. **Assemble the Stand:** Unfold the metal swivel stand and ensure it is fully extended and stable. Insert the provided screws (if any) and tighten them to secure the stand base.

2. **Insert Bottom Section:** Carefully insert the largest tree section (bottom section) into the assembled metal stand. Ensure it is firmly seated and upright.
3. **Attach Middle and Top Sections:** Continue by inserting the middle section(s) into the section below, aligning the poles. Finally, insert the top section.
4. **Fluff and Shape Branches:** The NOMA St Moritz tree features hinged branches for easy setup. Starting from the bottom, gently pull down and spread out each branch. Work your way from the trunk outwards, separating individual tips to create a full and natural appearance. Adjust the tips to fill any gaps.





The Noma St Moritz artificial Christmas tree, fully assembled and ready for decoration.



Detail of the realistic PVC and PE tips, showcasing the textured and full appearance of the branches.

4. OPERATING INSTRUCTIONS

Once assembled, your NOMA St Moritz tree is ready for use:

- **Placement:** Position the tree in your desired indoor location, ensuring it is on a flat, stable surface away from high-traffic areas where it might be knocked over.
- **Decoration:** Begin decorating your tree. Distribute ornaments and lights evenly to maintain balance and prevent stress on individual branches.
- **Lighting:** If adding lights, ensure they are suitable for indoor use and follow the light manufacturer's instructions for safe installation.

5. MAINTENANCE

Proper care will ensure the longevity of your artificial Christmas tree:

- **Cleaning:** To clean, gently dust the branches with a soft, dry cloth or use a feather duster. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Before storing, remove all decorations and lights. Disassemble the tree by reversing the setup steps. Carefully compress the branches. Store the tree sections and stand in their original packaging or a suitable storage bag/box. Keep in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Tree appears sparse:** Ensure all hinged branches are fully extended and individual tips are separated and shaped. Spend time fluffing each section thoroughly.
- **Tree is wobbly:** Verify that the metal stand is fully unfolded and all screws (if applicable) are securely tightened. Ensure the tree pole is inserted correctly and firmly into the stand. Place the tree on a completely flat and stable surface.
- **Branches not aligning:** Check that each tree section is inserted into the correct corresponding section. The sections are typically designed to fit together in a specific order (bottom, middle, top).

7. SPECIFICATIONS

Feature	Detail
Brand	Noma
Model Number	7217010
Product Dimensions (L x W x H)	33.02 x 119.38 x 38.1 cm; 12.8 kilograms
Assembly Required	Yes
Batteries Required	No
Included Parts	Metal swivel stand
Material	Polyvinyl Chloride (PVC), Polyethylene (PE), Metal

Feature	Detail
Color	Green
Recommended Product Use	Christmas Tree
Occasion	Christmas
Special Feature	Hinged branches
Seasons	Winter
Tree Type	Pine

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official NOMA website. Keep your proof of purchase for any warranty claims.