

OhO sunshine B09DCC8F8J

OhO sunshine Chameleon Fashion Audio and Sport Audio Sunglasses Kit

User Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the proper use, setup, operation, and maintenance of your OhO sunshine Chameleon Fashion Audio and Sport Audio Sunglasses Kit. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- OhO sunshine Chameleon Audio Sunglasses (1 pair)
- USB Charging Cable (1)
- Cleaning Cloth (1)
- User Manual (1)
- Protective Case (1)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your OhO sunshine Chameleon Audio Sunglasses.



Figure 3.1: Front view of the OhO sunshine Chameleon Audio Sunglasses. This image displays the overall design, featuring dark lenses and a light-colored frame, highlighting the fashion aspect of the eyewear.



Figure 3.2: Side view of the OhO sunshine Chameleon Audio Sunglasses. This perspective shows the sleek black frame, the integrated audio components within the temples, and a visible power/multi-function button on the side arm, along with regulatory markings.

The sunglasses integrate audio technology discreetly within the frame, allowing for hands-free listening and communication while providing UV protection. Key components include the lenses, frame, integrated speakers, microphone, and control buttons.

4. SETUP

4.1 Charging the Sunglasses

1. Locate the charging port on the sunglasses (typically on one of the temples).
2. Connect the provided USB charging cable to the sunglasses.
3. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The indicator light will illuminate during charging and turn off or change color when fully charged.
5. A full charge typically takes approximately 1-2 hours.

4.2 Bluetooth Pairing

1. Ensure the sunglasses are fully charged.
2. Press and hold the multi-function button (usually the power button) for 3-5 seconds until the indicator light flashes rapidly (e.g., blue and red alternately), indicating pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices. The sunglasses will appear as "OhO sunshine" or a similar name.
5. Select the sunglasses from the list to connect.
6. Once connected, the indicator light will typically stop flashing and remain solid blue or turn off. A voice prompt may confirm the connection.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until you hear a power-on prompt or see the indicator light.
- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until you hear a power-off prompt or the indicator light turns off.

5.2 Music Playback

- **Play/Pause:** Short press the multi-function button once.
- **Next Track:** Double-press the multi-function button.
- **Previous Track:** Triple-press the multi-function button.
- **Volume Control:** Use the volume buttons on the sunglasses (if present) or adjust volume directly on your paired device.

5.3 Call Management

- **Answer Call:** Short press the multi-function button once when a call comes in.
- **End Call:** Short press the multi-function button once during a call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the multi-function button when not on a call.

5.4 Voice Assistant

- **Activate Voice Assistant:** Press and hold the multi-function button for 2 seconds (when not on a call or playing music) to activate your device's voice assistant (Siri, Google Assistant, etc.).

6. MAINTENANCE

6.1 Cleaning

- Use the provided cleaning cloth to gently wipe the lenses and frame.
- For stubborn smudges, use a lens cleaning spray specifically designed for eyewear. Do not use harsh chemicals or abrasive materials.
- Avoid getting water directly into the electronic components.

6.2 Storage

- When not in use, store the sunglasses in their protective case to prevent scratches and damage.
- Avoid exposing the sunglasses to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.

6.3 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the sunglasses regularly, even if not in frequent use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cannot power on	Low battery	Charge the sunglasses fully.

Problem	Possible Cause	Solution
Cannot pair with device	Sunglasses not in pairing mode; Bluetooth off on device; device too far.	Ensure sunglasses are in pairing mode. Turn on Bluetooth on your device. Move device closer to sunglasses. Forget previous pairings on device and try again.
No sound	Volume too low; not connected; audio source issue.	Increase volume on sunglasses and device. Reconnect Bluetooth. Check audio playback on your device.
Intermittent connection	Interference; device too far; low battery.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Keep device within range. Charge sunglasses.

8. SPECIFICATIONS

- **Model:** B09DCC8F8J
- **Brand:** OhO sunshine
- **Color:** Black
- **Connectivity:** Wireless (Bluetooth)
- **Manufacturer:** OhO sunshine
- **Date First Available:** August 23, 2021
- **Features:** Audio playback, Call management, UV protection

9. WARRANTY AND SUPPORT

OhO sunshine products are designed for quality and reliability. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official OhO sunshine website. Please retain your proof of purchase for warranty claims.

For further assistance, you may visit the OhO sunshine store on Amazon: [OhO sunshine Amazon Store](#)