

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vacmaster](#) /

› [Vacmaster 1500W 18L Wet & Dry Vacuum Cleaner User Manual](#)

Vacmaster VWM1518R-03

Vacmaster VWM1518R 1500W 18L Wet & Dry Vacuum Cleaner

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the Vacmaster VWM1518R 1500W 18L Wet & Dry Vacuum Cleaner. This powerful and versatile appliance is designed for efficient cleaning of both wet and dry debris in various environments, including homes, garages, workshops, and gardens. Please read this manual thoroughly before operating the vacuum cleaner to ensure safe and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not leave the vacuum cleaner unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without filters in place.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental

capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Carefully unpack your Vacmaster VWM1518R and ensure all items are present and undamaged. If any items are missing or damaged, please contact customer service.

- Vacmaster VWM1518R Wet & Dry Vacuum Cleaner Unit
- Flexible Hose (7m with remote control)
- Extension Wands
- Crevice Tool
- Utility Nozzle
- Floor Nozzle
- Round Dusting Brush
- Cartridge Filter
- Foam Filter (for wet vacuuming)
- Wall Mount Bracket
- Accessory Storage Bag
- User Manual

Date du calcul	Suzhou Cleva Electric Appliance Co. Ltd. Please fill CN, 215000, Jiangsu, Suzhou, Suzhou Industrial Park, No.8 wei zheng luout					
Nom ou marque commerciale du fournisseur	VWM1518R 03					
Adresse du fournisseur	20-12-2022					
Référence du modèle donnée par le fournisseur						
Critère	Sous-critère	Note du sous-critère sur 10	Coefficient du sous critère	Note du critère sur 20	Total des notes des critères sur 100	
CRITÈRE 1 : DOCUMENTATION	1.1 Durée de disponibilité de la documentation technique et relative aux conseils d'utilisation et d'entretien	6.9	2	13.7	51.1	
CRITÈRE 2 : DÉMONTABILITÉ, ACCÈS, Outils, FIXATIONS	2.1 Facilité de démontage des pièces de la liste 2*	10.0	1	17.0		
	2.2 Outils nécessaires (liste 2)	9.0	0.5			
	2.3 Caractéristiques des fixations entre les pièces de la liste 1** et de la liste 2	5.0	0.5			
CRITÈRE 3 : DISPONIBILITÉ DES PIÈCES DÉTACHÉES	3.1 Durée de disponibilité des pièces de la liste 2	0	1	4.3		
	3.2 Durée de disponibilité des pièces de la liste 1	0	0.5			
	3.3 Délais de livraison des pièces de la liste 2	10.0	0.3			
	3.4 Délais de livraison des pièces de la liste 1	6.7	0.2			
CRITÈRE 4 : PRIX DES PIÈCES DÉTACHÉES	4. Rapport prix des pièces de la liste 2 sur prix de l'équipement neuf	4.0	2	8.0		
CRITÈRE 5 : CRITÈRE	5.1 Assistance à distance sans frais	4.0	2	8.0		
Note de l'indice sur 10					5.1	

Figure 3.1: All included accessories for the Vacmaster VWM1518R vacuum cleaner, including various nozzles, brushes, filters, and the wall mount.

4. SETUP

4.1 Assembly

- Filter Installation:** For dry vacuuming, ensure the cartridge filter is securely installed over the filter cage. For wet vacuuming, remove the cartridge filter and install the foam filter.
- Hose Connection:** Insert the flexible hose into the vacuum port on the front of the unit until it clicks into place.
- Accessory Attachment:** Attach the desired extension wands and nozzle to the end of the hose.



Figure 4.1: The Vacmaster VWM1518R vacuum cleaner shown with its main unit, hose, and various attachments, illustrating its complete setup.

4.2 Wall Mounting (Optional)

The Vacmaster VWM1518R can be conveniently wall-mounted to save space and provide easy access.

- Choose Location:** Select a sturdy wall surface near a power outlet, ensuring sufficient clearance around the unit.
- Install Bracket:** Use appropriate hardware (not included) to securely fasten the wall mount bracket to the wall. Ensure it is level and can support the weight of the vacuum cleaner.
- Mount Vacuum:** Carefully lift the vacuum cleaner and slide it onto the wall mount bracket until it locks into place.



Figure 4.2: A man demonstrating the ease of removing the Vacmaster VWM1518R vacuum cleaner from its wall-mounted bracket, highlighting its convenient storage solution.




Figure 4.3: A man vacuuming the interior of a car, with the Vacmaster VWM1518R conveniently wall-mounted in the background, showcasing its practical use in a garage setting.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off and Remote Control

Plug the power cord into a suitable electrical outlet. The Vacmaster VWM1518R features a remote control on the hose for convenient operation.

- Press the **ON/OFF** button on the remote control to start or stop the vacuum cleaner.
- The remote control allows you to operate the unit without needing to reach the main power switch on the vacuum body.



Figure 5.1: A close-up view of the remote control integrated into the hose handle of the Vacmaster VWM1518R, showing the power buttons for convenient operation.

5.2 Dry Vacuuming

For dry vacuuming, ensure the cartridge filter is installed. Use appropriate nozzles for different surfaces.

- Attach the desired nozzle (e.g., floor nozzle for large areas, crevice tool for tight spaces).
- Turn on the vacuum cleaner using the remote control.
- Move the nozzle over the dry debris to be collected.

5.3 Wet Vacuuming

For wet vacuuming, remove the cartridge filter and install the foam filter. Do not use the cartridge filter for wet pickup.

- Attach the utility nozzle or floor nozzle.
- Turn on the vacuum cleaner.

- Slowly move the nozzle over the liquid spill. The vacuum will automatically shut off when the tank is full.
- Empty the tank immediately after wet pickup.



Figure 5.2: A man using the Vacmaster VWM1518R to vacuum liquid from an outdoor drain, demonstrating its wet pickup capability.

5.4 Blower Function

The Vacmaster VWM1518R also functions as a powerful blower, ideal for clearing leaves or debris from outdoor areas.

1. **Connect Hose to Blower Port:** Locate the blower port on the rear of the vacuum cleaner. Insert the flexible hose into this port.
2. **Attach Nozzle:** Attach a suitable nozzle (e.g., utility nozzle) to the end of the hose.
3. **Activate Blower:** Turn on the vacuum cleaner using the remote control. Air will now exit through the hose, functioning as a blower.




Figure 5.3: A man operating the Vacmaster VWM1518R in blower mode, effectively clearing fallen leaves from a paved outdoor area.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your vacuum cleaner.

6.1 Emptying the Tank

Always unplug the vacuum cleaner before emptying the tank.

- Release the latches on the side of the tank and lift off the motor head.
- Carefully empty the collected debris or liquid into a suitable receptacle.
- Clean the inside of the tank with water and mild detergent if necessary, then dry thoroughly.
- Replace the motor head and secure the latches.

6.2 Filter Cleaning and Replacement

Clean or replace filters regularly to maintain suction power.

- **Cartridge Filter (Dry Use):** Tap off loose dust. For thorough cleaning, rinse under running water. Allow to air dry completely before re-installing. Replace if damaged or excessively dirty.
- **Foam Filter (Wet Use):** Rinse with water and mild soap. Squeeze out excess water and allow to air dry completely before storage or re-use.

7. TROUBLESHOOTING

If you encounter issues with your Vacmaster VWM1518R, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	No power supply. Remote control battery low.	Check power cord connection and outlet. Replace remote control batteries.
Low suction power.	Clogged filter. Full tank. Hose or nozzle blockage.	Clean or replace filter. Empty the tank. Check and clear any blockages in hose or nozzle.
Motor shuts off during wet pickup.	Tank is full.	Empty the tank. This is a safety feature.
Unusual noise.	Foreign object in impeller. Loose component.	Unplug and inspect for foreign objects. Check all connections and ensure components are secure.



8. SPECIFICATIONS


Feature	Specification
Model Number	VWM1518R-03
Power	1500 W
Tank Capacity	18 Litres
Hose Length	7 meters
Voltage	1500 Volts (likely refers to motor power, not electrical voltage)
Noise Level	70 dB
Product Dimensions (L x W x H)	49 x 41 x 55 cm
Item Weight	10 Kilograms
Special Feature	Wet/Dry, Blower Function, Remote Control, Wall Mountable

9. WARRANTY AND SUPPORT

Vacmaster products are manufactured to high-quality standards. For warranty information, technical support, or to order replacement parts, please refer to the contact information provided on the Vacmaster official website or your purchase documentation. Please have your model number (VWM1518R-03) and purchase date ready when contacting support.

Related Documents - VWM1518R-03

	<p>Vacmaster VQ1530SFDC Wet and Dry Vacuum Cleaner Operator's Manual</p> <p>Comprehensive operator's manual for the Vacmaster VQ1530SFDC 1500W 30L wet and dry vacuum cleaner, including safety instructions, specifications, assembly, operation (dry, wet, blowing), maintenance, and troubleshooting.</p>
	<p>Vacmaster VQ1530SFDC Wet and Dry Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Vacmaster VQ1530SFDC 30L 1500W wet and dry vacuum cleaner, covering safety, assembly, operation, maintenance, troubleshooting, and technical specifications.</p>
	<p>Vacmaster VOC1218PF-01 18L 1250W Wet & Dry Vacuum Cleaner User Manual</p> <p>This document provides comprehensive instructions for the Vacmaster VOC1218PF-01 18L 1250W Wet & Dry Vacuum Cleaner, covering safety information, unpacking, assembly, operation, maintenance, troubleshooting, and technical data.</p>
	<p>Vacmaster VDK1538SWC Wet & Dry Vacuum Cleaner Instruction Manual</p> <p>Comprehensive instruction manual for the Vacmaster VDK1538SWC wet and dry vacuum cleaner, covering assembly, operation, safety, maintenance, and troubleshooting for optimal performance.</p>
	<p>Vacmaster VQ1530SFDC Wet and Dry Vacuum Cleaner: Powerful 30L 1500W Shop Vac</p> <p>Explore the Vacmaster VQ1530SFDC, a versatile 30L 1500W wet and dry vacuum cleaner designed for effective cleaning of liquids and dry debris. This comprehensive user manual provides essential safety information, assembly instructions, operation guidelines, maintenance tips, and troubleshooting solutions for optimal performance and longevity.</p>



[Vacmaster VJF608PF 0201 6 Gallon Wet/Dry Vacuum Operator's Manual](#)

Operator's manual for the Vacmaster VJF608PF 0201 6 Gallon Wet/Dry Vacuum, covering safety instructions, assembly, operation, maintenance, and troubleshooting.