

Sauder 427417

Sauder Dawson Trail Lift-Top Coffee Table User Manual

Model: 427417 | Brand: Sauder

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Sauder Dawson Trail Lift-Top Coffee Table. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. This coffee table features a lift-top surface, hidden storage, and open shelving, designed for versatile use in your living space.

SAFETY INFORMATION

Adhering to these safety guidelines is crucial for preventing injury and damage to the product.

- **Lifting:** Always lift with your legs, not your back, when handling components during assembly or moving the assembled table.
- **Stability:** Ensure the table is stable and securely assembled before placing items on it or using the lift-top mechanism.
- **Assembly:** Follow all assembly instructions carefully. Improper assembly can lead to instability and potential injury.
- **Weight Limit:** Do not exceed the specified weight limit for the lift-top mechanism or any shelves. Overloading can cause damage or collapse.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow them to play on or around the table, especially when the lift-top is in motion.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the separate assembly guide for a detailed list of components and hardware. If any parts are missing or damaged, contact Sauder customer support.

SETUP AND ASSEMBLY

Assembly of the Sauder Dawson Trail Lift-Top Coffee Table is designed to be quick and easy, featuring slide-on moldings for efficient construction.

1. **Preparation:** Clear a spacious, clean area for assembly. Lay out all components on a soft, non-abrasive surface to prevent scratches.
2. **Tools Required:** A screwdriver is recommended for assembly.
3. **Follow Instructions:** Refer to the detailed assembly instructions provided in the separate assembly guide included with your product. Follow each step sequentially.
4. **Secure Connections:** Ensure all screws, fasteners, and slide-on moldings are securely tightened before moving or using the table.



Image: The Sauder Dawson Trail Lift-Top Coffee Table positioned in a living room, showcasing its design and functionality.

OPERATING INSTRUCTIONS

Lift-Top Mechanism

The coffee table features a lift-top surface that can be raised and extended forward to create a convenient workspace or dining surface.

1. **To Lift:** Gently grasp the front edge of the tabletop and lift upwards. The mechanism will smoothly extend the top upwards and forwards.
2. **To Lower:** Carefully push the tabletop downwards and backwards. Guide it slowly until it rests securely in its closed position. Avoid letting it drop suddenly.
3. **Usage:** The lifted top provides a stable surface for activities such as working on a laptop, eating, or crafting while seated on a sofa.



Image: The coffee table with its lift-top mechanism fully extended, displaying a laptop and other items on the raised surface.

Storage Compartments

- **Hidden Storage:** Beneath the lift-top surface, a hidden compartment is available for discreetly storing items such as blankets, board games, books, or remote controls.
- **Open Shelving:** The lower section of the table features open shelves, ideal for displaying decorative items, storing organizing bins, or keeping frequently accessed items within reach.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your coffee table.

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the Raven Oak finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood.
- **Heat and Moisture:** Protect the surface from extreme heat and moisture. Use coasters under beverages and heat pads under hot items.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten

as necessary.

TROUBLESHOOTING

If you encounter any issues with your Sauder Dawson Trail Lift-Top Coffee Table, consider the following common solutions:

- **Lift-Top Mechanism Sticking:** Ensure no objects are obstructing the mechanism. Check that all assembly screws related to the lift-top are properly tightened.
- **Table Instability:** Verify that the table is placed on a level surface. Recheck all assembly fasteners and tighten any that are loose.
- **Scratches or Dents:** For minor cosmetic damage, touch-up pens or furniture repair kits matching the Raven Oak finish may be used.

For persistent issues or concerns not addressed here, please contact Sauder customer support.

SPECIFICATIONS




Image: Detailed diagram illustrating the dimensions of the Sauder Dawson Trail Lift-Top Coffee Table, including overall and compartment measurements.

Feature	Detail
Brand	Sauder
Model Name	Dawson Trail
Model Number	427417
Product Dimensions (L x W x H)	43.15" x 19.45" x 19.02" (109.6 cm x 49.4 cm x 48.3 cm)
Color	Raven Oak Finish
Material Type	Engineered Wood
Item Weight	66 Pounds (29.9 kg)

Feature	Detail
Table Design	Lift-Top Coffee Table with Open Shelf
Tools Recommended For Assembly	Screwdriver
Indoor/Outdoor Usage	Indoor

WARRANTY INFORMATION

This Sauder product is covered by a **5-year limited warranty**. This warranty covers parts and manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or visit the official Sauder website.

CUSTOMER SUPPORT

If you have any questions regarding assembly, operation, missing parts, or warranty claims, please contact Sauder customer support. Contact information can typically be found on the Sauder website or on the packaging materials.

Online Resources: Visit the official Sauder website for additional product information, FAQs, and support resources.