

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Vinsetto](#) /

› [Vinsetto Electric Height Adjustable Standing Desk \(Model 920-072V81\) Instruction Manual](#)

Vinsetto 920-072V81

Vinsetto Electric Height Adjustable Standing Desk

MODEL: 920-072V81

Introduction

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your Vinsetto Electric Height Adjustable Standing Desk. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: Vinsetto Electric Height Adjustable Standing Desk

Safety Information

Caution:

- To prevent potential hazards, ensure the desk's 'Anti-Collision System' is functioning properly to avoid collisions with other furniture or objects while adjusting.
- Do not overload the desk beyond its weight capacity of 154 lbs (70 kg) to avoid overheating and damage.
- Always follow the assembly instructions and securely anchor the desk if required.
- Keep children and pets away from the desk during operation.
- Ensure all cables are properly managed to prevent tripping hazards or damage during height adjustments.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (Main and L-shaped extension)
- Desk Legs (2)
- Support Beams (Horizontal bars)
- Electric Motor and Control Box
- Control Panel with Memory Buttons
- Adjustable Foot Pads
- Headphone Hook
- Cable Management Tray/Clips
- Assembly Hardware (Screws, Allen wrenches, etc.)
- Power Adapter and Cable



Figure 2: Desk components laid out for assembly.

Setup Instructions

Follow these steps carefully for proper assembly. While the video below demonstrates assembly for a similar L-shaped desk, the general principles and component connections apply to your 54" model.

1. **Assemble Desktop Panels:** Connect the main desktop panels using the provided dowels and fasteners. Ensure they are securely aligned.
2. **Attach Desk Legs:** Secure the desk legs to the desktop frame using the designated screws. Ensure the motor is correctly positioned on one of the legs.
3. **Install Support Beams:** Attach the horizontal support beams between the legs. Pay attention to the orientation of the middle hole for the sync rod.
4. **Connect Sync Rod:** Insert the retractable end of the sync rod into the hole of the leg without the motor. Connect the other end to the metal rod of the leg with the motor. Ensure the small black screws on the sync rod accessory are facing upwards. If not, turn the sync rod as shown in the video.

5. **Secure All Screws:** Double-check that all screws are tightened before proceeding.
6. **Install Cable Management and Accessories:** Attach the cable management tray and headphone hook to the underside of the desktop.
7. **Connect Control Panel and Power:** Connect the control panel and power adapter to the control box. Route cables neatly using the cable management features.
8. **Flip the Desk:** With assistance, carefully flip the assembled desk upright.

Your browser does not support the video tag.

Video 1: General Assembly Guide for an L-shaped Electric Standing Desk. The assembly process is similar for the Vinsetto 54" model.

SIT-STAND WORKING EXPERIENCE




Figure 3: Desk dimensions for planning your workspace.

Operating Instructions

Your Vinsetto Electric Height Adjustable Standing Desk features intuitive controls for seamless height adjustments and personalized settings.

Height Adjustment

Use the **Up (▲)** and **Down (▼)** buttons on the control panel to raise or lower the desk to your desired height. The LED display will show the current height.

Memory Presets

The desk offers 4 memory preset options to save your preferred sitting and standing heights:

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the '**M**' button (or similar memory set button, if present) followed by one of the numbered preset buttons (1, 2, 3, or 4). The display will confirm the setting.
3. To recall a saved height, simply press the corresponding numbered preset button.

Anti-Collision System

The integrated anti-collision system is designed to prevent damage by stopping the desk's movement if it encounters an obstacle during adjustment. If the desk stops unexpectedly, check for obstructions and clear them before resuming operation.



Figure 4: Smart Control Panel for height adjustment and memory presets.

ELEGANT WORKSPACE

The 54" x 24" size work area provides enough space



Figure 5: Anti-Collision System in action.

Your browser does not support the video tag.

Video 2: General demonstration of an electric standing desk's height adjustment and features.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your standing desk.

- **Cleaning:** Wipe the desk surfaces with a damp or dry cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and reorganize cables to prevent tangling or interference with the desk's movement.
- **Screw Tightness:** Every few months, check all assembly screws and tighten them if necessary to maintain stability.

- **Motor Inspection:** Ensure the motor and moving parts are free from dust and debris. Do not attempt to lubricate internal motor components.



Figure 6: Single electric motor for smooth height adjustments.

Troubleshooting

If you encounter issues with your desk, refer to the following common solutions:

- **Desk Not Moving:** Check all power connections. Ensure the power adapter is securely plugged into both the wall outlet and the control box.
- **Error Code on Display:** Refer to the specific error code in the full user manual (if provided separately) or contact customer support. Often, a power cycle (unplugging and replugging) can resolve minor electronic glitches.
- **Anti-Collision System Triggering Frequently:** Ensure there are no objects in the path of the desk's movement. The system's sensitivity might be adjustable in some models; consult the full manual for details.
- **Unstable or Wobbly Desk:** Check that all assembly screws are tight. Ensure the adjustable foot pads are

properly leveled on an even floor.

Specifications

Brand	Vinsetto
Model Number	920-072V81
Overall Dimensions	53.25"L x 23.5"W x 28.25"-45.75"H
Desktop Size	54" L
Height Adjustment Range	28.25" to 45.75"
Weight Capacity	154 lbs (70 kg)
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Special Feature	Electric, Memory Presets, Anti-Collision System
Item Weight	57.9 Pounds

Warranty and Support

This Vinsetto Electric Height Adjustable Standing Desk comes with a **Limited Warranty**. The manufacturer's warranty for parts and labor is **90 Days** from the date of purchase.

For warranty claims, technical assistance, or to report missing/damaged parts, please contact Vinsetto customer support through your retailer or the official Vinsetto website. Please have your model number (920-072V81) and proof of purchase ready.