

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aresrora](#) /

› [Aresrora M020/V7 Portable Bluetooth Speaker User Manual](#)

Aresrora M020 or V7

Aresrora M020/V7 Portable Bluetooth Speaker User Manual

Model: M020 or V7 | Brand: Aresrora

INTRODUCTION

Thank you for purchasing the Aresrora M020/V7 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

IMPORTANT SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for any repairs.
- Keep the speaker away from water and liquids. While it is indicated as waterproof, prolonged submersion or exposure to strong jets of water should be avoided.
- Use only the provided charging cable or a certified 5V charger.
- Dispose of the battery and speaker according to local regulations.

PACKAGE CONTENTS

Please check the box for the following items:

- Aresrora M020/V7 Portable Bluetooth Speaker
- Charging Cable
- Nylon Rope
- User Manual

PRODUCT OVERVIEW



Figure 1: Aresrora M020/V7 Portable Bluetooth Speaker (Red)



Figure 2: Top Control Panel

Button Functions:

- **Power Button (Center):**
 - Press and hold to power on/off the speaker.
 - Click to connect to another M020 or V7 speaker for True Wireless Stereo (TWS) pairing.
- **"+" Button:**
 - Long press to increase volume.
 - Click to skip to the next track.
- **"-" Button:**
 - Long press to decrease volume.
 - Click to go to the previous track.

SETUP GUIDE

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and a 5V USB power adapter (not included). The charging indicator light will show charging status. A full charge takes approximately 1.5 hours and provides up to 6 hours of playtime.




Figure 3: Battery Life Indication

2. Powering On/Off

Press and hold the power button (center button) for a few seconds until you hear an audible prompt or see the indicator light illuminate, indicating the speaker is powering on or off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "M020" or "V7" from the list of devices.
4. Once paired, the speaker will emit a confirmation sound, and the indicator light will stop flashing.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.



Bluetooth 5.0

Wide compatibility, stable connection

Figure 4: Bluetooth 5.0 Connectivity

4. True Wireless Stereo (TWS) Pairing (Optional)

To achieve a stereo sound experience, you can pair two M020 or V7 speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one of the speakers, click the power button once. The speakers will attempt to pair with each other.
3. Once successfully paired, you will hear a confirmation sound.
4. Now, connect your device to one of the speakers via Bluetooth as described in step 3. Both speakers will play audio in stereo.



Figure 5: True Wireless Stereo Pairing

OPERATING INSTRUCTIONS

1. Playing Audio via Bluetooth

After successfully pairing your device, open your preferred music application and begin playback. Audio will stream wirelessly to the speaker.

2. Playing Audio via TF Card

Insert a TF (MicroSD) card loaded with MP3 audio files into the TF card slot on the speaker. The speaker will automatically detect the card and begin playing music. Use the '+' and '-' buttons to navigate tracks.

3. Hands-Free Calling

When connected to your smartphone via Bluetooth, the speaker can be used for hands-free calls. The built-in microphone allows for clear communication.

- **Answer/End Call:** Press the power button once.
- **Reject Call:** Press and hold the power button.

Hands Free Call



Figure 6: Hands-Free Calling

4. Volume Control and Track Navigation

- **Volume Up:** Long press the "+" button.
- **Volume Down:** Long press the "-" button.
- **Next Track:** Click the "+" button.
- **Previous Track:** Click the "-" button.

MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port and TF card slot are free from dust and debris.
- Store the speaker in a cool, dry place when not in use.
- If the speaker will not be used for an extended period, charge it periodically to maintain battery health.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the charging cable.
Cannot pair with Bluetooth device.	<ul style="list-style-type: none">Ensure the speaker is in pairing mode (flashing indicator light).Make sure Bluetooth is enabled on your device.Move the speaker closer to your device (within 10 meters).Forget the device from your phone's Bluetooth settings and try pairing again.Ensure no other devices are connected to the speaker.
No sound or low volume.	<ul style="list-style-type: none">Increase the volume on both the speaker and your connected device.Ensure the speaker is properly paired.Check if the audio source is playing.
Sound cutting in and out.	<ul style="list-style-type: none">Move the speaker closer to your device.Avoid obstacles between the speaker and your device.Ensure there is no interference from other wireless devices.Charge the speaker if the battery is low.
TF card not playing.	<ul style="list-style-type: none">Ensure the TF card is inserted correctly.Verify that the audio files on the card are in a supported format (e.g., MP3).Try another TF card to rule out card issues.

SPECIFICATIONS

Model Name	M020 or V7
Brand	Aresrora
Connectivity Technology	Bluetooth, TF Card
Bluetooth Version	5.0
Bluetooth Range	Up to 10 meters (33 feet)
Speaker Output Power	5 Watts
Battery Capacity	500 mAh Lithium Polymer
Play Time	Up to 6 hours
Charging Time	Approx. 1.5 hours
Input Voltage	5 Volts
Item Weight	3.1 ounces
Product Dimensions	1.96"D x 1.96"W x 1.96"H
Material	Metal, Plastic

Waterproof	Yes
Special Features	Built-in Microphone, Portable, Stereo Pairing, TF Card Playback

WARRANTY AND SUPPORT

The Aresrora M020/V7 Portable Bluetooth Speaker comes with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or contact Aresrora customer support.

If you encounter any issues or have questions not covered in this manual, please contact our customer support team for assistance.

© 2023 Aresrora. All rights reserved.