

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SLOPEHILL](#) /

› [SLOPEHILL Dog Training Collar User Manual](#)

SLOPEHILL 880

SLOPEHILL Dog Training Collar User Manual

Model: 880

Brand: SLOPEHILL

INTRODUCTION

This SLOPEHILL Dog Training Collar is designed to assist in effective dog training, offering 7 distinct training modes to help correct various behavioral issues and teach basic commands. The system includes a remote transmitter and a waterproof receiver collar, suitable for small, medium, and large dogs.



Image: The SLOPEHILL Dog Training Collar system, showing the remote transmitter and the receiver collar.

SETUP GUIDE

1. Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. The remote typically lasts for up to 45 days, and the receiver for up to 15 days on a full charge. Ensure the silicone plug of the charging port on the receiver is tightened after charging to maintain water resistance.

Long-Lasting Battery Life



Remote Last For:

45 Days



Receiver Last For:

15 Days



Image: The remote and receiver collar connected to charging cables, illustrating the long-lasting battery life.

2. Attaching the Collar and Contact Points

The collar strap is adjustable from 8 to 26 inches, fitting dogs from 8 to 140 lbs. For dogs over 20 pounds or older than 3 months, the shock training function can be used. Ensure the collar fits snugly but comfortably, allowing one finger to fit between the collar and your dog's neck. Install the silicone points onto the contact prongs to make them softer and more comfortable for your dog.

1 Remote 3 Channels

Supports maximum 3 dogs training with only 1 remote transmitter





Image: A diagram illustrating the correct fit of the collar and the use of safe conductive silicone prongs.

If your dog has long or thick hair, it may be necessary to slightly shave the hair around the contact points on the neck to ensure proper contact and effectiveness of the training functions.

3. Pairing the Remote and Receiver

Refer to the specific pairing instructions included in your product packaging. Typically, this involves turning on both devices and pressing a pairing button on the receiver while the remote is in pairing mode. Once paired, the devices will communicate for training.

OPERATING INSTRUCTIONS

The SLOPEHILL Dog Training Collar offers 7 distinct training modes:

- **Beep Mode:** Provides an audible tone.
- **Vibration Mode:** Delivers a gentle vibration.
- **Low Shock Level (0-50):** Adjustable static stimulation for mild correction.
- **High Shock Level (51-99):** Adjustable static stimulation for stronger correction.
- **Shock Lock Mode:** Disables the shock function, allowing only beep and vibration modes.
- **Light Mode:** Activates a light on the collar for visibility in low light conditions.
- **Keypad Lock Mode:** Prevents accidental button presses on the remote.

7 Training Modes

Correct Dog's Bad Behaviors in Time










 Beep	 Vibration	 Shock Lock	 Keypad lock
 Low shock (0-50)	 High shock (51-99)	 Anti-lost Light	

Image: Visual representation of the 7 training modes available on the collar.

Remote Control Range

The remote control has an ultra-long range of up to 2600 feet, allowing for effective training over significant distances.

2600Ft Remote Control Range

Ultra Long Distance



Image: An illustration demonstrating the 2600ft remote control range of the training collar.

Using the Anti-Lost Light

The collar features an anti-lost light that can be activated from the remote. This light helps you easily find and locate your dog at night, improving visibility and safety during evening walks or outdoor activities.

Anti-lost Light

Easily find and locate your dogs at night



Anti-lost Light
Easily find and locate your dogs at night

Take care at night:
Stay visible and avoid vehicles and bicycles

Image: A visual showing the anti-lost light feature on the collar, useful for night visibility.

Official Product Video: Dog Training Collar with Remote

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the SLOPEHILL Dog Training Collar with Remote.

MAINTENANCE

Collar Wear Time

Important: Do not leave the collar on your dog for more than 8 hours per day!

Prolonged wear can lead to skin irritation. Reposition the receiver on your pet's neck every 1 to 2 hours to prevent pressure sores.

Water Resistance

The receiver collar is 100% water-resistant (IP68 rated), allowing your dog to wear it during swimming, bathing, raining, and other outdoor activities. However, the remote transmitter is NOT water-resistant and should be kept dry.

IP68 Waterproof Receiver Collar

Note: Remote is not waterproof



Swimming



Bathing



Raining



Splashing

Image: A golden retriever swimming, demonstrating the IP68 waterproof capability of the receiver collar.

Cleaning and Care

Regularly inspect the collar and contact points for any signs of wear or irritation on your dog's skin. Clean the collar and receiver with a damp cloth as needed. Ensure the charging port is sealed when not charging to maintain water resistance.

TROUBLESHOOTING

Collar Not Responding to Remote

- Ensure both the remote and receiver are fully charged.
- Verify that the remote and receiver are properly paired. If not, re-pair them according to the setup instructions.
- Check if the keypad lock or shock lock modes are active on the remote. Deactivate them if necessary.
- Ensure the collar is making proper contact with your dog's skin. Trim hair if it's too long or thick around the contact points.
- Confirm you are within the 2600ft operating range.

Battery Drains Quickly

- Ensure both devices are fully charged before use.
- Frequent use of high-intensity modes (e.g., high shock) can consume more battery.
- Check for any signs of damage to the charging cables or ports.

Skin Irritation on Dog's Neck

- Do not leave the collar on for more than 8 hours per day.
- Reposition the collar every 1-2 hours to prevent prolonged pressure on one spot.
- Ensure the collar is not too tight. It should allow one finger to fit comfortably underneath.
- Clean the contact points and your dog's neck regularly.
- If irritation persists, discontinue use and consult a veterinarian.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand Name	SLOPEHILL
Model Name	880
Item Weight	10.2 ounces
Item Dimensions (LxWxH)	6.9 x 4.3 x 0.1 inches
Collar Length	8 - 26 inches (Adjustable)
Fits Dogs Weight	8 - 140 lbs
Shock Function Age/Weight Restriction	Dogs over 3 months old or weighing over 20 lbs

Remote Control Range	2600 feet
Receiver Water Resistance	IP68 (100% water-resistant)
Remote Water Resistance	Not water-resistant
Battery Type	2 CR123A batteries (included)
Included Components	Remote Control, Receiver, Leash
Material	Nylon
Country of Origin	China

WARRANTY INFORMATION

This product comes with a **1-year manufacturer warranty**. Please retain your proof of purchase for warranty claims. For details on warranty coverage and claims, refer to the documentation included with your product or contact customer support.

CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your SLOPEHILL Dog Training Collar, please reach out to our customer service team. We offer multi-channel service including email, phone, and live chat, with 24-hour friendly customer support available 7 days a week.

Contact information can typically be found in the user manual included in your product packaging or on the official SLOPEHILL website.



Image: An icon representing customer service availability.