

[Manuals.plus](#) /

› [KRUPS](#) /

› KRUPS Nespresso Inissia Capsule Container Instruction Manual

## KRUPS XN100, XN1001, XN1007

# KRUPS Nespresso Inissia Capsule Container Instruction Manual

Model: XN100, XN1001, XN1007 Series

## INTRODUCTION

This manual provides essential information for the proper use and maintenance of your KRUPS Nespresso Inissia Capsule Container. This container is designed as a direct replacement or spare part for KRUPS C40 and D40 Series Nespresso coffee machines, including Inissia models XN100, XN1001, and XN1007. It serves to collect used coffee capsules during the brewing process, ensuring a clean and efficient operation of your machine.

## INSTALLATION

The capsule container is designed for easy installation and removal. Follow these steps to correctly install the container into your compatible Nespresso machine:

1. **Preparation:** Ensure your Nespresso machine is turned off and unplugged from the power outlet before installation.
2. **Locate the Slot:** Identify the designated slot for the used capsule container within your Nespresso Inissia C40 or D40 series machine. This is typically located behind the brewing unit.
3. **Insert the Container:** Gently slide the KRUPS Nespresso Capsule Container into the slot. Ensure it is oriented correctly, with the opening facing the capsule ejection mechanism. The container should slide in smoothly and sit securely in place.
4. **Verify Fit:** Once inserted, the container should fit snugly without excessive force. If it does not fit, double-check the orientation and ensure it is the correct model for your machine.



*Image: Side view of the KRUPS Nespresso Inissia Capsule Container, showing its shape designed for machine integration.*

## OPERATION

Once installed, the capsule container operates automatically as part of your Nespresso machine's brewing cycle:

- **Capsule Ejection:** After each coffee preparation, the used Nespresso capsule will be automatically ejected from the brewing unit and fall into this container.
- **Capacity:** The container is designed to hold multiple used capsules before needing to be emptied. The exact capacity may vary slightly depending on the capsule size and machine model, but it typically holds around 9-11 used capsules.
- **Full Indicator:** Some Nespresso machines may have an indicator or a noticeable change in operation when the capsule container is full. Refer to your coffee machine's manual for specific details.



*Image: Top view of the KRUPS Nespresso Inissia Capsule Container, showing the slotted design for capsule collection.*

## MAINTENANCE AND CLEANING

---

Regular cleaning of the capsule container is essential to maintain hygiene and ensure optimal performance of your coffee machine. Follow these cleaning guidelines:

1. **Emptying:** When the container is full, or at least once a day if the machine is used frequently, carefully remove it from the machine. Dispose of the used coffee capsules responsibly.
2. **Rinsing:** Rinse the container thoroughly under warm running water. Use a mild dish soap if necessary to remove any coffee residue or stains.
3. **Cleaning Tools:** For stubborn residue, a soft brush or sponge can be used. Avoid abrasive cleaners or scouring pads, as these can scratch the plastic surface.
4. **Drying:** Allow the container to air dry completely before reinserting it into the machine. Alternatively, wipe it dry with a clean, soft cloth.
5. **Frequency:** Clean the capsule container regularly, ideally after every few uses or whenever it is emptied, to prevent mold growth and unpleasant odors.

## Troubleshooting

While the capsule container is a simple component, here are some common issues and their solutions:

| Problem                                           | Possible Cause                                       | Solution                                                                                                                                      |
|---------------------------------------------------|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Container does not fit into the machine.          | Incorrect orientation or incompatible machine model. | Ensure the container is inserted with the correct orientation. Verify your Nespresso machine is a compatible Inissia C40 or D40 series model. |
| Used capsules are not falling into the container. | Container is full or improperly seated.              | Empty the container if full. Remove and reinsert the container, ensuring it is securely seated in its slot. Check for any obstructions.       |
| Unpleasant odor from the container.               | Infrequent cleaning or residue buildup.              | Clean the container thoroughly with warm water and mild soap. Ensure it is completely dry before reinserting. Increase cleaning frequency.    |

## Specifications

- **Brand:** KRUPS
- **Model Compatibility:** Nespresso Inissia XN100, XN1001, XN1007 Series (fits Krups C40 and D40 Series Coffee Machines)
- **Material:** Plastic
- **Color:** Clear/White
- **Finish:** Glossy
- **Item Weight:** Approximately 2.11 ounces (0.06 Kilograms)

## Warranty and Support

For any questions regarding the KRUPS Nespresso Inissia Capsule Container, including warranty information or technical support, please contact KRUPS customer service. Refer to your original Nespresso coffee machine manual or the official KRUPS website for contact details and further assistance.  
**KRUPS Official Website:** [www.krups.com](http://www.krups.com)

© 2025 KRUPS. All rights reserved. Information subject to change without notice.

### Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B09DGRXBBJ>

More documents and user manuals: <https://manuals.plus/>