

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Senso](#) /

› [Senso Orbit Wireless Earbuds Instruction Manual](#)

Senso Orbit Wireless Earbuds 666228000217

Senso Orbit Wireless Earbuds Instruction Manual

Model: Orbit 666228000217



INTRODUCTION

Thank you for choosing Senso Orbit Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with features like Environmental Noise Cancellation (ENC), deep bass, and a compact charging case. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

WHAT'S IN THE BOX

- Senso Orbit Wireless Earbuds
- Compact USB-C Charging Case
- Multiple Sizes of Ear Tips
- USB-C Charging Cable
- Instruction Manual



Image: Senso Orbit Earbuds with multiple ear tip sizes for a comfortable fit.

SETUP

Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB-C cable to the charging port on the case and to a power source. The LED indicators on the case will show the charging status.

Pairing with Your Device

The Senso Orbit earbuds feature a responsive one-step instant connection. Simply open the charging case, and the earbuds will automatically enter pairing mode. Then, follow these steps:

1. Open the charging case.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
3. Select "Orbits" or "Orbits ENC70" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbuds are ready for use.

Responsive One-Step Instant Connection

Instantly Connect when you Open the Case



Image: Earbuds in their charging case, demonstrating the one-step instant connection with a smartphone's Bluetooth settings.

OPERATING INSTRUCTIONS

Touch Controls

The Senso Orbit earbuds are equipped with multi-function touch controls. Simply tap on the earbuds to access various functions:

- **Volume +/-**: Double tap the Left (L) earbud to decrease volume, or the Right (R) earbud to increase volume.
- **Play/Pause**: Single tap either L or R earbud.
- **Previous/Next Track**: Triple tap the L earbud for the previous track, or the R earbud for the next track.
- **Answer/Reject Phone Call**: Press and hold either L or R earbud for 2 seconds to answer or reject a call.
- **Activate Voice Assistant (SIRI)**: Press and hold either L or R earbud for 2 seconds.

Multi-Function Touch Control

Simply Tap on the Earbuds to Access All Functions



Volume + / -



Play / Pause



Previous/ Next Track



Answer / Reject Phone Call



Activate SIRI




Image: A user demonstrating the touch controls on the Senso Orbit earbuds, with a visual guide to different tap functions.

Charging the Earbuds and Case

The charging case provides extended battery life for your earbuds. The earbuds will charge automatically when placed inside the case and the lid is closed. The case itself can be charged via a USB-C cable. The LED indicators on the case show the remaining battery level.

Power Your Entire Day

Long Battery Life You Can Quickly Charge via USB-C

7 hrs
Listening Time

35 hrs
With Charging Case



Image: Senso Orbit earbuds and their charging case, illustrating the long battery life and USB-C charging capability.

Environmental Noise Cancellation (ENC) for Calls

The Senso Orbit earbuds feature a QUAD-microphone array with ENC technology to effectively suppress environmental noise and enhance voice clarity during calls. This reduces ambient noise by up to 35dB, ensuring clear communication.

Your browser does not support the video tag.

Video: This video demonstrates the Environmental Noise Cancellation (ENC) feature of the Senso Orbit Wireless Earbuds, highlighting how it reduces background noise for clearer calls.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, you may gently wipe them with a damp cloth and mild soap, ensuring they are completely dry before reattaching.

Water Resistance

The Senso Orbit earbuds are IPX rated, providing protection against light rain, accidental splashes, and sweat. They are suitable for sports and exercise. However, they are not designed for submersion in water. Avoid exposing them to excessive moisture or harsh chemicals.



Image: Senso Orbit earbuds shown with water droplets, illustrating their IPX rating for protection against water and sweat.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid. Check your device's Bluetooth settings to ensure it's discoverable and select "Orbits". If issues persist, try resetting the earbuds (refer to specific reset instructions if provided in a separate quick start guide).
- No sound from one earbud:** Place both earbuds back in the charging case, close the lid, and then reopen it.

Re-pair with your device.

- **Charging issues:** Ensure the USB-C cable is securely connected to both the case and the power source. Check if the charging port is clean and free of debris.
- **Poor call quality:** Ensure the earbuds are properly seated in your ears. Check for any obstructions around the microphones.

SPECIFICATIONS

Feature	Detail
Model Name	Orbits
Connectivity Technology	Bluetooth 5.0, Wireless
Wireless Communication Technology	Bluetooth
Included Components	Charging Case
Material	Plastic, Silicone
Specific Uses For Product	Sports and Exercise
Charging Time	2 Hours
Water Resistance Level	Waterproof (IPX rated)
Control Method	Touch
Bluetooth Version	5.0
Noise Control Features	Active Noise Control (ENC)
Special Feature	Lightweight, Microphone Included, Noise Cancellation, Water-resistant, Wireless
Item Weight	5 ounces
Battery Life (Earbuds)	Up to 7-8 hours
Total Playtime (with Charging Case)	Up to 35 hours

WARRANTY AND SUPPORT

Extended Warranty

Senso offers an option to extend the warranty to two years for free. To convert to a Two Year Warranty, please visit www.sensoshop.com/warranty. This must be claimed within 7 days of receiving the product.

Customer Support

For any further assistance, technical support, or inquiries, please refer to the contact information provided with your product packaging or visit the official Senso website.

© 2023 Senso. All rights reserved.