

[Manuals.plus](#) /

› [pTron](#) /

› pTron Quinto Evo 8W Wireless Bluetooth 5.0 Speaker User Manual

pTron Quinto Evo

pTron Quinto Evo 8W Wireless Bluetooth 5.0 Speaker User Manual

Model: Quinto Evo

1. INTRODUCTION

Thank you for choosing the pTron Quinto Evo 8W Wireless Bluetooth 5.0 Speaker. This portable speaker is designed to deliver impressive sound quality with robust bass, offering versatile connectivity options and integrated controls for an enhanced audio experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.



Image 1.1: The pTron Quinto Evo speaker is lightweight and suitable for both indoor and outdoor use, making it easy to carry.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x pTron Quinto Evo Speaker
- 1 x Charging Cable (Micro USB)
- 1 x Aux Cable (3.5mm)
- 1 x User Guide

3. PRODUCT OVERVIEW

3.1. Controls

INTEGRATED BUTTON CONTROLS & WATER-RESISTANT CASING



LONG PRESS POWER ON/OFF
SHORT PRESS MODE CHANGE



SHORT PRESS PREVIOUS SONG
LONG PRESS VOLUME DOWN



SHORT PRESS NEXT SONG
LONG PRESS VOLUME UP



SHORT PRESS PLAY/PAUSE
SHORT PRESS CALL ANSWER/HANG-UP



Image 3.1: The speaker features integrated button controls for easy operation and a water-resistant casing.

Power Button ():

Long Press: Power ON/OFF

Short Press: Mode Change (Bluetooth, Aux, Micro SD, USB)

Previous Track / Volume Down Button (-):

Short Press: Previous Song

Long Press: Volume Down

Next Track / Volume Up Button (+):

Short Press: Next Song

Long Press: Volume Up

Play/Pause / Call Control Button ():

Short Press: Play/Pause music

Short Press (during call): Answer/Hang-up call

3.2. Ports



Image 3.2: The speaker supports multiple direct plug & play modes via 3.5mm Aux, Micro SD card, and USB drive slots.

- **Micro USB Charging Port:** For charging the speaker.
- **3.5mm AUX Input:** For wired audio connection.
- **Micro SD Card Slot:** For playing music directly from a Micro SD card.
- **USB Drive Slot:** For playing music directly from a USB flash drive.

4. SETUP

4.1. Charging the Speaker

1. Connect the provided Micro USB charging cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power adapter (DC5V/500mA, not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and turn off once fully charged.

4.2. Powering On/Off

- **To Power ON:** Long press the Power button () until you hear an audible prompt.
- **To Power OFF:** Long press the Power button () again until you hear an audible prompt.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Pairing



Image 5.1: The speaker utilizes Bluetooth v5.0 for fast pairing and seamless connectivity up to 10 meters, and includes a built-in microphone.

1. Ensure the speaker is powered ON and in Bluetooth mode (indicated by a flashing LED). If not, short press the Power button () to cycle through modes until Bluetooth mode is active.
2. Enable Bluetooth on your smartphone or other device.
3. Search for available Bluetooth devices and select "**pTron Quinto Evo**" from the list.
4. Once paired, the LED indicator will stop flashing, and you will hear a confirmation sound.

5.2. True Wireless Stereo (TWS) Function

TRUE WIRELESS FUNCTION

CONNECT 2 QUINTO EVO'S AND DOUBLE THE VOLUME



Image 5.2: Connect two Quinto Evo speakers wirelessly to achieve True Wireless Stereo sound and double the volume.

To pair two pTron Quinto Evo speakers for a stereo experience:

1. Ensure both speakers are powered OFF.
2. Power ON both speakers simultaneously. They will enter Bluetooth pairing mode.
3. On one of the speakers (this will be the primary speaker), long press the Play/Pause button () for 2-3 seconds. The speakers will attempt to connect to each other.
4. Once successfully paired, you will hear a confirmation sound, and the LED on the primary speaker will flash, while the secondary speaker's LED will be solid.
5. Now, connect your device to the primary speaker via Bluetooth as described in section 5.1. Audio will play through both speakers in stereo.

5.3. Auxiliary (AUX) Input

Use the 3.5mm AUX cable to connect the speaker to any device with a 3.5mm audio output:

1. Connect one end of the 3.5mm AUX cable to the speaker's AUX port.
2. Connect the other end to your audio source (e.g., smartphone, laptop).
3. The speaker will automatically switch to AUX mode, or you can short press the Power button () to select AUX mode.

5.4. Micro SD Card / USB Drive Playback

To play music directly from a Micro SD card or USB drive:

1. Insert a Micro SD card or USB drive (with MP3 audio files) into the corresponding slot on the speaker.
2. The speaker will automatically detect the storage device and begin playback, or you can short press the Power button () to select the appropriate mode.

5.5. Hands-free Calling

When connected via Bluetooth, the built-in microphone allows for hands-free calls:

- **Answer/End Call:** Short press the Play/Pause button ().
- **Reject Call:** Long press the Play/Pause button ().

6. MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or high humidity.
- Keep the speaker away from water, although it is water splash resistant, it is not fully waterproof for submersion.
- Store the speaker in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

Problem	Solution
Speaker does not power ON.	Ensure the speaker is fully charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	Ensure the speaker is in Bluetooth pairing mode. Turn off and on Bluetooth on your device. Move the speaker closer to your device. Clear previous Bluetooth connections on your device.
No sound from speaker.	Check volume levels on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX, SD, USB) is selected.
TWS pairing fails.	Ensure both speakers are powered off before attempting TWS pairing. Follow the TWS pairing steps carefully.
Poor sound quality.	Ensure the speaker is within the Bluetooth range (10 meters). Check for interference from other wireless devices. Try a different audio source or file.

8. SPECIFICATIONS



Image 8.1: Physical dimensions of the pTron Quinto Evo speaker.

Feature	Detail
Brand	pTron
Model Name	Quinto Evo

Feature	Detail
Speaker Maximum Output Power	8 Watts
Connectivity Technology	Auxiliary, Bluetooth, USB, Wireless
Bluetooth Version	5.0
Bluetooth Range	10 Metres
Audio Output Mode	Stereo
Speaker Type	Subwoofer
Audio Driver Size	45 Millimetres
Frequency Response	20000 Hz
Battery Capacity	1200 mAh
Battery Average Life	12 Hours
Charging Time	Approximately 2-3 Hours
Power Source	Battery Powered
Control Method	Button
Is Waterproof	TRUE (Water Splash Resistant)
Item Dimensions (D x W x H)	7.5D x 7.5W x 19H Centimeters
Item Weight	375 Grams
Enclosure Material	ABS
Compatible Devices	Laptop, Personal Computer, Smartphone, Tablet

9. WARRANTY & SUPPORT

9.1. Warranty Information

The pTron Quinto Evo speaker comes with a **1-year manufacturer warranty** covering manufacturing defects only. Please retain your purchase receipt for warranty claims.

9.2. Customer Support

For any support or warranty-related queries, please contact:

- **Manufacturer:** Parude Technology (Shenzhen) Co. Ltd.
- **Manufacturer Address:** Building A1, Red Box Creative Park, No. 3 Huancheng South Road, Bantian Street, Longgang District, Shenzhen City, China 518116.
- **Importer:** Palred Electronics Pvt. Ltd.
- **Importer Address:** Sy.No.1240, Kurnool Nandyal Road, Nannur Village, Kurnool, Andhra Pradesh, 518002, India

