

[Manuals.plus](#) /

› [AULA](#) /

› AULA F2088 Typewriter Style Mechanical Gaming Keyboard Blue Switches,Rainbow LED Backlit,Removable Wrist Rest,Media Control Knob,Retro Punk Round Keycaps,USB Wired Computer Keyboard Black-blue switches

AULA F2088

AULA F2088 Mechanical Gaming Keyboard User Manual

Model: F2088 | Brand: AULA

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your AULA F2088 Typewriter Style Mechanical Gaming Keyboard. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- 1 x Wired Blue Switch Mechanical Keyboard
- 1 x Wrist Rest
- 1 x Keycap Puller
- 1 x English Manual

SETUP

The AULA F2088 keyboard is designed for simple plug-and-play functionality. No additional drivers or software are required for basic operation.

Connecting the Keyboard

1. Locate an available USB port on your computer (PC, Mac, Laptop, Desktop).
2. Insert the USB connector of the keyboard into the USB port.
3. The keyboard will be automatically recognized by your operating system (Windows 7/8/10/XP/Vista, Linux, Mac OS).
4. The backlight will illuminate, indicating the keyboard is ready for use.



The AULA F2088 keyboard connected via USB, showcasing its rainbow LED backlight and detachable wrist rest.

Attaching the Wrist Rest

The keyboard comes with a magnetic wrist rest for enhanced ergonomic comfort during extended use.

1. Align the magnetic edges of the wrist rest with the corresponding area at the bottom front of the keyboard.
2. The magnets will secure the wrist rest in place.



The detachable magnetic wrist rest provides ergonomic support, reducing hand fatigue.


Adjusting Keyboard Angle

The keyboard features adjustable kickstands on the underside to modify the typing angle for personal comfort.


1. Gently lift the front edge of the keyboard.
2. Flip out the two kickstands located at the rear corners of the keyboard.
3. Place the keyboard back down to rest on the extended kickstands.

ERGONOMIC DESIGN FOR COMFORT

User-friendly for long time typing and gaming



Adjustable kickstand



Adjustable kickstands allow for a customized ergonomic typing angle.

OPERATING INSTRUCTIONS

Key Features Overview

- **Retro Typewriter Style Round Keycaps:** Equipped with mechanical blue switches, providing a tactile and clicky response. Double-shot injection molded keycaps ensure durability and clear backlighting.
- **Multimedia and Backlight Control Knob:** A dedicated knob for easy control of media playback, volume, and backlight effects.
- **Metal Panel:** The keyboard features a top-grade aluminum alloy panel for enhanced durability and a premium feel.
- **104 Keys Anti-Ghosting:** Ensures all simultaneous keystrokes are registered accurately, crucial for gaming and fast typing.

Backlight Control

The AULA F2088 keyboard offers various backlight modes and customization options.

- The keyboard supports 19 different lighting effects.
- Backlight brightness and speed can be adjusted.
- Three customized backlight profiles can be created and saved.





The keyboard features bright multicolor backlighting with multiple modes and adjustable brightness.

Using the Control Knob:

- **Short Press:** Cycles through the 19 pre-set lighting effects.
- **Long Press (3 seconds):** Switches between Lighting Control Mode and Multimedia Mode.
- **Rotate in Lighting Control Mode:** Adjusts backlight brightness.

MULTIMEDIA & BACKLIGHT CONTROL KNOB

Long press 3s to switch the modes



The dedicated knob allows switching between lighting and multimedia control modes by long-pressing for 3 seconds.

Multimedia Control

When the control knob is in Multimedia Mode, it provides quick access to media functions.

- **Rotate in Multimedia Mode:** Adjusts media volume.
- **Dedicated Media Keys (M1, M2, M3):** These buttons provide quick access for music play, pause, and track switching.

Anti-Ghosting Technology

The 104-key anti-ghosting feature ensures that every keystroke is registered accurately, even when multiple keys are pressed simultaneously. This is particularly beneficial for fast typing and complex gaming commands.

- **FN + PRTSC:** Activates 6-key rollover (default).
- **FN + SCRLK:** Activates N-key rollover.



MECHANICAL BLUE SWITCH

Tactile & clicky sound



4.0mm
Trigger route



60±10g
Key force



100 million times
Key strokes

The keyboard supports full 104-key anti-ghosting for precise input during intense use.

MAINTENANCE

Regular cleaning and proper care will extend the lifespan of your keyboard.

General Cleaning

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and keyboard surface.
- Avoid spraying liquids directly onto the keyboard.
- For dust and debris between keys, use compressed air.

Keycap Removal (for deep cleaning)

A keycap puller is included for easy removal and reinstallation of keycaps.

1. Gently place the keycap puller over the desired keycap.

2. Apply even pressure and pull upwards until the keycap detaches from the switch.
3. Clean the keycap and the area around the switch.
4. To reattach, align the keycap with the switch stem and press down firmly until it clicks into place.



The mechanical blue switches are visible when keycaps are removed, facilitating deep cleaning.

TROUBLESHOOTING

Keyboard Not Responding

- Ensure the USB cable is securely connected to both the keyboard and the computer.
- Try connecting the keyboard to a different USB port on your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's USB port.
- Restart your computer.

Backlight Not Working or Incorrectly Displaying

- Ensure the keyboard is properly connected and receiving power.
- Use the control knob to adjust brightness (rotate in Lighting Control Mode).
- Short press the control knob to cycle through different lighting effects.
- Perform a factory reset if customization issues persist (refer to advanced settings or software if applicable, though the product description states no software is required).

Keys Repeating or Not Registering Correctly

- This can sometimes occur due to dust or debris under the keycap or switch. Try removing the affected keycap with the provided puller and cleaning the area with compressed air.
- Ensure the keycap is re-seated properly.
- If the issue persists across multiple keys or after cleaning, it may indicate a hardware issue.

SPECIFICATIONS

Brand	AULA
Model Number	F2088
Product Dimensions	17.13 x 4.84 x 1.5 inches
Item Weight	2.25 pounds
Connectivity Technology	USB Wired
Keyboard Description	Mechanical Keyboard (Blue Switches)
Number of Keys	104
Backlighting Color Support	Rainbow LED (Single Color per zone)
Special Features	Round Keycaps, LED Backlit, Ergonomic, Removable Wrist Rest, Volume Control Knob
Compatible Devices	PC, Mac, Laptop, Tablet, Desktop computer
Operating Systems	Windows 7/8/10/XP/Vista, Linux, Mac OS

WARRANTY AND SUPPORT

AULA products are manufactured to high-quality standards. For specific warranty information and terms, please refer to the documentation included with your purchase or visit the official AULA website.

For technical support, product inquiries, or assistance with troubleshooting beyond this manual, please contact AULA customer service through their official channels or visit the [AULA Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question