

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Retevis](#) /

› [Retevis RB19P GMRS Walkie Talkie Instruction Manual](#)

Retevis RB19P

Retevis RB19P GMRS Walkie Talkie Instruction Manual

Model: RB19P | Brand: Retevis

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Retevis RB19P GMRS Walkie Talkies. Please read this manual thoroughly before using the product and retain it for future reference.

WHAT'S IN THE BOX

- 6X RB19P GMRS Radios
- 6X G-type Earpiece
- 1X 6 Way Multi Unit Charger
- 1X Adapter
- 1X English Manual



Figure 1: Package Contents of Retevis RB19P Walkie Talkies.

PRODUCT FEATURES

- Ultra-slim body design with a 1.7-inch screen for easy communication.
- 30 preset GMRS channels with enhanced penetration for longer range.
- 2000mAh Li-Ion battery providing 16 to 20 hours of heavy use.
- USB-C charging port for convenient charging.
- Includes earpiece and mic set with finger PTT for clear communication in noisy environments.
- Volume memory function to prevent excessively loud reboots.

ULTRA-THIN

Business walkie-talkies



Figure 2: Ultra-thin and lightweight design of the RB19P.



Figure 3: 1.7-inch display and key functions.

SETUP AND CHARGING

Before first use, ensure the walkie talkie is fully charged. The device features a 2000mAh Li-Ion battery and can be charged via its USB-C port or the multi-unit charger.

2000MAH BATTERY

16-20H

Usage Time

4H

USB-C Charging



Figure 4: USB-C Charging for the 2000mAh Battery.

To charge using the multi-unit charger, place the walkie talkie securely into an available slot. Ensure the charging indicator illuminates. A full charge typically takes approximately 4 hours.

Retevis RB19P

Ultra-Slim Walkie Talkie for Business



Figure 5: Multi-unit charger for multiple RB19P radios.

OPERATING INSTRUCTIONS

Power On/Off

To power on or off, long press the power button located on the top of the radio. A voice prompt will confirm the action.

Your browser does not support the video tag.

Video 1: Demonstrates how to power on/off the Retevis RB19P walkie talkie, adjust volume, change channels, activate VOX, and use emergency alarm and keypad lock.

Volume Adjustment

Use the up and down arrow buttons on the front panel to adjust the volume. The display will show the current volume level.

Channel Selection

The RB19P has 30 preset GMRS channels. Use the left and right arrow buttons to cycle through the available channels. A voice prompt will announce the selected channel number.

VOX Hands-Free Operation

To activate VOX (Voice Operated Exchange) for hands-free communication, short press the square button twice. Ensure VOX is enabled before using an earpiece for hands-free operation.



Figure 6: Custom single-pin earpiece for RB19P. Turn on VOX before use.

Emergency Alarm

To activate the local and remote emergency alarm, long press the left arrow button. The radio will emit a loud alarm sound.

Keypad Lock/Unlock

To lock the keypad, long press the square button. To unlock, long press the square button again.

NOAA Weather Channel

The RB19P can access NOAA weather channels. Refer to the video for instructions on how to enter NOAA Regulation Mode and adjust channels.

Your browser does not support the video tag.

Video 2: Instructions on how to change settings and access NOAA weather channels on the Retevis RB19P.

COMPATIBILITY NOTES

The Retevis RB19P (30 channels) supports direct calls on channels 1-5 for 16-channel radios, and channels 1-22 for 22-channel radios. Channels 23-30 of RB19P are repeater channels. Communication with other brands of walkie-talkies may require specific firmware; contact Retevis support for assistance.

COMPACT AND SIMPLE

Ready to use right out of the box



Figure 7: RB19P Compatibility with other channel configurations.

RANGE INFORMATION

The effective range of your walkie talkie can vary significantly based on terrain, obstacles, atmospheric conditions, radio power, signal type, and antenna. While the RB19P offers strong penetration, dense environments like heavily wooded areas or urban settings with many buildings will reduce range.

Your browser does not support the video tag.

Video 3: Demonstrates the range performance of the RB19P in densely wooded areas.

Your browser does not support the video tag.

Video 4: Explains factors affecting two-way radio range and how to extend it.

How to extend further distance?

- Increase the transmission power (in theory, if the transmission power is doubled, the communication distance can be expanded to approximately 1.4 times the original distance).
- Improve the receiving sensitivity (adjust the squelch threshold of the walkie-talkie and use a high-gain antenna to correspondingly improve the receiving sensitivity of the walkie-talkie).
- Keep launching from a higher location.
- Keep your battery charged.

SPECIFICATIONS

Item Weight	9.1 ounces
Product Dimensions	6.14 x 2.09 x 0.59 inches
Item Model Number	FA9059V-C9059C-C9154AX6
Batteries	1 Lithium Ion batteries required. (included)
Number of Channels	30
Special Feature	Ultra thin; high power; 2000mAh battery; USB-C; 1.7inch screen
Frequency Range	GMRS
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT

Retevis provides a 2-year warranty for the radio body and a 1-year warranty for accessories. For any issues or support, please contact Retevis via Amazon. They aim to reply within 12 hours.