Tefal EY505D

Tefal EY505D Easy Fry & Grill Deluxe User Manual

Model: EY505D

Introduction

This user manual provides essential information for the safe and efficient operation of your Tefal EY505D Easy Fry & Grill Deluxe. Please read this manual thoroughly before first use and keep it for future reference. The Tefal EY505D is a versatile 2-in-1 appliance, combining a hot air fryer and a grill, designed to offer healthy and delicious cooking options.



Image: The Tefal EY505D Easy Fry & Grill Deluxe hot air fryer shown with its removable grill plate, highlighting its dual functionality.

Safety Instructions

Always follow basic safety precautions when using electrical appliances.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate the appliance if the plug, power cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning.
- Do not block the air inlet and outlet openings during operation.
- The surfaces may become hot during use. Do not touch hot surfaces directly.
- Use only accessories recommended by the manufacturer.

Product Overview

The Tefal EY505D Easy Fry & Grill Deluxe features a compact design with a user-friendly digital interface.



Image: A close-up view of the digital control panel on the Tefal EY505D, showing various preset program icons and temperature/timer display.

Key Components:

- Main Unit with Digital Control Panel
- Removable Cooking Basket
- Die-cast Aluminum Grill Plate
- Power Cord

Dimensions:



Image: Diagram illustrating the dimensions of the Tefal EY505D: approximately 32 cm (12.6 inches) height, 27 cm (10.63 inches) width, and 36 cm (14.17 inches) depth.

The appliance measures approximately 10.63 x 14.21 x 12.76 inches (27 x 36 x 32 cm) and weighs 12.32 pounds (5.6 kg).

Setup and First Use

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Cleaning:** Before first use, clean the cooking basket and grill plate with hot water, dish soap, and a non-abrasive sponge. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the appliance on a stable, heat-resistant, and level surface, away from walls or other appliances to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

General Operation:

- Insert the cooking basket or grill plate into the appliance.
- Place your ingredients into the basket or onto the grill plate. Do not overfill.
- Select your desired cooking program or manually set the temperature (80°C to 200°C) and time (up to 60 minutes) using the digital touch control panel.
- Press the start button to begin cooking.
- The appliance will automatically shut off when the timer expires.

Cooking Functions:

The Tefal EY505D offers 2-in-1 technology for both air frying and grilling, along with 8 automatic programs.



Image: The digital control panel displaying the 8 preset programs for various food types including fries, nuggets, roasted chicken, pizza, meat, fish, vegetables, and dessert.

- **Air Frying:** Utilizes hot air for crispy results with little to no oil. Ideal for fries, nuggets, and other fried foods.
- **Grilling:** Use the cast aluminum grill plate for tender, juicy meat or vegetables with authentic grill marks.

- **Dehydration:** Prepare healthy homemade snacks like dried fruits or vegetables.



Image: The Tefal EY505D with its cooking basket pulled out, showing a perfectly roasted whole chicken inside, demonstrating its XL capacity.

The XL capacity of 4.2 liters allows for cooking larger portions, suitable for families.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Removable Parts:** The cooking basket and grill plate are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
3. **Main Unit:** Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners or scourers.
4. **Interior:** Clean the interior of the appliance with a damp cloth and mild detergent if necessary.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; appliance fault.	Check power cord connection; try a different outlet; contact customer support if problem persists.
Food is not cooked evenly.	Basket/plate overloaded; incorrect temperature/time setting.	Do not overload; shake or flip food halfway through cooking; adjust temperature/time as needed.
White smoke coming from appliance.	Grease residue from previous use; fatty ingredients.	Clean the appliance thoroughly after each use; remove excess fat from ingredients.
Food is not crispy.	Too much moisture in food; not enough oil (for air frying); basket overloaded.	Pat food dry before cooking; add a small amount of oil; cook in smaller batches.

Specifications

Feature	Detail
Model Name	EY505D Easy Fry & Grill Deluxe
Capacity	4.2 Liters
Wattage	2000 Watts (2 Kilowatts)
Voltage	240 Volts
Temperature Range	80°C - 200°C (176°F - 392°F)
Control Method	Touch Digital Panel
Material	Stainless Steel (Outer), Stainless Steel/Aluminum (Inner)
Dimensions (L x W x H)	14.21 x 10.63 x 12.76 inches (approx.)
Item Weight	12.32 pounds (5.6 Kilograms)
Dishwasher Safe Parts	Yes (Removable parts)
Special Features	2-in-1 Air Fryer & Grill, 8 Automatic Programs, Dehydration Function, Timer, Nonstick Coating

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Tefal website. Keep your proof of purchase for warranty claims.

Online Resources: Visit the Official T-Fal Store on Amazon

© 2024 Tefal. All rights reserved.