



[Manuals.plus](#) /

› [MEMBER'S MARK](#) /

› Member's Mark Tilting TV Wall Mount XD6116 User Manual

MEMBER'S MARK XD6116

Member's Mark Tilting TV Wall Mount (Model XD6116) User Manual

For 32-90 inch TVs

INTRODUCTION

This manual provides comprehensive instructions for the safe and proper installation, operation, and maintenance of your Member's Mark Tilting TV Wall Mount, Model XD6116. Please read this manual thoroughly before installation and retain it for future reference.

SAFETY INFORMATION

WARNING: Failure to read and follow all instructions may result in personal injury or property damage. Do not install this product if you do not understand these instructions or have doubts about the safety of the installation. If you have any questions, please contact customer support.

- Ensure the mounting surface can safely support the combined weight of the mount and your TV.
- Do not exceed the maximum weight capacity of 150 lbs (68 kg).
- This mount is designed for installation on 16" or 24" wood studs. Do not install on drywall alone.
- Use appropriate safety gear during installation, including eye protection.
- Keep children and pets away during installation.
- Check all connections and fasteners regularly to ensure they remain secure.

PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.



Figure 1: Product packaging for the Member's Mark Tilting TV Wall Mount. The box indicates "TILT TV WALL MOUNT," "EASY 3-STEP INSTALLATION," "HOLDS UP TO 150 LBS," and "32-90" TVs."

Your package includes the main wall mount assembly and an extensive hardware packet designed to ensure compatibility with various TV models and wall types. Refer to the included hardware list for specific fastener sizes and types.

SPECIFICATIONS

Brand	Member's Mark
Model Number	XD6116
Compatible TV Sizes	32-90 inches
Maximum Weight Capacity	150 lbs (68 kg)
Mounting Type	Wall Mount (for 16" or 24" wood studs)
Movement Type	Tilt
Maximum Tilt Angle	10 Degrees
Distance from Wall	2.32 inches (low-profile design)
Material	Alloy Steel
Color	Black
Product Dimensions	25.78 x 16.93 x 16.93 inches
Item Weight	7 pounds
UPC	193968096052

SETUP AND INSTALLATION

This tilting TV wall mount is designed for easy 3-step installation on 16" or 24" wood studs. Ensure you have the necessary tools (e.g., stud finder, drill, level, screwdriver) before beginning.



Figure 2: The main components of the Member's Mark Tilting TV Wall Mount, showing the wall plate and the two vertical TV brackets with adjustable arms.

Step 1: Attach Brackets to TV

1. Carefully place your TV face down on a soft, clean surface to prevent screen damage.
2. Identify the VESA mounting holes on the back of your TV.
3. Select the appropriate screws, washers, and spacers from the hardware packet that fit your TV's mounting holes.
4. Attach the two vertical TV brackets to the back of your TV, ensuring they are centered and securely fastened. The brackets should be oriented so the hooks face upwards and the pull-straps are at the bottom.

Step 2: Mount Wall Plate to Wall

1. Locate two adjacent wood studs using a stud finder. Mark the center of each stud at the desired height for your TV.
2. Hold the wall plate against the wall, aligning its mounting holes with your marked stud centers. Use a level to ensure the wall

plate is perfectly horizontal.

3. Mark the pilot hole locations. Drill pilot holes into the center of the studs.
4. Secure the wall plate to the wall using the provided lag bolts and washers. Tighten all bolts firmly, but do not overtighten.

Step 3: Hang TV on Wall Plate

1. With assistance, carefully lift the TV with the attached brackets.
2. Hook the top of the TV brackets onto the top edge of the wall plate.
3. Gently lower the TV until the brackets fully engage with the wall plate.
4. Engage the safety locking mechanisms (typically pull-straps or screws at the bottom of the brackets) to secure the TV to the wall plate.

Post-Installation Leveling

This mount features a leveling design that allows for easy adjustment even after installation. Refer to the specific mechanism on your mount (usually small adjustment screws on the TV brackets) to fine-tune the TV's horizontal level.

OPERATING THE TILT FEATURE

The Member's Mark Tilting TV Wall Mount allows you to effortlessly adjust your TV's vertical viewing angle by up to 10 degrees. This feature is designed to reduce glare from windows or lighting and optimize your viewing experience.

- To tilt the TV, gently grasp the top and bottom edges of your TV.
- Carefully push the top of the TV backward or pull the bottom forward to achieve the desired tilt angle. No tools are required for this adjustment.
- The mount will hold the TV securely at the chosen angle.

The low-profile design keeps your TV only 2.32 inches from the wall, while the tilting mechanism still provides easy access to cables behind the TV when tilted.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV wall mount.

- **Cleaning:** Wipe the mount with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight and secure. Loose fasteners can compromise safety.
- **Weight Limit:** Do not hang additional items on the mount or exceed the maximum weight capacity of 150 lbs.

TROUBLESHOOTING

If you encounter issues with your TV wall mount, refer to the following common solutions:

- **TV is not level:** Use the post-installation leveling feature to adjust the TV's horizontal position. Ensure the wall plate was installed level initially.
- **TV feels unstable:** Immediately remove the TV from the mount. Re-check all wall plate and TV bracket fasteners to ensure they are securely tightened. Verify that the wall studs are properly engaged and the wall can support the weight.
- **Difficulty tilting:** Ensure no cables are obstructing the tilting mechanism. The tilt should be effortless; if it feels stiff, check for obstructions or contact support.

WARRANTY INFORMATION

The Member's Mark Tilting TV Wall Mount (Model XD6116) is backed by a **10-Year Warranty**. This warranty covers defects in

materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, or to initiate a warranty claim, please contact Member's Mark customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report a missing/damaged part, please contact Member's Mark customer support. Refer to your product packaging or the Member's Mark official website for the most current contact information.

