

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [XLEADER](#) /

› [XLEADER SoundAngel Mate \(2nd Gen\) Pro Shower Speaker Instruction Manual](#)

XLEADER USMATES

XLEADER SoundAngel Mate (2nd Gen) Pro Shower Speaker Instruction Manual

Model: USMATES | Brand: XLEADER

INTRODUCTION

Thank you for choosing the XLEADER SoundAngel Mate (2nd Gen) Pro Shower Speaker. This portable Bluetooth speaker is designed to provide high-quality audio in wet environments, featuring IPX7 waterproofing, 8W crystal sound with rich bass, and a long 15-hour playtime. This manual provides essential information for setup, operation, and maintenance to ensure you get the best experience from your device.

WHAT'S IN THE BOX

- XLEADER SoundAngel Mate Bluetooth Speaker
- Customized 3.5mm jack Charging Cable
- Multilingual User Manual
- Warranty Card
- Donation Card
- Suction Cup
- Premium Gift box

PRODUCT FEATURES

- **IPX7 Waterproof:** Fully immersible up to 1 meter for 30 minutes, ideal for showers, pools, and outdoor activities.
- **3D Crystal Sound & Rich Bass:** Equipped with an 8W speaker, precision neodymium driver, and proprietary bass radiator for clear, powerful audio.
- **Long Playtime:** Up to 15 hours of continuous music playback on a single charge.
- **Bluetooth 5.0:** Ensures stable and fast wireless connection with compatible devices up to 100 meters range.
- **Built-in Microphone:** For hands-free calling.
- **Versatile Mounting:** Includes a strong suction cup for smooth surfaces and a silicone lanyard for hanging.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the customized 3.5mm jack charging cable to the speaker's charging port and a USB power source. The charging time is approximately 3 hours. The LED indicator will show charging status.

2. Power On/Off

Press and hold the power button () located on the control panel to turn the speaker On or Off. A voice prompt will confirm the action.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter pairing mode, indicated by a flashing LED light.
2. On your smartphone or Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "SoundAngel Mate" from the list. A voice prompt will confirm successful pairing.
4. The speaker will automatically reconnect to the last paired device when turned on, if within range.

Your browser does not support the video tag.

Video: Demonstrates easy Bluetooth connection and usage of the XLEADER SoundAngel Mate speaker.

4. Mounting the Speaker

The speaker comes with a strong suction cup. Ensure the surface is clean and smooth before attaching. Press the suction cup firmly against the surface until it adheres securely. A silicone lanyard is also included for hanging the speaker.

Strong Suction Cup

Enjoy a funny shower with music



IPX7



Calling



Image: The XLEADER SoundAngel Mate speaker with its strong suction cup, shown attached to a shower wall, highlighting its secure grip for wet environments.

OPERATING INSTRUCTIONS

1. Music Playback

- Play/Pause:** Press the Play/Pause button (▶/||) to play or pause music.
- Volume Up/Next Track:** Short press the V+/ button to increase volume. Long press to skip to the next track.
- Volume Down/Previous Track:** Short press the V-/ button to decrease volume. Long press to go to the previous track.

2. Hands-Free Calling

- Answer Call:** Press the Phone button () to answer an incoming call.
- End Call:** Press the Phone button () again to end an active call.
- Reject Call:** Press and hold the Phone button () to reject an incoming call.

3. Light Modes

The speaker features multiple LED light modes. Press the Light button () to cycle through different lighting effects

or turn them off.

Your browser does not support the video tag.

Video: A detailed guide on how to use the waterproof shower speaker, including pairing, controls, and light functions.

MAINTENANCE

- After use in water, gently wipe the speaker dry with a soft cloth.
- Ensure the charging port cover is securely closed to maintain its waterproof rating.
- Avoid using harsh chemicals or abrasive cleaners on the speaker.
- Store in a cool, dry place when not in use.

TROUBLESHOOTING

No Power

- Ensure the speaker is fully charged.
- Press and hold the power button for a few seconds to ensure it's turning on correctly.

Cannot Pair

- Make sure the speaker is in pairing mode (flashing LED).
- Ensure Bluetooth is enabled on your device and it's within range (up to 100 meters).
- Forget "SoundAngel Mate" from your device's Bluetooth list and try pairing again.
- If multiple users are trying to connect, ensure previous devices are disconnected or have forgotten the speaker.

Poor Sound Quality

- Ensure the speaker and your device are within optimal Bluetooth range.
- Check the volume levels on both the speaker and your connected device.
- Ensure there are no obstructions between the speaker and the connected device.

SPECIFICATIONS

Brand	XLEADER
Model Name	SoundAngel Mate
Item Model Number	USMATES
Material	Plastic
Color	D Bright Silver
Product Dimensions	1.97 x 1.97 x 1.97 inches
Item Weight	8.8 ounces (0.25 Kilograms)
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	100 Meters (66 feet)

Speaker Maximum Output Power	5 Watts
Water Resistance Level	Waterproof (IPX7)
Battery Type	1 Lithium Polymer battery (included)
Battery Capacity	120 Milliamp Hours
Charging Time	3 Hours
Playtime	Up to 15 hours
Control Method	Voice
Mounting Type	Freestanding

WARRANTY AND SUPPORT

The XLEADER SoundAngel Mate (2nd Gen) Pro Shower Speaker comes with a 3-year warranty. For any support inquiries, please refer to the contact information provided in your product packaging or visit the official XLEADER website.