

Akitas AK561

Akitas 2 in 1 Corded Upright Vacuum Cleaner

USER MANUAL

[Overview](#) [Setup](#) [Operation](#) [Introduction](#) [Product](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. Introduction

Thank you for choosing the Akitas 2 in 1 Corded Upright Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and retain it for future reference.

This versatile vacuum cleaner is designed for effective cleaning of various floor types, offering both upright and handheld functionality for comprehensive home cleaning.

2. Product Overview

2.1 Key Features

- **Powerful Energy Efficient Motor:** Provides strong suction power for effective cleaning.
- **Lightweight Design:** Weighs only 3kg for easy maneuverability and transport.
- **Electric Powered Turbo Spinning Brush Head:** Ensures balanced performance on both carpet and timber/tiled floors.
- **LED Light on Head:** Illuminates the cleaning path to easily spot dirt and debris.
- **2 in 1 Design:** Easily converts from an upright vacuum to a handheld unit for versatile cleaning.
- **Stainless Steel Covered HEPA Filter:** Washable and designed for extended life, capturing fine dust and allergens.

2.2 Product Components

Familiarize yourself with the main parts of your Akitas vacuum cleaner:



Figure 2.1: Full Upright Vacuum Assembly. This image shows the complete vacuum cleaner in its upright configuration, ready for floor cleaning.



Figure 2.2: Handheld Vacuum Unit. This image displays the main body of the vacuum detached, functioning as a portable handheld cleaner.



Figure 2.3: Motorized Floor Head with LED Lights. A detailed view of the brush head, highlighting the integrated LED illumination for improved visibility.



Figure 2.4: Crevice Tool and Dusting Brush. This image shows the versatile attachment used for cleaning tight spaces and delicate surfaces.

3. Setup and Assembly

Your Akitas vacuum cleaner requires minimal assembly before first use. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in Section 2.2 are present.
2. **Attach Handle:** Insert the handle into the top of the main vacuum body until it clicks securely into place.
3. **Connect Floor Head:** Align the main vacuum body with the motorized floor head and push down firmly until it locks.
4. **Cord Management:** Unwind the power cord and secure it using the cord clips on the handle, if available.
5. **Initial Filter Check:** Ensure the HEPA filter and dust cup are correctly installed before operation. Refer to Section 5.2 for filter installation details.

Your vacuum cleaner is now ready for use in upright mode.

4. Operating Instructions

4.1 General Operation

1. **Power Connection:** Plug the power cord into a suitable electrical outlet.
2. **Power On/Off:** Press the power button located on the handle to turn the vacuum cleaner ON. Press again to turn OFF.
3. **Cleaning:** Guide the vacuum cleaner across the surface to be cleaned. The LED lights on the floor head will illuminate the path.
4. **Maneuvering:** The lightweight design allows for easy steering around furniture and obstacles.



Figure 4.1: Vacuum in Use. Demonstrates the vacuum cleaner effectively cleaning a hard floor surface, with the LED lights active.

4.2 2-in-1 Functionality (Handheld Mode)

To convert your upright vacuum into a handheld unit:

1. **Disconnect Main Body:** Press the release button (usually near the base of the main body) and pull the main vacuum unit upwards to detach it from the floor head and handle.
2. **Attach Accessories:** Connect the crevice tool or dusting brush (Figure 2.4) directly to the nozzle of the handheld unit for cleaning upholstery, car interiors, or tight corners.
3. **Reassembly:** To return to upright mode, simply re-attach the handheld unit to the floor head and handle until it clicks securely.

5. Maintenance and Care

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

5.1 Dust Cup Emptying

1. **Disconnect Power:** Always unplug the vacuum cleaner from the power outlet before performing any maintenance.
2. **Remove Dust Cup:** Locate the dust cup release button (typically on the main body) and detach the dust cup.
3. **Empty Contents:** Hold the dust cup over a waste bin and open the bottom flap to empty accumulated dirt and debris.
4. **Clean Dust Cup:** Wipe the inside of the dust cup with a damp cloth if necessary. Ensure it is completely dry before reattaching.
5. **Reattach Dust Cup:** Securely re-attach the dust cup to the main vacuum body until it clicks into place.

5.2 Filter Cleaning

The stainless steel covered HEPA filter is washable and designed for longevity. Clean it regularly to maintain suction power.

1. **Access Filter:** With the dust cup removed, locate and carefully pull out the HEPA filter assembly.
2. **Wash Filter:** Rinse the HEPA filter under cool, running water until the water runs clear. Do not use detergents or hot water.
3. **Dry Filter:** Allow the filter to air dry completely for at least 24 hours before reinstallation. Do not use a dryer or direct heat.
4. **Reinstall Filter:** Once completely dry, place the HEPA filter back into its housing within the dust cup.

5.3 Brush Head Maintenance

Periodically check the motorized brush head for tangled hair or debris.

1. **Disconnect Power:** Unplug the vacuum cleaner.
2. **Access Brush Roll:** Turn the floor head upside down. You may need to use a coin or screwdriver to unlock the brush roll cover.
3. **Clean Brush Roll:** Carefully remove any hair, string, or debris wrapped around the brush roll using scissors.
4. **Reassemble:** Replace the brush roll and secure its cover.



Figure 5.1: Underside of Motorized Floor Head. This view shows the brush roll that requires periodic cleaning.

6. Troubleshooting

Before contacting customer support, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
Low suction power.	Dust cup is full.	Empty the dust cup (Section 5.1).
Low suction power.	HEPA filter is dirty or clogged.	Clean or replace the HEPA filter (Section 5.2). Ensure it is completely dry before reinstallation.
Low suction power.	Hose or nozzle is blocked.	Check for blockages in the hose, floor head, or handheld nozzle and remove them.
Brush roll not spinning.	Hair or debris tangled in brush roll.	Clean the brush roll (Section 5.3).
Brush roll not spinning.	Floor head not properly attached.	Ensure the floor head is securely connected to the main body.

7. Specifications

Technical details for your Akitas 2 in 1 Corded Upright Vacuum Cleaner:

Feature	Detail
Brand	Akitas
Model Number	AK561
Power / Wattage	600 watts
Item Weight	3 kg
Capacity	3 Kilograms (Dust Cup)
Noise Level	76 dB
Filter Type	HEPA Filter (Stainless Steel Covered)
Special Features	Corded, 2-in-1 Design, Turbo Spinning Brush Head, LED Light
Included Components	Crevice Tool, Dusting Brush, HEPA Filter

8. Warranty and Support







For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Akitas store online.

You can find more information and contact details by visiting the [Akitas Store on Amazon](#).

When contacting support, please have your model number (AK561) and purchase details ready.



Related Documents - AK561

	<p>Akitas X7 Spot Cleaner: User Manual and Guide</p> <p>Comprehensive guide for the Akitas X7 Spot Cleaner, covering features, usage instructions, maintenance, troubleshooting, and warranty information.</p>
	<p>Akitas Vacuum Cleaner User Manual and Accessories Guide</p> <p>Comprehensive user manual and accessories guide for Akitas vacuum cleaners, detailing operation, maintenance, and safety information for models like C1 and C6.</p>
	<p>Akitas V8 22.2v Cordless Vacuum Cleaner User Manual</p> <p>User manual for the Akitas V8 22.2v 150w 3-in-1 Cordless Upright Handheld Stick Vacuum Cleaner. Includes assembly, operation, and maintenance instructions.</p>
	<p>Akitas V10 Cordless Stick Vacuum Cleaner: User Manual, Features, and Warranty</p> <p>Comprehensive guide to the Akitas V10 Cordless Stick Vacuum Cleaner, covering features, specifications, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>Akitas C6 Deluxe Vacuum Cleaner Instruction Manual</p> <p>Detailed instruction manual for the Akitas C6 Deluxe Cylinder Vacuum Cleaner, a product by Akitas (Chelsea Company Limited), covering setup, operation, maintenance, safety precautions, and warranty information.</p>
	<p>Akitas C10T Bagless Cylinder Vacuum Cleaner - User Manual</p> <p>User manual for the Akitas C10T Bagless Cylinder Vacuum Cleaner, detailing features, specifications, safety precautions, assembly, operation, maintenance, and warranty information.</p>