



Manuals.plus /

› findtime /

› findtime Men's Digital Watch Waterproof Pedometer Watches Sport Watch Step Counter Calorie Military Watch with Stopwatch Alarm LED Backlight Countdown User Manual

findtime MS1

findtime Men's Digital Watch User Manual

MODEL: MS1

1. Introduction

Thank you for choosing the findtime Men's Digital Watch. This watch is designed for sport enthusiasts, featuring a step counter, LED backlight, stopwatch, countdown timer, and alarm functions. Its robust construction with an ABS case and stainless steel bottom cover makes it suitable for various outdoor activities. This manual provides detailed instructions on how to set up, operate, and maintain your watch.



Image: The findtime Men's Digital Watch in yellow, showcasing its design and digital display.

2. Setup and Initial Configuration

Before using your watch, please ensure it is properly set up. The watch features multiple buttons for navigation and setting:

- **MODE Button (Left-Bottom):** Cycles through different modes (Time, Pedometer, Stopwatch, Alarm, Countdown).
- **LIGHT Button (Left-Top):** Activates the EL backlight.
- **SET Button (Right-Top):** Used to enter setting mode for various functions.
- **START/UP Button (Right-Middle):** Used to start/stop functions or increase values during setting.
- **RESET/DOWN Button (Right-Bottom):** Used to reset functions or decrease values during setting.



Image: The watch face with labels indicating the functions of each button for easy setup and navigation.

Setting Time and Date:

1. In Time Mode, press and hold the **SET** button until the display flashes.
2. Use the **MODE** button to cycle through the settings (seconds, hours, minutes, year, month, day, 12/24 hour format).
3. Use the **START/UP** and **RESET/DOWN** buttons to adjust the values.
4. Press **SET** again to confirm and exit the setting mode.

3. Operating Modes

3.1. Pedometer Mode

This watch features a pedometer to track your activity. It records steps, calories burned, distance walked, and exercise time. It can save exercise data for the past 31 days.

PRODUCT DISPLAY



Image: A visual representation of the watch's activity tracking capabilities, showing steps, distance, and calories.

- To enter Pedometer Mode, press the **MODE** button until 'STEP' or a similar indicator appears.
- The watch will automatically begin counting steps when you start moving.
- Review historical data by navigating through the pedometer menu (refer to specific on-screen prompts).

3.2. Stopwatch Mode

The stopwatch function allows for precise timing of activities.

- Press the **MODE** button to navigate to Stopwatch Mode.
- Press **START/UP** to begin timing.
- Press **START/UP** again to pause.
- Press **RESET/DOWN** to reset the stopwatch to zero.

3.3. Alarm Mode

Set an alarm to remind you of important events.

- Press the **MODE** button to navigate to Alarm Mode.
- Press and hold **SET** to enter alarm setting mode.

- Use **START/UP** and **RESET/DOWN** to set the alarm time.
- Press **SET** to confirm.

3.4. Countdown Mode

Use the countdown timer for specific durations.

- Press the **MODE** button to navigate to Countdown Mode.
- Press and hold **SET** to enter countdown setting mode.
- Use **START/UP** and **RESET/DOWN** to set the desired countdown time.
- Press **START/UP** to begin the countdown.
- The watch will alert you when the countdown reaches zero.

3.5. EL Backlight

The EL backlight illuminates the display for visibility in low-light conditions.

- Press the **LIGHT** button to activate the backlight. It will remain on for a few seconds.




Image: A graphic illustrating various features of the watch, including sport step, calorie record, sport mileage, countdown, dual city time, luminous display, week display, water resistance, shockproof, hour report, low voltage detection, dual mode time, alarm mode, and stopwatch timing.

4. Maintenance

Water Resistance:

Your findtime watch is water resistant up to 50 meters (164 feet). This means it can withstand:

- Hand washing
- Cold showering
- Swimming

IMPORTANT NOTE:

- DO NOT immerse the watch in hot water or expose it to steam.
- DO NOT press any buttons while the watch is in water.



Image: The watch being splashed with water, visually confirming its 50-meter water resistance for daily use and swimming.

Cleaning:

To maintain the appearance and longevity of your watch, it is highly recommended to clean the strap regularly with a soft cloth.

5. Troubleshooting

- **Mist or Droplets Inside Watch:** If you observe mist or droplets inside the watch surface, please contact the manufacturer immediately for maintenance. This is crucial to prevent moisture corrosion of the internal components.
- **Pedometer Not Counting Steps:** Ensure the watch is worn securely on your wrist. Movement patterns can affect step counting accuracy. If the issue persists, try resetting the watch (refer to the 'Setup' section for basic reset procedures, if applicable, or contact support).
- **Display is Dark/Hard to Read:** Ensure the battery is not low. Use the EL backlight in low-light conditions. If the display remains consistently dim, contact customer support.

6. Specifications

Feature	Specification
Item Model Number	MS1
Case Diameter	1.73 inches / 44mm
Case Thickness	0.59 inches / 15mm
Weight	1.69 oz / 48g
Max Wrist Circumference	9 inches
Band Clasp Type	Buckle
Water Resistant Depth	50M / 164FT
Band Material	Silicone
Body Material	ABS
Movement	Quartz

PARAMETER



Image: A detailed diagram illustrating the physical dimensions of the watch, including case diameter, total length, and band width.

7. Warranty and Support

Your findtime Digital Watch comes with a **12-month warranty**. If you have any questions, concerns, or require maintenance, please do not hesitate to contact the manufacturer directly. Refer to the packaging or product information for specific contact details.

For any issues related to mist or droplets found inside the watch surface, it is imperative to contact the manufacturer immediately to prevent moisture corrosion of the internal components.