

[Manuals.plus](#) /

› [Rulefiss](#) /

› Rulefiss T7A Portable Bluetooth Speaker Instruction Manual

Rulefiss T7A

Rulefiss T7A Portable Bluetooth Speaker Instruction Manual

Model: T7A



INTRODUCTION

Thank you for purchasing the Rulefiss T7A Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Rulefiss T7A Portable Bluetooth Speaker
- 1 x Micro USB Charging Cable
- 1 x User Manual

PRODUCT OVERVIEW

The Rulefiss T7A is a versatile portable Bluetooth speaker designed for various environments, including showers and outdoor activities. It features IP7 waterproofing, LED lights, a built-in microphone, and dual pairing capabilities.

Button function description




Image: Front view of the Rulefiss T7A speaker, highlighting its control buttons and central T7A logo.

Button Functions

Portable bluetooth speaker

Rulefiss

ENJOY MUSIC ANYWHERE



Image: Detailed diagram illustrating the function of each button on the T7A speaker.

- **Power Button (On/Off):** Press and hold to power the speaker on or off.
- **M Button (Mode):** Short press to switch between Bluetooth mode and FM Radio mode.
- **T Button (LED Control):** Short press to cycle through LED light modes.
- **- Button (Volume Down / Next Song):** Short press to decrease volume. Long press to skip to the next song.
- **+ Button (Volume Up / Previous Song):** Short press to increase volume. Long press to go to the previous song.
- **Play/Pause Button:** Short press to play or pause music. Long press to search FM channels in FM mode.
- **Built-in Microphone:** For hands-free calling.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the micro USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status.

- Charging time: Approximately 3-4 hours.
- Playtime: Up to 7 hours at 50% volume.

2. Powering On/Off

To power on, press and hold the **Power Button** until the LED lights illuminate and you hear an audible prompt. To power off, press and hold the **Power Button** again until the lights turn off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, short press the **M Button** to switch to Bluetooth mode.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).

3. Search for "T7A" in your device's Bluetooth settings and select it to pair.
4. Once paired, the LED will stop flashing, and you will hear a confirmation sound.

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on.

4. Dual Pairing Function (TWS)

To achieve true wireless stereo (TWS) sound, you can pair two T7A speakers together.

1. Ensure both T7A speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the primary speaker), double-press the **Play/Pause Button**. The speakers will search for each other.
3. Once successfully paired, you will hear a confirmation sound, and the LED on the primary speaker will flash, while the secondary speaker's LED will be solid.
4. Now, connect your device to the primary speaker ("T7A") via Bluetooth as described in step 3.



Image: Illustration of two T7A speakers connected for dual pairing, enhancing the audio experience.

5. Attaching with Suction Cup

The T7A speaker features a built-in suction cup for easy attachment to smooth, flat surfaces such as glass, tiles, or the back of a phone/tablet. Ensure the surface is clean and dry for optimal adhesion.



Image: The T7A speaker securely attached to a shower wall, demonstrating its waterproof capability and suction cup feature.

OPERATING INSTRUCTIONS

1. Playing Music

After successful Bluetooth pairing, you can play music from your connected device. Use the **Play/Pause Button** on the speaker to control playback. Use the **+** and **-** buttons for volume adjustment (short press) or track navigation (long press). For optimal volume, ensure both your connected device and the speaker are set to their maximum volume levels. For iOS devices, continuously short press the '+' button on the speaker or increase phone volume. For Android devices, ensure phone volume is maximum, then continuously short press the '+' button on the speaker.

2. FM Radio Mode

To use the FM radio function:

1. Insert the supplied micro USB charging cable into the speaker's charging port. This cable acts as an FM antenna.
2. Short press the **M Button** to switch to FM Radio mode.
3. Long press the **Play/Pause Button** to automatically scan and save available FM channels.
4. Use the **+** and **-** buttons (long press) to switch between saved channels.



Image: The T7A speaker being used in diverse environments, including an office, picnic, and camping, demonstrating its portability and FM radio capability.

3. LED Light Modes

The speaker features colorful LED lights that can enhance your listening experience. Short press the **T Button** to cycle through different light modes, including beat-driven and fixed color options. You can also use the LED light function independently without playing music.

BEAT-DRIVEN LIGHT SHOW

customizable modes enhances your beats
tailor the atmosphere to suit your mood

7 multi-coloured LED mood lights
with fixed colour or scrolling option




Image: The T7A speaker showcasing its customizable multi-colored LED mood lights, creating a vibrant atmosphere.

4. Hands-Free Calling

When connected to your smartphone via Bluetooth, the built-in microphone allows you to answer or end calls directly from the speaker.

- **Answer Call:** Short press the **Play/Pause Button**.
- **End Call:** Short press the **Play/Pause Button** during a call.
- **Reject Call:** Long press the **Play/Pause Button** when an incoming call rings.

MAINTENANCE

Cleaning

The T7A speaker is IP7 waterproof, meaning it can withstand immersion up to 3 feet for 30 minutes. To clean, gently wipe the surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is

securely closed before exposing the speaker to water.



Image: The T7A speaker in a wet environment, highlighting its waterproof capabilities.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically (e.g., every 3 months) to maintain battery health.

Battery Care

The speaker contains a built-in rechargeable Li-Ion battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Do not expose the speaker to temperatures above 60°C (140°F).
- Use only the provided charging cable or a certified equivalent.

TROUBLESHOOTING

Speaker does not power on

- Ensure the battery is charged. Connect the speaker to a power source using the micro USB cable.
- Press and hold the Power Button for a few seconds to ensure it's not just a short press.

Cannot pair with Bluetooth device

- Make sure the speaker is in Bluetooth pairing mode (flashing blue LED).
- Ensure the speaker is within 10 meters (33 feet) of your device.
- Turn off Bluetooth on other nearby devices that might be trying to connect.
- Forget "T7A" from your device's Bluetooth list and try pairing again.
- Restart both the speaker and your Bluetooth device.

No sound or low volume

- Increase the volume on both the speaker and your connected device.
- Ensure the speaker is properly paired and connected.
- Check if the audio source on your device is playing.

FM Radio reception is poor

- Ensure the micro USB cable is securely plugged into the speaker's charging port, as it acts as the antenna.

- Try repositioning the speaker or the USB cable for better signal reception.
- Perform an automatic channel scan again by long pressing the Play/Pause button in FM mode.

Suction cup does not hold

- Ensure the surface is clean, dry, and smooth.
- Press firmly on the speaker to remove any air bubbles under the suction cup.
- Avoid porous or textured surfaces.

SPECIFICATIONS

Model Name	T7A
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (33 feet)
Speaker Type	Portable, 3D, Surround Sound
Speaker Maximum Output Power	50 Watts
Water Resistance Level	IP7 Waterproof
Power Source	Battery Powered (1 Lithium Polymer battery included)
Battery Life	Up to 7 hours (at 50% volume)
Charging Time	3-4 hours
Control Method	Touch Buttons
Product Dimensions	1.97"D x 1.97"W x 1.97"H
Item Weight	9.9 ounces
Mounting Type	Suction Cup Mount

WARRANTY INFORMATION

This Rulefiss T7A speaker comes with a limited warranty. Please refer to the product packaging or contact customer support for specific warranty terms and conditions. The warranty typically covers manufacturing defects under normal use. For returns or replacements, please adhere to the retailer's return policy, which is generally 30 days from the purchase date.

CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact Rulefiss customer support. You can typically find contact information on the product packaging, the official Rulefiss website, or through your purchase platform.

When contacting support, please have your product model (T7A) and purchase details ready.

