

[Manuals.plus](#) /

> [kensen](#) /

> kensen 7D Head Shaver - 5-in-1 Electric Grooming Kit User Manual

kensen JK-5588A

kensen 7D Head Shaver - 5-in-1 Electric Grooming Kit

Model: JK-5588A

INTRODUCTION

Thank you for choosing the kensen 7D Head Shaver. This versatile 5-in-1 electric grooming kit is designed to provide a comprehensive and comfortable shaving experience for bald men, as well as for beard and nose hair trimming, facial cleansing, and massage. With its advanced features like 7D floating heads, IPX6 waterproofing, and a long-lasting battery, this device offers convenience and efficiency for your daily grooming routine.

SAFETY INFORMATION

Important Safety Precautions:

Use only as directed. Keep out of reach of children. Consult a physician if you have sensitive skin or any health concerns.

- Do not disassemble or attempt to repair the device yourself.
- Keep the charging port dry before charging.
- Avoid using the shaver on irritated or broken skin.
- Ensure the device is fully charged before first use.

WHAT'S IN THE BOX

Your kensen 7D Head Shaver package includes the following components:

- kensen 7D Electric Head Shaver (Main Unit)
- Nose Hair Trimmer Attachment
- Beard Trimmer Attachment
- Facial Massager Attachment
- Cleansing Brush Attachment
- USB Charging Cable
- Cleaning Brush
- Travel Case

- User Manual (this document)



Image: The kensen 7D Head Shaver kit, showing the main shaver unit, various detachable heads (nose trimmer, beard trimmer, facial massager, cleansing brush), USB cable, and a black travel case.



Image: A visual representation of all items included in the package, laid out neatly, highlighting the shaver, its attachments, and the travel case.

PRODUCT FEATURES

7D Fast & Smooth Floating Shaving Head

The shaver features 7 independent floating heads with skin-friendly and durable blades. This design allows for 360-degree shaving, adapting automatically to the contours of your face, neck, and head, ensuring close contact with the skin for an efficient, comfortable, and smooth shave.

UPGRADE 7D FLOATING HEAD

Fit every contours of your head, face & jaw Ergonomic Shaving Angle




Image: An illustration demonstrating how the 7D floating head adjusts to the curves of the head, face, and jaw for optimal contact.

Powerful 9200 RPM Motor & Precision Dual-Ring Blades

Equipped with a powerful 9200 RPM motor, this electric shaver delivers strong performance for effective shaving. The dual-ring blade mesh increases shaving volume while maintaining a comfortable feel. The 3cr13 stainless steel blades utilize advanced self-sharpening technology for consistent sharpness and durability.

SHARP AND DURABLE BLADES



360° floating
shaving



Double ring
knife net



Self-sharpening
blades



Alloy stainless
steel

Image: A detailed view of the shaver's 7 heads, highlighting the dual-ring blade design and the self-sharpening feature for a smooth shave.

USB Quick Charging & LED Display

The built-in lithium battery provides long-lasting power. A quick 2-hour USB charge offers up to 90 minutes of shaving time. The intelligent LED display shows the power percentage, travel lock status, charging tips, and washable tips icon, ensuring you are always aware of the device's status.

INTELLIGENT LED DIGITAL DISPLAY



BATTERY LEVEL DISPLAY

Digital display, power reminder at all times.



TRAVEL LOCK

Long press the power button for 3s, the travel lock locks or unlocks.



CLEANING TIPS

Work appears for 15 minutes, shutdown disappears.



CHARGING INDICATOR

When plugged in, the current battery level is displayed.



Image: A close-up of the shaver's handle, displaying the LED screen with battery percentage, travel lock indicator, and cleaning reminder icons.

90 MINUTES LONG BATTERY LIFE



Image: The shaver connected via a USB cable to a laptop, illustrating its convenient USB charging capability and long battery life.

IPX6 Waterproof & Easy to Clean

The kensen electric razor is IPX6 waterproof, allowing for both wet and dry shaving. You can comfortably use it in the shower with gel or foam, or for a quick dry shave. Its removable design makes it easy to clean under running water, ensuring hygiene and durability.



Image: A man using the shaver in the shower with shaving foam, emphasizing its 100% waterproof design for wet shaving.




Image: A side-by-side comparison showing the shaver being used for both dry shaving and wet shaving, highlighting its versatility.

5-in-1 Grooming Kit

This comprehensive kit includes five detachable accessories: the main head shaver, a nose hair trimmer, a beard trimmer, a facial massager, and a cleansing brush. This allows for all your body shaving, grooming, and cleansing needs with a single device.



Image: A collage of five images, each showing a man using one of the five different attachments of the grooming kit (head shaver, nose trimmer, beard trimmer, facial massager, cleansing brush).

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, fully charge the shaver. Connect the USB charging cable to the shaver's charging port and plug the other end into a compatible USB power source (e.g., computer, wall adapter). The LED display will show the charging progress.
3. **Attach Head:** Select the desired attachment (e.g., 7D shaver head, nose trimmer) and align it with the main unit. Gently push until it clicks securely into place.

OPERATING INSTRUCTIONS

General Operation

- **Power On/Off:** Press the power button once to turn the shaver on or off.
- **Travel Lock:** To activate the travel lock, press and hold the power button for 3 seconds. The travel lock icon will appear on the LED display. To unlock, press and hold the power button for 3 seconds again.

Using the 7D Head Shaver

- **Dry Shave:** For a quick and convenient shave, ensure your skin is clean and dry. Gently move the shaver in circular motions over the area to be shaved.
- **Wet Shave:** For a more comfortable shave, apply shaving gel or foam to your skin. Move the shaver in gentle circular motions. Rinse the shaver head under running water during and after use to prevent clogging.
- **Optimal Results:** For best results, shave against the direction of hair growth.

Using Other Attachments

- **Nose Hair Trimmer:** Insert the trimmer head gently into your nostril or ear canal. Move it slowly to trim unwanted

hair.

- **Beard Trimmer:** Attach the beard trimmer head. Use it to shape and trim your beard or mustache.
- **Facial Massager:** Attach the massager head. Gently move it over your face in circular motions to stimulate blood circulation.
- **Cleansing Brush:** Attach the cleansing brush head. Apply a small amount of facial cleanser to the brush or your face. Gently move the brush in circular motions to cleanse your skin.

MAINTENANCE & CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your kensen shaver.

1. **Daily Cleaning:** After each use, turn off the shaver. Detach the shaver head by pulling it away from the main unit. Rinse the shaver head and the hair chamber under running water until all hair and debris are removed.
2. **Deep Cleaning (Shaver Heads):**

Step 1: Pull away the shaver beads on the side one by one.

HOW TO OPENTHE SHAVER HEADS ?



STEP1
Pull away the shaver beads on the side one by one



STEP2
Rotate and pull out the middle head in the arrow direction indicated on it




STEP3
Clean the shaver head part and the hair storage of some with running water


Image: Illustration showing how to gently pull each of the seven individual shaver heads outwards from the main assembly.

Step 2: Rotate and pull out the middle head in the arrow direction indicated on it.

HOW TO OPENTHE SHAVER HEADS ?



STEP1
Pull away the shaver beads on the side one by one



STEP2
Rotate and pull out the middle head in the arrow direction indicated on it




STEP3
Clean the shaver head part and the hair storage of some with running water

Image: Illustration showing how to twist and remove the central shaver head, which allows access to the inner chamber for thorough cleaning.


Step 3: Clean the shaver head part and the hair storage of some with running water.

HOW TO OPEN THE SHAVER HEADS ?



STEP1

Pull away the shaver beads on the side one by one



STEP2

Rotate and pull out the middle head in the arrow direction indicated on it



STEP3

Clean the shaver head part and the hair storage of some with running water

Image: Illustration showing the shaver head being rinsed under running water, demonstrating the ease of cleaning due to its waterproof design.

3. **Drying:** After cleaning, shake off excess water and allow the shaver head to air dry completely before reattaching or storing.
4. **Storage:** Store the shaver and its accessories in the provided travel case in a cool, dry place, away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or depleted; Travel lock is activated.	Charge the shaver for at least 2 hours. Deactivate travel lock by pressing and holding the power button for 3 seconds.
Shaver performance is poor or pulls hair.	Shaver heads are clogged with hair; Blades are dull or damaged.	Clean the shaver heads thoroughly as per maintenance instructions. Consider replacing the shaver heads if performance does not improve.
LED display is not working.	Device malfunction.	Ensure the shaver is charged. If the issue persists, contact customer support.
Shaver does not charge.	Charging cable or adapter is faulty; Charging port is dirty or damaged.	Try a different USB cable and power adapter. Ensure the charging port is clean and dry.

SPECIFICATIONS

Feature	Detail
Product Dimensions	7.2 x 4.2 x 3.5 inches; 1.37 ounces
Item Model Number	JK-5588A
Batteries	1 Lithium Ion battery required
Manufacturer	kensen
Recommended Uses	Beard, Face, Nose Hair, Head

Feature	Detail
Special Features	Battery Indicator, Dry Shave, Floating Head, Rechargeable, Washable
Power Source	Battery Powered

WARRANTY & SUPPORT

kensen is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your kensen 7D Head Shaver comes with a 12-month replacement warranty.
- **Lifetime Service:** We offer lifetime service for our products.
- **Customer Support:** Our after-sales service team aims to respond to inquiries and resolve issues within 12 hours.
For assistance, please contact us through the retailer's platform or visit the official kensen store.
- **Online Store:** [Visit the kensen Store on Amazon](#)