

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Costzon](#) /
- › [Costzon 4-Wheel Off-Road Pedal Go Kart for Kids Instruction Manual](#)

Costzon B09DT3DFQZ

Costzon 4-Wheel Off-Road Pedal Go Kart for Kids

Model: B09DT3DFQZ

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Costzon 4-Wheel Off-Road Pedal Go Kart. Please read all instructions carefully before use and retain this manual for future reference.

The pedal go-kart is designed for children aged 3 to 8 years, offering an engaging and active outdoor play experience. It features an adjustable seat, responsive steering, and a dual brake system for enhanced control.



Image: Two young children playing with the green Costzon pedal go-kart in a park setting, one riding and one pushing.

SAFETY INFORMATION

- **Adult Supervision Required:** Always supervise children while they are operating the go-kart.
- **Protective Gear:** Ensure the rider wears appropriate safety gear, including a helmet, knee pads, and elbow pads.
- **Safe Riding Environment:** Use the go-kart on flat, smooth surfaces away from traffic, steep inclines, swimming pools, or other hazards. Avoid riding on uneven terrain, mud, or wet surfaces.
- **Weight Limit:** Do not exceed the maximum recommended weight capacity of 66 lbs (approximately 30 kg).
- **Pre-Ride Check:** Before each use, inspect the go-kart for loose parts, damaged components, and proper tire inflation.
- **Braking:** Instruct the child on how to use the handbrake effectively to stop the go-kart.
- **No Passengers:** This go-kart is designed for a single rider only.

PARTS LIST

Before assembly, ensure all parts are present and undamaged. Refer to the assembly video for visual guidance.

- Main Go-Kart Frame (pre-assembled with pedals and chain cover)
- Steering Wheel
- Steering Shaft Support
- Front Panel Plate
- Seat
- License Plate
- Front Steering Bar
- Wheels (4x)
- Springs (2x for front suspension)
- Various bolts, nuts, and washers (refer to hardware kit)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your pedal go-kart. For a detailed visual guide, please watch the provided installation video.

Step 1: Attach Front Panel Plate

Secure the front panel plate to the main frame using the appropriate bolts and washers. Ensure it is firmly attached.



Image: The front section of the go-kart with the front panel plate attached, illustrating the overall structure.

Step 2: Install Steering Bar

Fix the steering bar to the front axle assembly using the specified bolts and washers. Ensure smooth movement.

Step 3: Connect Steering Shaft Support

Attach the steering shaft support to the go-kart frame. This component connects the steering bar to the steering wheel mechanism.

Step 4: Mount Steering Wheel and License Plate

Insert the steering wheel onto the steering shaft and secure it with the provided washers and nut. Then, attach the license plate to the front of the go-kart.



Image: A top-down view of the go-kart, highlighting the installed steering wheel and front license plate.

Step 5: Install the Seat

Position the seat onto the frame and secure it using the M5*40mm bolts and 5*14 washers. The seat is adjustable to accommodate different rider heights.

Back and Forth Adjustable Seat



Image: A side view of the go-kart illustrating the adjustable seat, which can be moved forward or backward.

Step 6: Final Checks

Ensure all nuts and bolts are securely tightened. Check tire inflation and verify that the steering and braking systems function correctly before allowing a child to ride.

Assembly Video

For a step-by-step visual guide on assembling your go-kart, please watch the video below:


Video: Detailed installation guide for the pedal go-kart, demonstrating each assembly step.

OPERATING INSTRUCTIONS

Starting the Go-Kart

To start moving, ensure the gear lever (located on the middle of the chain guard) is pulled forward for direct start. The rider then pedals forward to propel the go-kart.

Flexible Gear Lever/Reverse



Image: A close-up view of the gear lever, indicating the 'Direct Start' and 'Neutral Position' settings.

Steering

The go-kart is steered using the steering wheel. Turn the wheel left to go left and right to go right. The responsive steering allows for easy maneuverability.

Braking

To stop the go-kart, pull the handbrake lever located next to the seat. This engages the dual brake system for effective stopping. The go-kart can also be pedaled backward.

Sensitive Double Brake System



Image: A detailed view of the go-kart's sensitive double brake system, showing the handbrake lever.

Adjusting the Seat

The seat can be adjusted to two different positions to accommodate various rider heights. Locate the adjustment mechanism beneath the seat and slide it to the desired position, ensuring it locks securely.

Operation Videos

Watch these videos for demonstrations of the go-kart's features and operation:

Video: A demonstration of the Costzon Pedal Kart, highlighting its features and ease of use.

Video: A child riding the Costzon Go Kart, showcasing its adjustable seat, flexible steering, and handbrake.

MAINTENANCE

- **Cleaning:** Clean the go-kart regularly with a damp cloth. Avoid harsh chemicals that may damage the finish.
- **Tire Care:** Check tire pressure periodically and inflate as needed. The EVA rubber tires are designed for durability and skid-proof performance.
- **Fasteners:** Regularly inspect all bolts, nuts, and other fasteners to ensure they are tight. Tighten any loose fasteners to prevent accidents.
- **Lubrication:** Periodically lubricate moving parts, such as the chain and pedal mechanism, with a suitable lubricant to ensure smooth operation.
- **Storage:** Store the go-kart in a dry, covered area to protect it from weather elements when not in use.

TROUBLESHOOTING

- **Difficulty Pedaling:**

- Check if the chain is properly aligned and lubricated.
- Ensure the gear lever is in the "Direct Start" position, not "Neutral."

- **Steering Issues:**

- Verify that the steering shaft and connections are securely fastened.
- Inspect the front wheels for any obstructions or damage.

- **Brake Malfunction:**

- Check the handbrake cable for proper tension and ensure it is not frayed or stuck.
- Inspect the brake pads for wear and tear.

SPECIFICATIONS

Product Dimensions	39.96 x 24.02 x 24.41 inches
Item Weight	20 pounds
Recommended Age	36 months - 8 years
Maximum Weight Capacity	66 lbs (approx. 30 kg)
Material	Metal frame, Polypropylene plastic, EVA rubber tires

Weight: 20 LBS

Recommend Age: 3-8 Age



Image: Visual representation of the go-kart's dimensions and weight.

WARRANTY & SUPPORT

For warranty information, technical support, or replacement parts, please contact Costzon customer service. Refer to your purchase documentation for specific contact details or visit the official Costzon website.

We are committed to providing high-quality products and support to ensure your satisfaction.