

[Manuals.plus](#) /

› [LUXPRO](#) /

› LUXPRO LP385 Rechargeable 500 Lumen Palm Light with Power Bank and Magnet User Manual

LUXPRO LP385

LUXPRO LP385 Rechargeable 500 Lumen Palm Light User Manual

Model: LP385

1. INTRODUCTION

The LUXPRO LP385 is a versatile, rechargeable palm light designed for various applications. It features a bright 500-lumen LED light, an integrated power bank for charging other devices, and a magnetic base for hands-free use. Its durable, water-resistant construction ensures reliability in diverse environments.



Figure 1: The LUXPRO LP385 Rechargeable Palm Light. This image shows the compact, rectangular light with its LED panel and a USB charging cable connected.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- LUXPRO LP385 Rechargeable Palm Light
- USB Charging Cable

3. SETUP AND INITIAL CHARGING

3.1 Charging the Device

Before first use, fully charge your LP385 palm light. The device includes a built-in rechargeable Lithium-Ion battery. A full charge typically takes approximately 6 hours.

1. Locate the USB charging port on the LP385.
2. Connect the included USB charging cable to the LP385's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator light will illuminate to show the charging status.
5. Once fully charged, disconnect the cable.

Charge On The Go

This light also features a power bank that can be used to charge your portable devices



Figure 2: The LP385 charging a smartphone. This image illustrates the power bank functionality, showing the LP385 connected via USB to a mobile device.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Brightness Modes

The LP385 features multiple brightness settings. To operate the light:

- Press the power button once to turn the light on to its High brightness mode (500 lumens).
- Press the power button a second time to switch to Low brightness mode (250 lumens).
- Press the power button a third time to turn the light off.



Figure 3: The LP385 emitting light, highlighting its 500-lumen output. This image shows the light illuminating a tent interior, demonstrating its brightness.



Figure 4: A graphic detailing the brightness, run time, beam distance, shockproof rating, and weatherproof rating of the LP385. It shows High brightness at 500 lumens for 4 hours and Low brightness at 250 lumens for 8 hours.

4.2 Using the Power Bank Feature

The LP385 can also serve as a portable power bank to charge other electronic devices.

1. Ensure the LP385 has sufficient charge.
2. Connect your electronic device (e.g., smartphone, tablet) to the LP385's USB output port using your device's charging cable.
3. The LP385 will begin charging your device.

4.3 Magnetic Attachment

The LP385 features a strong magnetic back, allowing for convenient, hands-free placement on metal surfaces.

- Simply place the back of the LP385 onto any ferrous metal surface.
- Ensure the light is securely attached before releasing it.



Attach to Metal Surfaces

Features a strong magnetic back, so you can place these lights where needed and operate hands-free.

Figure 5: The LP385 magnetically attached to a yellow metal surface. This image demonstrates the hands-free capability of the light.

5. MAINTENANCE

5.1 Cleaning

To maintain the performance and appearance of your LP385:

- Wipe the exterior with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these may damage the rubberized finish.
- Ensure the charging port cover is securely closed to maintain water resistance.

5.2 Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- Recharge the battery periodically if stored for a long time to prevent deep discharge.

6. TROUBLESHOOTING

If you encounter issues with your LP385, consider the following:

- **Light not turning on:** Ensure the battery is charged. Connect the device to a power source using the USB cable and allow it to charge for at least 30 minutes before attempting to turn it on again.
- **Device not charging:** Verify that the USB cable is securely connected to both the LP385 and the power source. Try a different USB cable or power source.
- **Power bank not charging other devices:** Ensure the LP385 has sufficient charge. Check the connection between the LP385 and the device you are trying to charge.

If problems persist, refer to the warranty information for further assistance.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	LP385
Brightness (High)	500 Lumens
Brightness (Low)	250 Lumens
Run Time (High)	4 Hours
Run Time (Low)	8 Hours
Beam Distance (High)	28 Meters
Beam Distance (Low)	20 Meters
Water Resistance	IPX4 (Water Resistant)
Battery Type	Rechargeable Lithium-Ion (1 included)
Charging Time	Approximately 6 hours
Dimensions	4.5 x 2.5 x 1.5 inches
Weight	7 ounces
Material	Plastic with Rubberized Finish
Special Features	Portable, Rechargeable, Power Bank, Magnetic Base

IPX4 Water Resistant Rating

Protected from splashing water from all directions




Figure 6: The LP385 with text indicating its IPX4 water-resistant rating. This image visually confirms the device's protection against splashing water.

8. WARRANTY AND CUSTOMER SUPPORT

8.1 Warranty Information

The LUXPRO LP385 comes with a 90-day limited warranty against manufacturer's defects. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty claims, or general inquiries, please contact your retailer or visit the official LUXPRO website for support resources.

You can find more information about LUXPRO products and support at the [LUXPRO Brand Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09DTC6L41>

More documents and user manuals: <https://manuals.plus/>