

[Manuals.plus](#) /

> [BOFENG](#) /

> BOFENG Metal Bed Frame Full Size with Industrial Headboard - Instruction Manual

BOFENG 1

BOFENG Metal Bed Frame Full Size with Industrial Headboard - Instruction Manual

Model: 1

INTRODUCTION

This manual provides detailed instructions for the assembly, proper use, maintenance, and troubleshooting of your BOFENG Full Size Metal Bed Frame with Industrial Headboard. Please read all instructions carefully before assembly and retain this manual for future reference.



Image: Fully assembled BOFENG Full Size Metal Bed Frame, black, with an industrial-style headboard, shown in a modern bedroom with a mattress and bedding.

SAFETY INFORMATION

- Be careful while assembling, disassembling, and handling the bed frame to avoid injury from sharp edges.
- Ensure all bolts and screws are securely tightened after assembly and periodically check for looseness.
- Do not exceed the maximum weight capacity of 500 lbs (approximately 227 kg).
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid jumping on the bed frame, as this can compromise its structural integrity and lead to injury.

SETUP AND ASSEMBLY INSTRUCTIONS

The BOFENG Metal Bed Frame is designed for straightforward assembly. All necessary tools and hardware are included in the package. It is recommended to assemble the bed frame with at least two people.

Package Contents:

- Bed Frame Components (Headboard, Footboard, Side Rails, Support Legs, Slats)
- Assembly Manual
- Screws and Bolts
- Allen Key

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a rug or blanket) to prevent scratches. Verify all parts are present against the parts list in your included assembly manual.
2. **Assemble Headboard and Footboard:** Attach the horizontal bars to the vertical posts of the headboard and footboard using the provided screws and Allen key. Do not fully tighten screws at this stage.
3. **Connect Side Rails:** Attach the side rails to the assembled headboard and footboard. Ensure the connections are secure but do not fully tighten the bolts yet.
4. **Install Center Support Legs:** Attach any central support legs to the main frame structure as indicated in the manual.
5. **Place Slats:** Position the metal slats across the frame. The slats are designed to prevent mattress sagging and eliminate the need for a box spring. Ensure they are evenly spaced and secured.
6. **Final Tightening:** Once all components are in place and aligned, systematically tighten all screws and bolts using the Allen key. Ensure all connections are firm and stable. *Important: Do not tighten any bolts fully until the entire frame is assembled to allow for proper alignment.*
7. **Check Stability:** Gently shake the assembled frame to ensure it is stable and all connections are secure.



Image: Disassembled BOFENG Full Size Metal Bed Frame, showing the headboard, footboard, side rails, and support slats, ready for assembly.



Image: Detail of the anti-mattress sliding design, a small raised edge on the bed frame's side rail, intended to keep the mattress in place.

OPERATING INSTRUCTIONS

Your BOFENG Metal Bed Frame is designed for optimal support and comfort. Follow these guidelines for proper use:

- **Mattress Placement:** Place your full-size mattress directly onto the steel slats. A box spring is not required for this platform bed frame.
- **Weight Capacity:** The bed frame is designed to support a maximum weight of 500 lbs (approximately 227 kg), including the mattress and occupants. Do not exceed this limit.
- **Under-Bed Storage:** The frame provides approximately 10.6 inches of clearance underneath, offering convenient space for storage boxes, luggage, or other items.



Image: A side view of the bed frame illustrating the 10.6-inch clearance beneath, with small storage drawers placed in the space.

MAINTENANCE

Regular maintenance will help prolong the life and stability of your bed frame:

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the powder-coated finish.
- **Check Connections:** Periodically (e.g., every 3-6 months) inspect all bolts and screws to ensure they remain tight. Re-tighten any loose connections to maintain stability and prevent squeaking.
- **Slat Inspection:** Ensure all steel slats are properly seated and not bent or damaged. Replace any damaged slats if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or incorrect assembly.	Ensure all bolts are fully tightened. Review assembly steps to confirm correct installation. Remember to only fully tighten bolts after all parts are loosely connected.
Squeaking noises.	Loose connections, friction between metal parts, or uneven floor.	Re-tighten all bolts. Apply a small amount of lubricant (e.g., silicone spray) to connection points if squeaking persists. Ensure the bed is on a level surface.
Mattress slides on the frame.	Lack of anti-slip features or mattress material.	The frame includes an anti-mattress sliding design. Ensure your mattress is properly seated against these features. Consider using a non-slip mattress pad if sliding continues.
Bent or damaged slats/frame.	Exceeded weight capacity or improper use (e.g., jumping).	Ensure the total weight on the bed does not exceed 500 lbs. Avoid activities that put excessive stress on the frame. Contact customer support for replacement parts if damage is significant.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	BOFENG
Model Number	1
Size	Full
Color	Black
Material	Metal
Product Dimensions (L x W x H)	77.95" x 54.92" x 35.43" (approx. 80 x 60 x 50 cm)
Under-Bed Clearance	10.6 inches
Item Weight	16.1 kg (approx. 35.5 lbs)
Special Feature	Squeak Resistant, No Box Spring Needed
Compatible Mattress Size	Full




Image: Technical diagram illustrating the length (77.95"), width (54.92"), headboard height (35.43"), and under-bed clearance (10.6") of the bed frame.

WARRANTY INFORMATION

This BOFENG Metal Bed Frame product includes a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, maintenance, or warranty of your BOFENG Metal Bed Frame, please do not hesitate to contact our customer service team. We are committed to providing a satisfactory solution for any inquiries.

For support, please refer to the contact information provided with your purchase or visit the official BOFENG store on Amazon: [BOFENG Store on Amazon](#).

PRODUCT VIDEOS

No official product videos from the seller are available for this model at this time.